


Type 70906X

Thyristor power units TYA 201, 202 and 203



Typ 709061/8-01-020



Typ 709062/8-01-100



Typ 709063/8-01-20

Interface description
for Types 709061,-62, and -63

70906100T92Z001K000



Contents

| | | |
|----------|--|-----------|
| 1 | Introduction | 5 |
| 1.1 | Preface | 5 |
| 1.2 | Typographical conventions | 6 |
| 1.2.1 | Warning signs | 6 |
| 1.2.2 | Note signs | 6 |
| 1.2.3 | Representation | 7 |
| 1.3 | Available interfaces | 7 |
| 1.4 | Identifying the device version | 7 |
| 1.5 | Interface connection | 8 |
| 1.6 | Termination resistor of the serial RS422/485 interface | 8 |
| 1.7 | Configuration | 9 |
| 1.7.1 | Baud rate | 9 |
| 1.7.2 | Data format | 9 |
| 1.7.3 | Device address | 9 |
| 1.7.4 | Min. response time | 10 |
| 2 | Protocol description | 11 |
| 2.1 | Master-Slave principle | 11 |
| 2.2 | Transmission mode (RTU) | 11 |
| 2.3 | Device address | 12 |
| 2.4 | Timing of the communication | 12 |
| 2.5 | Troubleshooting | 14 |
| 2.6 | Recognition of bus errors | 15 |
| 2.7 | Checksum (CRC16) | 15 |
| 3 | Functions | 17 |
| 3.1 | Read n words | 17 |
| 3.2 | Writing a word | 18 |
| 3.3 | Write n words | 19 |

Contents

| | | |
|------------|--|-----------|
| 4 | Data flow | 21 |
| 4.1 | Transmission formats | 21 |
| 4.1.1 | Integer values | 21 |
| 4.1.2 | Float values | 21 |
| 4.1.3 | Strings (texts) | 22 |
| 5 | Address tables | 23 |
| 5.1 | Device data | 23 |
| 5.2 | Type codes and options | 23 |
| 5.3 | Measured values | 24 |
| 5.4 | Binary signals (bit field) | 25 |
| 5.5 | Digital inputs and -output | 28 |
| 5.6 | Device status | 29 |
| 5.7 | Faults | 30 |
| 5.8 | Parameters of the operator level (storage in the RAM) | 32 |
| 6 | Default values via interface | 33 |
| 6.1 | Default set point values via interface | 33 |
| 6.2 | α-default value via interface | 33 |
| 6.3 | Controlling the analog output via Interface | 34 |
| 6.4 | Controlling the binary output via Interface | 34 |
| 6.5 | External Inhibit and external binary input1 and 2 | 34 |

1.1 Preface



Please read these operating instructions before starting up the instrument. Keep these operating instructions in a place that is accessible to all users at all times.

Please help us to improve this manual. Your suggestions will be welcome.

Warranty



All necessary settings are described in this Operating Manual. Handling the device in any way that is not described in the Operating Manual or that is expressly forbidden will jeopardize your warranty rights.

Please contact the nearest subsidiary or the head office should you encounter any problems.

Service

Service see last page

1 Introduction

1.2 Typographical conventions

1.2.1 Warning signs

Danger



This symbol is used when there may be danger to persons if the instructions are ignored or not followed correctly!

Caution



This sign is used where there may be damage to equipment or data if the instructions are ignored or not followed correctly!

ESD



This symbol is used when precautions are to be taken for handling **electrostatic discharge endangered components**.

1.2.2 Note signs

Note



This symbol is used when your attention is drawn to special information.

Reference



This symbol refers to **further information** contained in other manuals, chapters or sections.

Footnote

abc¹

Footnotes are comments that **refer** to specific text sections. Footnotes consist of two parts:
A marker in the text and the footnote text itself.
The markers in the text are arranged as continuous superscript numbers.

String of commands

Config level → Power controller → Operating mode

Small arrows between words are intended to facilitate faster location of parameters in the configuration level.

1.2.3 Representation

Hexadecimal number 0x0010 A hexadecimal number is identified by "0x" preceding the actual number (here: 16 decimal).

1.3 Available interfaces


The setup interface on the front (USB connector, type B Mini 5-pole) is fitted in every device.

An RS422 / RS485 (4-pole screw and plug-type connector on the device bottom) or Profibus interface (9-pole D-Sub connector on the front) must be specified in the order.

This operating manual only describes communication via the RS422/485 interface using the Modbus protocol.


1.4 Identifying the device version

Only devices having 54 in the type code (7) are equipped with the RS422/485 interface.




On the device

- * Press PGM
- * Select the "Device info" menu point and press PGM.




1 Introduction

1.5 Interface connection

| Connection | Modbus | | RS422 | RS485 |
|--|--------|---|---------|--------------|
| Plug-in screw terminals on the underside of the case | 19 |  | TxD (-) | RxD/TxD B(-) |
| | 18 | | TxD (+) | RxD/TxD A(+) |
| | 17 | | RxD (-) | - |
| | 16 | | RxD (+) | - |

(RS422/485 Modbus)




1.6 Termination resistor of the serial RS422/485 interface

To ensure fault-free operation of several instruments in a line structure, their internal termination resistors must be activated at the start and end.

- * Isolate the device
- * Open and turn the case


Bus termination resistor active

Push all 4 switches up



no bus termination (by the factory)

Push all 4 switches down



1.7 Configuration

Configuration is either carried out on the device or via the setup program. Here you can find an excerpt from the operating manual.

5.1.9 RS422/485

Interface parameters for RS422/485 (see interface description B70.9061.2)

| | Value/settings | Description |
|--------------------|----------------|----------------------------------|
| Baud rate | 9600 | |
| | 19200 | |
| | 38400 | |
| Data format | 8-1-none | Data bits-stop bits-parity check |
| | 8-1-odd | |
| | 8-1-even | |
| | 8-2-none | |
| Device address | 1 ...255 | |
| Min. response time | 0 ... 500ms | |

■ / **Bold** = factory setting

1.7.1 Baud rate

9 600 baud, 19 200 baud or 38 400 baud

1.7.2 Data format

Number of the data bits - number of the stop bits - parity:

- 8-1-none
- 8-1-even
- 8-1-odd
- 8-2-none

1.7.3 Device address

Ensure that the device address is within the range of 1 to 255.

Address 0 is reserved for broadcast messages, i.e. the instruction is carried out by the TYA 200 but no feedback is given.

If an instruction with the device address 255 is received by the device, it is always processed, even if a different device address is configured.

If the device address is set to 0, the device doesn't display a bus error after 10s without an order.

1 Introduction

1.7.4 Min. response time

Here you can enter a value within the range of 0 to 500 ms.

The time entered here must elapse after a Modbus inquiry was received before the response is transmitted to the master. We recommend to use the parameter for the RS485 interface when the counter part (master) or one of the other slaves connected to the bus require a certain time to toggle between sending and receiving.


The set time of 0 ms means that the TYA 200 responds as soon as possible. This setting should be used for the RS422 interface.

⇒ Section 2.4 “Timing of the communication”

2 Protocol description

2.1 Master-Slave principle

Communication between a PC (master) and a device (slave) using the Modbus takes place according to the master-slave principle, in the form of data request / instruction - response.



The master controls the data exchange, the slaves only have a response function. They are identified by their device address.

2.2 Transmission mode (RTU)

The transmission mode used is the RTU mode (Remote Terminal Unit). Data is transmitted in binary format (hexadecimal) with 8 bits. The LSB (least significant bit) is transmitted first. The ASCII operating mode is not supported.

Data format

The data format describes the structure of a character transmitted. The following data format options are available:

| Data word | Parity bit | Stop bit 1/2 bit | Number of bits |
|-----------|------------|---------------------|-------------------|
| 8 bits | — | 1 | 9 |
| 8 bits | even | 1 | 10 |
| 8 bits | odd | 1 | 10 |
| 8 bits | — | 2 | 10 |

2 Protocol description

2.3 Device address

Ensure that the device address is within the range of 1 to 255.

Address 0 is reserved for broadcast messages, i.e. the instruction is carried out by the TYA 200 but no feedback is given.



A maximum of 31 slaves can be addressed via the RS485 interface.

There are two data exchange possibilities:

Query

Data request/instruction by the master to a slave via the corresponding device address.

The slave addressed responds.

Broadcast


Instruction by the master to all slaves via the device address 0. The connected slaves do not respond. Thus, a specific set point value can be transmitted to all slaves. In such a case, the correct acceptance of the value by the slaves should be checked by subsequently reading out the set point value.

Data request with the device address 0 is meaningless.

2.4 Timing of the communication

Timing scheme

Example for the time sequence of a communication with 1 Modbus master (e.g. a SCADA software on a PC or a PLC) and 2 TYA 200 as Modbus slave 1 and Modbus slave 2:



2 Protocol description

| | |
|---------------------------|--|
| t1 | End marker of the request: As per Modbus specification: min. 3.5 times the transmission time required for 1 character depending on the baud rate. In TYA 200 the time is: <ul style="list-style-type: none">· for 9600 bps: 4.1 ms· for 19200 bps: 2.1 ms· for 38400 bps: 1.1 ms |
| t2 | Internal processing time: This time is required by the power controller to process the received request and prepare the response. The TYA 200 normally requires 1 to 3 ms and max. 6 ms. |
| t3 | End marker of the response: Identical duration as t1. |
| Timing | <p>The master transmits a data request for slave 1. After transmitting the last character, all connected TYA 200 slaves wait for the specified time t1 and subsequently evaluate the instruction. Slave 2 discards the instructions due to an incompatible device address. Slave 1, however, starts to process the request and prepare the response within the set time t2. Then, slave 1 transmits the response and immediately switches back to receiving after transmitting the last character. Slave 2, which can also "hear" the response (RS485) must wait for the set time t3 prior to evaluating the received response, ignoring it due to the incompatible device address and switching back to receiving. The master is only now allowed to transmit a new instruction!</p> <p>No data requests are admissible from the master during t1, t2 and t3, otherwise, the TYA 200 will either ignore the instruction or the data will become invalid on the bus due to data collision.</p> <p>Time t3 is required by all other slaves on the bus to switch back to receiving. (Due to the fact that every TYA 200 connected to the bus (RS485) also receives the response, the master must wait for this time prior to sending a new instruction. Otherwise, the other power controllers are not ready to receive instructions.)</p> |
| Min. response time | <p>In the TYA 200, it is also possible to set a minimum response time from 0 to 500 ms in the configuration. The TYA 200 does not transmit any response before this time has elapsed (measured from the time the last character was received), thus, the time period of t1 + t2 is accordingly extended. - This setting is required for RS485 interfaces to:</p> |

2 Protocol description

- a) allow the master to switch from "Transmit" to "Receive".
- b) allow other devices, which require much more time before the device address of the received protocol is evaluated to process the data. Configure the **Minimum response time** for the RS485 interface such that even the slowest bus participant has evaluated the data request of the master and has noted that this instruction is not relevant before the TYA 200 starts its response. (In an interface linkage with a LOGO-SCREEN 500 cf or LOGOSCREEN es, the minimum response time for the TYA200 should be set to 25 ms.)

2.5 Troubleshooting

In the event of the following errors, the TYA 200 does not respond to the transmitted instruction:

- The baud rate and/or data format of Master and TYA 200 are not compatible
- The device address of the TYA 200 does not comply with that contained in the protocol and is not equal to 255 (for 255, a response is always transmitted).
- The checksum (CRC) is not correct.
- The instruction is incomplete or over-defined
- The number of words to be read is zero.

In these cases, the instruction of the master should be transmitted again after timeout.

If the instruction of the master was received without transmission error but cannot be processed for specific reasons, the TYA 200 will respond as specified in the Modbus protocol: In the response, the received function code is linked to 0x80 OR as error identification and the error code is sent back in the data field.

Error codes

- 01: invalid Modbus function
- 02: invalid data address
- 03: Data value outside the admissible value range
- 04: Error while processing the instruction (e.g. Could not write to flash memory)
- 06: Instruction cannot be carried out at this time therefore try again
- 08: write-protected

If a number of words exceeding the admissible number is to be read or written (see table of the Modbus functions), the TYA 200 also sends back error code 02.

2 Protocol description

When reading out float values, the error number is entered into the value itself, if the value is invalid, i.e. the error code is transmitted as float value instead of the measured value.

| Errors | Error code for float values |
|---------------------|--------------------------------|
| (Un-derrange) | 0xFF800000 (Negative Infinity) |
| (Overrange) | 0x7F800000 (Positive Infinity) |
| other invalid value | 0x7FC00000 (Not a Number) |

2.6 Recognition of bus errors

If an RS4xx-Interface is used in the TYA 200, the failure of Modbus-Master was not recognized including Software-Version 256.01.10. From Software-Version 256.01.11 on, the following feature was added:

If an RS4xx-Interface is used in the TYA 200 and at least 10 s no bus-telegram is received, a bus-error is indicated.

In this error-case the TYA 200 can be switch over to configurable replacement value, because the setpoint over Modbus cannot be sent from the Master. If you set the Modbus-device-adress to 0, this behaviour will be deactivated.

2.7 Checksum (CRC16)

The checksum (CRC16) serves to recognize transmission errors. If an error is identified during evaluation, the device concerned does not respond.

Calculation scheme

| | |
|--|------|
| CRC = 0xFFFF | |
| CRC = CRC XOR ByteOfMessage | |
| For (1 to 8) | |
| CRC = SHR(CRC) | |
| if (flag shifted right = 1) | |
| then | else |
| CRC = CRC XOR 0xA001 | |
| while (not all ByteOfMessage processed); | |

2 Protocol description

Example

Data request: Read two words, starting at address 0x00CE
(CRC16 = 0xA592)

| | | | | | | | |
|----|----|----|----|----|----|----|-------|
| 07 | 03 | 00 | CE | 00 | 02 | A5 | 92 |
| | | | | | | | CRC16 |

Response: (CRC16 = 0xADF5)

| | | | | | | | | |
|----|----|----|--------|--------|-------|----|----|----|
| 07 | 03 | 04 | 00 | 00 | 41 | C8 | AD | F5 |
| | | | Word 1 | Word 2 | CRC16 | | | |

3 Functions

The following functions are available for the device:

| Function number | Function | Max. number |
|-----------------|----------------|------------------------------|
| 0x03 or 0x04 | Read n words | max. 127 words (= 254 bytes) |
| 0x06 | Writing a word | 1 word |
| 0x10 | Write n words | max. 127 words (= 254 bytes) |

If an instruction is received with a different function No. by the device, it will respond with the Modbus error code 1 (ILLEGAL FUNCTION).

3.1 Read n words

This function is used to read n words starting from a specific address.

Data request

| Slave address | Function | Address | Number of words | Checksum |
|---------------|--------------|------------|-----------------|----------|
| | 0x03 or 0x04 | first word | (max. 127) | CRC16 |
| 1 byte | 1 byte | 2 bytes | 2 bytes | 2 bytes |

response

| Slave address | Function | Number of bytes read | Word value(s) | Checksum |
|---------------|--------------|----------------------|---------------|----------|
| | 0x03 or 0x04 | | | CRC16 |
| 1 byte | 1 byte | 1 byte | x byte | 2 bytes |

Example

Read the load current measured value

Modbus address of the load current = 0x003C

Data request:

| | | | | | | |
|----|----|----|----|----|----|------|
| 01 | 03 | 00 | 3C | 00 | 02 | 0407 |
|----|----|----|----|----|----|------|

Response:

| | | | | | | | |
|----|----|----|------------------------|----|----|-----|------|
| 01 | 03 | 04 | 70 | A3 | 41 | 45 | E172 |
| | | | Load current = 12.34 A | | | CRC | |

3 Functions

3.2 Writing a word

For the Write Word function, the data blocks for instruction and response are identical.

instruction

| Slave address | Function 0x06 | Word address | Word value | Checksum CRC16 |
|---------------|---------------|--------------|------------|----------------|
| 1 byte | 1 byte | 2 bytes | 2 bytes | 2 bytes |

response

| Slave address | Function 0x06 | Word address | Word value | Checksum CRC16 |
|---------------|---------------|--------------|------------|----------------|
| 1 byte | 1 byte | 2 bytes | 2 bytes | 2 bytes |

Example

Write external inhibit input = 1

Modbus address = 0x0074

Instruction:

| | | | | | | |
|----|----|----|----|----|----|------|
| 01 | 06 | 00 | 74 | 00 | 01 | 0810 |
|----|----|----|----|----|----|------|

Response (as instruction):

| | | | | | | |
|----|----|----|----|----|----|------|
| 01 | 06 | 00 | 74 | 00 | 01 | 0810 |
|----|----|----|----|----|----|------|

3.3 Write n words

This function is used to write n words starting from a specific address.

instruction

| Slave address | Function 0x10 | Address first word | Number of words (max. 127) | Number of bytes | Word value(s) | Checksum-CRC16 |
|---------------|---------------|--------------------|----------------------------|-----------------|---------------|----------------|
| 1 byte | 1 byte | 2 bytes | 2 bytes | 1 byte | x byte | 2 bytes |

response

| Slave address | Function 0x10 | Address first word | Number of words | Checksum CRC16 |
|---------------|---------------|--------------------|-----------------|----------------|
| 1 byte | 1 byte | 2 bytes | 2 bytes | 2 bytes |

Example

Write set point value = 12.34

Modbus address = 0x0044

Instruction:

| | | | | | | | | | | | |
|----|----|----|----|----|----|----|-------------------------|----|----|----|------|
| 01 | 10 | 00 | 44 | 00 | 02 | 04 | 70 | A3 | 41 | 45 | ED2D |
| | | | | | | | Set point value = 12.34 | | | | CRC |

Response:

| | | | | | | |
|----|----|----|----|----|----|------|
| 01 | 10 | 00 | 44 | 00 | 02 | 01DD |
|----|----|----|----|----|----|------|

3 Functions

4.1 Transmission formats

4.1.1 Integer values

For the transmission of integer values (and also for the addresses) the arrangement "Big-Endian" (Motorola format) is used.

The high byte first, followed by the low byte.



e.g.: Request of the int value of Modbus address 0x000D, if 45 (= 0x002D) is written beneath this address

Request: 0103000D000115C9

Response: 010302002D7859

4.1.2 Float values

For float values, the TYA 200 Modbus operates with the IEEE-754 standard format (32 bits), the only difference being that byte 1 and 2 are changed over with byte 3 and 4.



e.g.: Request of the float value of Modbus address 0x0104, if 550.0 (= 0x44098000 in the IEEE-754 format) is written beneath this address

Request: 0103010400028436

Response: 0103048000440920F5

Please determine the way float values are saved in your application. Once transmission from the paperless recorder is completed, the bytes of the float value possibly need to be changed over accordingly.

4 Data flow

4.1.3 Strings (texts)

Character strings are always terminated with '\0' (ASCII code 0x00) to mark the end. Characters after this mark are without significance.

e.g.:Request of the text of Modbus address 0x000E, to which the "TYA 200" (ASCII code: 0x54, 0x59, 0x41, 0x20, 0x32, 0x30, 0x30, 0x20, 0x00) is written:

Request: 0103000E0005E40A

Response: 01030A**54594120323030200000**5E93

(instead of 0x00 directly in front of CRC, any other value can be written)

The number of characters for the strings specified in the following tables includes the terminating '\0'.

e.g.: "char 10" means that the text can include 9 characters followed by the ending '\0'.

5 Address tables

The addresses of the readable and writable words are specified in the following tables of this chapter. The customer can read and/or write the values with SCADA programs, PLC and similar.

The entries under "Access" have the following meaning:

R Read Only, the value can only be read

R/W Read / Write, the value can be overwritten and read

The number of characters for the strings specified under "Data type" includes the terminating '\0'.

e.g.: "char 10" means that the text can include 9 characters followed by the suffix '\0'.

5.1 Device data

| Address | Access | Data type | Signal designation |
|---------|--------|-----------|---------------------------|
| 0x0000 | R | char 11 | Software version |
| 0x0006 | R | char 13 | VdN number |
| 0x000D | R | word | Internal software version |
| 0x000E | R | char 9 | Device name ("TYA 200 ") |
| 0x0013 | R | char 20 | Serial number |
| 0x001D | R | char 9 | Inspection ID |

5.2 Type codes and options

| Address | Access | Data type | Signal designation |
|---------|--------|-----------|--|
| 0x0023 | R | char 31 | Type key |
| 0x0033 | R | enum | Grundtyp: 0 = 709061 (TYA 201 - Einzelgerät), 1 = 709062 (TYA 202 - Sparschaltung), 2 = 709063 (TYA 203 - Dreiphasen-Leistungssteller) |
| 0x0034 | R | enum | Nominal voltage: 0 = 24 V, 1 = 42 V, 2 = 115 V, ... (230, 265, 400, 440 V), 7 = 500 V |
| 0x0035 | R | enum | Rated current: 0 = 16 A, 1 = 30 A, 2 = 50 A, 3 = 75 A, ... (100, 150, 200 A), 7 = 250 A |
| 0x0036 | R | enum | Current measurement option 0 = no, 1 = yes |
| 0x0037 | R | word | Released options |
| | R | Bit0 | Reserve |
| | R | Bit1 | Reserve |
| | R | Bit2 | Reserve |
| | R | Bit3 | Reserve |
| | R | Bit4 | Reserve |
| | R | Bit5 | Reserve |
| | R | Bit6 | P control option |

5 Address tables

| Address | Access | Data type | Signal designation |
|---------|--------|-----------|---|
| | R | Bit7 | Reserve |
| | R | Bit8 | Device can only be used as slave |
| | R | Bit9 | Reserve |
| | R | Bit10 | Reserve |
| | R | Bit11 | Reserve |
| | R | Bit12 | Reserve |
| | R | Bit13 | Reserve |
| | R | Bit14 | Reserve |
| | R | Bit15 | Reserve |
| 0x0038 | R | enum | Equipped binary output: 0=Relay, 1=Optocoupler |
| 0x0039 | R | enum | Equipped interface: 0=None, 1=RS422/RS485, 2=Profibus |

5.3 Measured values

| Address | Access | Data type | Signal designation |
|---------|--------|-----------|--|
| 0x0100 | R | float | Load voltage |
| 0x0102 | R | float | Load current |
| 0x0104 | R | float | Power |
| 0x0106 | R | float | Load resistance |
| 0x0108 | R | float | Actual value |
| 0x010A | R, W | float | Input set point value (in %) |
| 0x010C | R | float | Effectice setpoint value |
| 0x010E | R | float | Output level |
| 0x0110 | R | float | Alpha (in °) (<i>current value, read only</i>) |
| 0x0112 | R | float | Mains voltage |
| 0x0114 | R | float | Mains frequency |
| 0x0116 | R | float | Device temperature |
| 0x0118 | R | float | Current input |
| 0x011A | R | float | Voltage input |
| 0x011C | R | float | Load voltage slave/slave1 |
| 0x011E | R | float | Load current slave/slave1 |
| 0x0120 | R | float | Power slave/slave1 |
| 0x0122 | R | float | Load resistance slave/slave1 (in Ω) |
| 0x0124 | R | float | Mains voltage slave/slave1 (in V) |
| 0x0126 | R | float | Device temp. slave/slave1 (in °C) |
| 0x0128 | R | float | Load voltage slave2 (in V) |
| 0x012A | R | float | Load current slave2 (in A) |
| 0x012C | R | float | Power slave2 (in W) |
| 0x012E | R | float | Load resistance slave2 (in Ω) |

5 Address tables

| Address | Access | Data type | Signal designation |
|---------|--------|-----------|--|
| 0x0130 | R | float | Mains voltage slave2 (in V) |
| 0x0132 | R | float | Device temp. slave2 (in °C) |
| 0x0134 | R | float | Three-phase power (in W) |
| 0x0136 | R, W | float | Alpha default value (in °) <i>(only writable if "via interface" is configured)</i> |
| 0x0138 | R, W | float | Analog output (in %) <i>(only writable if "via interface" is configured)</i> |
| 0x013A | R | float | Reserve |
| 0x013C | R | float | Reserve |

5.4 Binary signals (bit field)

| Address | Access | Data type | Signal designation |
|---------|--------|---|--|
| 0x013E | R | word | Binary signals (bit field) - 1st section |
| | R | Bit0 | Inhibit input |
| | R | Bit1 | Binary input 1 |
| | R | Bit2 | Binary input 2 |
| | R | Bit3 | External Inhibit input |
| | R | Bit4 | External binary input 1 |
| | R | Bit5 | External binary input 2 |
| | R | Bit6 | Binary output |
| | R | Bit7 | Inhibit |
| | R | Bit8 | Inhibit by the slave |
| | R | Bit9 | Soft start is still running |
| | R | Bit10 | Current limiting is active |
| | R | Bit11 | The external change-over to phase angle is active. |
| | R | Bit12 | The external current limit value is used. |
| | R | Bit13 | The display PCB is connected. |
| | R | Bit14 | The power controller is currently reconfigured. |
| R | Bit15 | The power controller operates in the test and calibration mode. | |

5 Address tables

| Address | Access | Data type | Signal designation |
|---------|--------|-----------|---|
| 0x013F | R | word | Binary signals (bit field) - 2nd section |
| | R | Bit0 | The power controller operates in manual mode. |
| | R | Bit1 | The keyboard is locked. |
| | R | Bit2 | The display is switched off |
| | R | Bit3 | The power controller is connected to the supply voltage. |
| | R | Bit4 | The slave/slave1 power controller is connected to the supply voltage. |
| | R | Bit5 | The rotary field detection was successfully completed. |
| | R | Bit6 | Resistance limitation is active. |
| | R | Bit7 | External switching of setpoint value is active |
| | R | Bit8 | Slave2 is connected to the supply voltage |
| | R | Bit9 | Inhibit of Slave2 |
| | R | Bit10 | Reserve |
| | R | Bit11 | Reserve |
| | R | Bit12 | Reserve |
| | R | Bit13 | Reserve |
| | R | Bit14 | Reserve |
| R | Bit15 | Reserve | |
| 0x0140 | R | word | Malfunction signals (bit field) - 1st section |
| | R | Bit0 | Min-Alarm |
| | R | Bit1 | Max-Alarm |
| | R | Bit2 | Load error |
| | R | Bit3 | Teach-in for load monitoring is still missing. |
| | R | Bit4 | Blown fuse |
| | R | Bit5 | Thyristor breakage |
| | R | Bit6 | Thyristor short circuit |
| | R | Bit7 | Performance limitation due to over-temperature |
| | R | Bit8 | Over-temperature |
| | R | Bit9 | Supply voltage too low |
| | R | Bit10 | Supply voltage too high |
| | R | Bit11 | Temporary supply voltage drop |
| | R | Bit12 | wire breakage on input current |
| | R | Bit13 | wire breakage on input voltage |
| | R | Bit14 | Bus-error |
| R | Bit15 | Reserve | |

5 Address tables

| Address | Access | Data type | Signal designation |
|---------|--------|-----------|--|
| 0x0141 | R | word | Malfunction signals (bit field) - 2nd section |
| | R | Bit0 | Min-Alarm on Slave/Slave1 |
| | R | Bit1 | Max-Alarm on Slave/Slave1 |
| | R | Bit2 | Load error on Slave/Slave1 |
| | R | Bit3 | Blown fuse at the slave or slave1 |
| | R | Bit4 | Thyristor breakage at the slave/slave1 |
| | R | Bit5 | Thyristor short circuit at the slave/slave1 |
| | R | Bit6 | Performance limitation due to over-temperature in slave/slave1 |
| | R | Bit7 | Over-temperature in slave/slave1 |
| | R | Bit8 | Supply voltage slave/slave1 too low |
| | R | Bit9 | Supply voltage slave/slave1 too high |
| | R | Bit10 | Temporary supply voltage drop at slave/slave1 |
| | R | Bit11 | Reserve |
| | R | Bit12 | Reserve |
| | R | Bit13 | Wrong energy counter configuration |
| | R | Bit14 | Reserve |
| R | Bit15 | Reserve | |
| 0x0142 | R | word | Malfunction signals (bit field) - 3rd section |
| | R | Bit0 | Master/slave synchronization has failed |
| | R | Bit1 | Error in the master/slave communication |
| | R | Bit2 | Error on the data cable between master and slave |
| | R | Bit3 | The rotary field detection has failed |
| | R | Bit4 | Rotary field error |
| | R | Bit5 | Wiring error |
| | R | Bit6 | The power controller or one of the slaves is incompatible. |
| | R | Bit7 | Regulation not possible |
| | R | Bit8 | Reserve |
| | R | Bit9 | Reserve |
| | R | Bit10 | Reserve |
| | R | Bit11 | Reserve |
| | R | Bit12 | Reserve |
| | R | Bit13 | Reserve |
| | R | Bit14 | Reserve |
| R | Bit15 | Reserve | |
| 0x0143 | R | word | Malfunction signals (bit field) - 4th section |
| | R | Bit0 | Min-Alarm on Slave2 |
| | R | Bit1 | Max-Alarm on Slave2 |
| | R | Bit2 | Load error on Slave2 |
| | R | Bit3 | Blown fuse at the slave2 |

5 Address tables

| Address | Access | Data type | Signal designation |
|---------|--------|-----------|--|
| | R | Bit4 | Thyristor breakage at the slave2 |
| | R | Bit5 | Thyristor short circuit at the slave2 |
| | R | Bit6 | Performance limitation due to over-temperature in slave2 |
| | R | Bit7 | Over-temperature in slave2 |
| | R | Bit8 | Supply voltage slave2 too low |
| | R | Bit9 | Supply voltage slave2 too high |
| | R | Bit10 | Temporary supply voltage drop at slave2 |
| | R | Bit11 | Reserve |
| | R | Bit12 | Reserve |
| | R | Bit13 | Systembus: invalid configuration |
| | R | Bit14 | Systembus: watchdog timeout |
| | R | Bit15 | Systembus: local error |

5.5 Digital inputs and -output

| Address | Access | Data type | Signal designation |
|---------|--------|-----------|---|
| 0x0144 | R | bool | Inhibit input |
| 0x0145 | R | bool | Digital input 1 |
| 0x0146 | R | bool | Digital input 2 |
| 0x0147 | R, W | bool | External Inhibit-input |
| 0x0148 | R, W | bool | External binary input 1 |
| 0x0149 | R, W | bool | External binary input 2 |
| 0x014A | R, W | bool | Digital output (<i>only writable if "interface-signal" is configured</i>) |

5.6 Device status

| Address | Access | Data type | Signal designation |
|---------|--------|-----------|---|
| 0x014B | R | bool | Inhibit |
| 0x014C | R | bool | Inhibit slave/slave1 |
| 0x014D | R | bool | Soft start phase |
| 0x014E | R | bool | Current limitation active |
| 0x014F | R | bool | Ext. change-over to phase angle active |
| 0x0150 | R | bool | Ext. current limit value active |
| 0x0151 | R | bool | The Display-socket is connected |
| 0x0152 | R | bool | Reconfiguration active |
| 0x0153 | R | bool | Power Controller is in Calibrating mode |
| 0x0154 | R | bool | Manual mode active |
| 0x0155 | R | bool | Keyboard locked |
| 0x0156 | R | bool | Display lighting deactivated |
| 0x0157 | R | bool | Power Controller is connected on power supply |
| 0x0158 | R | bool | Slave/Slave1 is connected on power supply |
| 0x0159 | R | bool | Rotating field detected |
| 0x015A | R | bool | Resistance limitation active |
| 0x015B | R | bool | Ext. change-over of setpoint specification active |
| 0x015C | R | bool | Slave2 is connected on power supply |
| 0x015D | R | bool | Inhibit Slave2 |
| 0x015E | R | bool | Reserve |
| 0x015F | R | bool | Reserve |
| 0x0160 | R | bool | Reserve |
| 0x0161 | R | bool | Reserve |
| 0x0162 | R | bool | Reserve |
| 0x0163 | R | bool | Reserve |

5 Address tables

5.7 Faults

| Address | Access | Data type | Signal designation |
|---------|--------|-----------|---|
| 0x0164 | R | bool | Collective fault |
| 0x0165 | R | bool | Low alarm |
| 0x0166 | R | bool | High alarm |
| 0x0167 | R | bool | Load error |
| 0x0168 | R | bool | Missing teach-in |
| 0x0169 | R | bool | Blown Fuse |
| 0x016A | R | bool | Thyristor breakage |
| 0x016B | R | bool | Thyristor short-circuit |
| 0x016C | R | bool | Limitation active due to overtemperature |
| 0x016D | R | bool | Over-temperature |
| 0x016E | R | bool | Mains voltage is too low |
| 0x016F | R | bool | Mains voltage is too high |
| 0x0170 | R | bool | Short-term mains drop |
| 0x0171 | R | bool | Wire break current input |
| 0x0172 | R | bool | Wire break voltage input |
| 0x0173 | R | bool | System bus error |
| 0x0174 | R | bool | Reserve |
| 0x0175 | R | bool | Low alarm slave/slave1 |
| 0x0176 | R | bool | High alarm slave/slave1 |
| 0x0177 | R | bool | Load error slave/slave1 |
| 0x0178 | R | bool | Fuse breakage slave/slave1 |
| 0x0179 | R | bool | Thyristor breakage slave/slave1 |
| 0x017A | R | bool | Thyristor short-circuit slave/slave1 |
| 0x017B | R | bool | Limitation active due to overtemperature of slave/slave 1 |
| 0x017C | R | bool | Over-temperature slave/slave1 |
| 0x017D | R | bool | Mains voltage of slave/slave1 is too low |
| 0x017E | R | bool | Mains voltage of slave/slave1 is too high |
| 0x017F | R | bool | Short-term mains drop slave/ slave1 |
| 0x0180 | R | bool | Reserve |
| 0x0181 | R | bool | Reserve |
| 0x0182 | R | bool | Wrong energy counter configuration |
| 0x0183 | R | bool | Reserve |
| 0x0184 | R | bool | Reserve |
| 0x0185 | R | bool | Master slave synchronisation failed |
| 0x0186 | R | bool | Error in master slave communication |
| 0x0187 | R | bool | Data cable faulty |
| 0x0188 | R | bool | Rotation field detection failed |

5 Address tables

| Address | Access | Data type | Signal designation |
|---------|--------|-----------|--|
| 0x0189 | R | bool | Rotation field error |
| 0x018A | R | bool | Wiring error |
| 0x018B | R | bool | Der oder einer der Slave-Steller ist inkompatibel |
| 0x018C | R | bool | Sollwert ist nicht erreichbar |
| 0x018D | R | bool | Reserve |
| 0x018E | R | bool | Reserve |
| 0x018F | R | bool | Reserve |
| 0x0190 | R | bool | Reserve |
| 0x0191 | R | bool | Reserve |
| 0x0192 | R | bool | Reserve |
| 0x0193 | R | bool | Reserve |
| 0x0194 | R | bool | Reserve |
| 0x0195 | R | bool | Low alarm slave2 |
| 0x0196 | R | bool | Max alarm slave2 |
| 0x0197 | R | bool | Load error slave2 |
| 0x0198 | R | bool | Fuse breakage slave2 |
| 0x0199 | R | bool | Thyristor breakage slave2 |
| 0x019A | R | bool | Thyristor short-circuit slave2 |
| 0x019B | R | bool | Limitation active due to overtemperature of slave2 |
| 0x019C | R | bool | Over-temperature slave2 |
| 0x019D | R | bool | Mains voltage of slave2 is too low |
| 0x019E | R | bool | Mains voltage of slave2 is too high |
| 0x019F | R | bool | Short-term mains drop slave2 |
| 0x01A0 | R | bool | Reserve |
| 0x01A1 | R | bool | Reserve |
| 0x01A2 | R | bool | Systembus: invalid configuration |
| 0x01A3 | R | bool | Systembus: watchdog timeout |
| 0x01A4 | R | bool | Systembus: local error |

5 Address tables

5.8 Parameters of the operator level (storage in the RAM)

**from Device-
software
Version
256.01.03 on**

The following parameters are taken over into the RAM during writing. For this reason, they can be permanently cyclically rewritten, but get lost, if the device is switched off.

| Address | Access | Data type | Signal designation |
|---------|--------|-----------|---|
| 0x00DC | R, W | word | Switch off display light in (minutes) |
| 0x00DD | R, W | word | Angle alpha start (in °) |
| 0x00DE | R, W | float | Current limit value (in A) |
| 0x00E0 | R, W | float | Resistance limit value (in Ω) |
| 0x00E2 | R, W | float | Maximum actuating variable (in %. not the same as shown on the device) |
| 0x00E4 | R, W | float | Base load (in %. not the same as shown on the device) in V / A / W / kW / Ω / °C / °F) |
| 0x00E6 | R, W | float | Min. limit value alarm (in V / A / W / kW / Ω / °C / °F - depending on the monitored value) |
| 0x00E8 | R, W | float | Max. limit value alarm (in V / A / W / kW / Ω / °C / °F - depending on the monitored value) |
| 0x00EA | R, W | float | Limit value hysteresis (in V / A / W / kW / Ω / °C / °F - depending on the monitored value) |
| 0x00EC | R, W | float | Limit value load monitoring (10...50 %) |
| 0x00EE | R, W | float | Setpoint in the case of a bus-error/wire break (in %) |
| 0x00EF | R | word | Reserve |
| 0x00F0 | R | word | Reserve |
| 0x00F1 | R | word | Reserve |
| 0x00F2 | R | word | Reserve |
| 0x00F3 | R | word | Reserve |
| 0x00F4 | R | word | Reserve |
| 0x00F5 | R | word | Reserve |

6 Default values via interface

6.1 Default set point values via interface

If the set point value for a controller is to be defined via an interface, it must be configured accordingly: Use the keyboard on the device or the setup program to set "*via interface*" under: *Config level* → *Set point value config.* → *Default set point value.* If this is not set, writing a value to the Modbus address 0x010A is not taken into account.

The set point value must be written as a percent value on the Modbus address 0x010A. The range of the transmitted set point value is not checked. Thus, the power controller never replies with Modbus error code 03 (data value outside the admissible value range). Set point values that are too great or too small are corrected later to 100% or 0 %.

If applicable, other variables, such as basic load, max. setting value and soft start, are also taken into account for the internal set point value calculation. This results in the effective set point value being saved in the cascade control which can be read out from the Modbus address 0x010C as required.

The transmitted set point value is used for SCR control until a new set point value is transmitted via the interface.

Set point values transmitted to the power controller are only saved in the RAM, i.e. they are lost in the event of a power failure.

After power ON the set point value 0 % is started with until the first received set point over interface or a detected bus-error.

6.2 α -default value via interface

For logic mode (*Config level* → *Power controller* → *SCR control* to "*Logics (switch)*"), a phase angle α can be additionally configured for all sine waves to limit the maximum performance. This phase angle can also be set cyclically via the interface. For this purpose, set the default α value to "*via interface*" under: *Config level* → *Set point value config.* → .

α must be written to Modbus address 0x0136 as angle value (0...180°). The transmitted phase angle is not controlled for its range. Thus, the power controller never replies with Modbus error code 03 (data value outside the admissible value range). Angle values that are too great or too small are corrected later to 180° or 0°.

The transmitted angle value is used for SCR control until a new angle value is transmitted via the interface.

After Power-ON 180° are used for α until the first value is received.

Angle values transmitted to the power controller are only saved in the RAM, i.e. they are lost in the event of power failure. After power ON, the default α value of 180° is used for SCR control until a new angle value is transmitted via the interface.

6 Default values via interface

6.3 Controlling the analog output via Interface

From Software-Version 256.02.01 on, the analog output can be set via the interface. Before this could happen, the parameter *Config level* → *Analog output* → *Output value* has to be set to: "From Interface".

The parameter *Config level* → *Analog output* → *Signal range start value* should be set to "0%" and the *Signal range end value* to "100%".

If for instance a float value of 50.0 is written on the modbus adress 0x0138 the analog output set to 4 to 20 mA, will put out 12mA. This value remains unchanged until an other value is received.

After Power-off the value of 0%(4mA) will be put out until a new value is received over interface.

In the case of a bus-error the value of 0%(4mA) will be put out.

The output values are saved in the RAM memory and get lost in the case of an Power-off.

6.4 Controlling the binary output via Interface

From Software-Version 256.02.01 on, the binary outputs (relay and optocoupler) can be set via the interface.

The parameter *Config level* → *Binary output* → *Output mode binary out* should be set to "Interf.sign.outp".

The desired state of the output level is written with a "0" for low and "1" for high on the on the modbus adress 0x014A. This value remains unchanged until an other value is received.

After Power-off or a bus -error the output is switched off that means value of "0" will be put out.

The output values are saved in the RAM memory and get lost in the case of an Power-off.

After Power-on the binary output will remain switched off "0" until he is activated again with "1" via interface.

6.5 External Inhibit and external binary input1 and 2

Over the modbus adresses 0x0147 to 0x0149 external inhibit, external binary input1 and external binary input2 can be set.

These binary inputs have got the same behaviour as wired on the device with potential free contacts. They are only switched via interface and can be used in the same way for functions such as current limiting, ext. swiching to phase angle control or keyboard lock.

After Power-on the binary inputs will remain switched off "0" until ther are activated again with "1" via interface.

In case of a bus -error the inputs are switched off "0".



JUMO GmbH & Co. KG

Street address:
Moritz-Juchheim-Straße 1
36039 Fulda, Germany
Delivery address:
Mackenrodtstraße 14
36039 Fulda, Germany
Postal address:
36035 Fulda, Germany
Phone: +49 661 6003-0
Fax: +49 661 6003-607
Email: mail@jumo.net
Internet: www.jumo.net

JUMO Instrument Co. Ltd.

JUMO House
Temple Bank, Riverway
Harlow, Essex, CM20 2DY, UK
Phone: +44 1279 63 55 33
Fax: +44 1279 62 50 29
Email: sales@jumo.co.uk
Internet: www.jumo.co.uk

JUMO Process Control, Inc.

6733 Myers Road
East Syracuse, NY 13057, USA
Phone: +1 315 437 5866
Fax: +1 315 437 5860
Email: info.us@jumo.net
Internet: www.jumousa.com

