

**logoline** 500  
junior

Pen recorder with text printing

**B 95.3535**  
**Operating Manual**

08.04/00351782



# Contents

---

## **1 About this Manual**

1.1	Preface .....	5
1.2	Arrangement of the documentation .....	6
1.3	Typographical conventions .....	7
1.3.1	Warnings .....	7
1.3.2	Notes .....	7
1.3.3	Presentation .....	8

## **2 Identifying the instrument version**

2.1	Instrument description .....	9
2.2	Type designation .....	10

## **3 Installation**

3.1	Location and climatic conditions .....	12
3.2	Fitting in position .....	13

## **4 Electrical connection**

4.1	Notes on installation .....	14
4.2	Connection diagram .....	15

## **5 Starting up**

5.1	Display and controls .....	16
5.2	Opening and closing the door .....	16
5.3	Marking the channel label .....	16
5.4	Fitting the fibre pens .....	17

## **6 Preparation**

6.1	Operating modes and status .....	18
6.2	Operating principle .....	19

## **7 Text printing**

7.1	Printing priorities .....	24
7.2	Time .....	25
7.3	Change of chart speed .....	26
7.4	Recording start and end .....	27
7.5	Print test .....	28
7.6	Service print .....	29

## **8 Programming**

8.1	Basic status .....	30
8.2	Operating level .....	31

---

# Contents

---

8.3	Chart speed .....	32
8.4	Print test .....	33
8.5	Service print .....	34
8.6	Level inhibit and code request .....	35
8.7	Parameter level .....	36
8.8	Language .....	37
8.9	Date and time .....	38
8.10	Summer time .....	39
8.11	Display of time .....	41
8.12	Configuration level .....	42
8.13	Signal inputs .....	43

## **9 Consumables**

9.1	Summary of consumables .....	45
9.2	Removing and replacing the chart cassette .....	46
9.2.1	Changing the roll chart .....	47
9.2.2	Changing the fanfold chart .....	48

## **10 Accessories**

10.1	Converting the chart cassette .....	49
------	-------------------------------------	----

## **11 Fault finding**

11.1	What to do if... ..	50
------	---------------------	----

## **12 Appendix**

12.1	Error messages .....	51
12.2	Hardware fault .....	52
12.3	Status messages .....	53
12.4	Overview of the parameters .....	54

## **Index**

---

# 1 About this Manual

---

## 1.1 Preface



Please read this Operating Manual before commissioning the instrument. Keep the manual in a place which is accessible to all users at all times.

Please assist us to improve this manual, where necessary.

Your suggestions will be welcome.

Phone

Germany (0661) 6003-727

abroad +49 661 6003-0

Fax

Germany (0661) 6003-508

abroad +49 661 6003-607



All necessary settings and, where appropriate, alterations inside the instrument are described in this manual. If any difficulties should still arise during start-up, you are asked not to carry out any prohibited manipulations. You could endanger your rights under the instrument warranty!

Please contact the nearest JUMO subsidiary or the head office.



When returning chassis, modules or components, the regulations of EN 61340-5-1 and EN 61340-5-2 "Protection of electronic devices from electrostatic phenomena" must be observed. Use only the appropriate **ESD** packaging material for transport.

Please note that we can not be held liable for any damage caused by ESD (electrostatic discharge).

# 1 About this Manual

---

## 1.2 Arrangement of the documentation

This Operating Manual is supplied with the instrument. It is addressed to the OEM (original equipment manufacturer) and users with appropriate technical know-how.

In addition to installation and electrical connection, it contains all the information on instrument start-up, operation and parameter setting.

# 1 About this Manual

---

## 1.3 Typographical conventions

### 1.3.1 Warnings

The signs for **Danger** and **Warning** are used in this manual under the following conditions:



**Danger** This symbol is used when there may be **danger to personnel** if the instruction is disregarded or not followed accurately.



**Warning** This symbol is used when there may be **damage to equipment or data** if the instruction is disregarded or not followed accurately.



**Warning** This symbol is used where precautions have to be observed during the handling of components which may be damaged by electrostatic discharges.

### 1.3.2 Notes



**Note** This symbol is used if your **special attention** is drawn to a remark.



**Reference** This symbol refers to additional information in other handbooks or sections.

abc<sup>1</sup>

**Footnote** Footnotes are notes which refer to certain points in the text. Footnotes consist of 2 parts:

Markings in the text and the footnote text.



The markings in the text are arranged as continuous superscript numbers.

# 1 About this Manual

---

- \* **Action** This sign indicates that an action to be performed is described.

The individual steps are indicated by this asterisk, e.g.:

- \* press key 
- \* enter with 

## 1.3.3 Presentation

 + 

**Keys** Keys are shown as boxes. Both symbols and texts are possible. Where a key has multiple functions, the text shown is the one corresponding to the actual function discussed.

## 2 Identifying the instrument version

---

### 2.1 Instrument description

The pen recorder provides up to three channels for recording measurements, which are isolated from each other by optocouplers. Channel 1 can be used to write text in addition to the signal trace. All channels are zeroed using Hall sensors. The measurements can be indicated by pointers against scales.

A 4-digit 7-segment display is available for programming. Operation is by six keys on the instrument front. The configuration data are stored permanently in EEPROM.

Input signals include current and voltage signals (standard signals). The watchdog monitors the recorder function and triggers a restart in the event of a fault. On a power failure, the real-time clock is supplied by a lithium battery.

An overview of all the parameters of the pen recorder is given in the Appendix (⇒ Section 12.4).


## 2 Identifying the instrument version

### 2.2 Type designation

The label is affixed to the housing. The instrument version can be identified from the type designation.

The extra Codes are listed in sequence and separated by a comma.

The voltage of the supply must correspond to the voltage indicated on the label.



LL. v-44uj/... Pen recorder  
with scales

- 1 1 channel  
with text writing
- 2 2 channels  
(channel 1 with text writing)
- 3 3 channels  
(channel 1 with text writing)
- v amplifier
- 44 bezel 144mm x 144mm
- u convertible chart cassette

### Extra Codes

- sk special scales,  
e. g. in m<sup>3</sup>/h, bar etc.  
(to calibration curve if  
non-linear)
- fp cassette for fanfold chart  
16m long
- r32 roll chart  
32m long
- ab housing for wall mounting.  
The panel-mounting instrument  
is fitted in a carrier and can be  
swung out through 90°.
- tm housing with carrying handle,  
rubber feet and terminal cover,  
also 3m mains supply cable  
with grounding plug
- TG-35 portable recording station

## 2 Identifying the instrument version

---

ts	door with lock (IP54)
IP65	IP65 seal, wide mounting brackets
061	UL approval

### Ordering example

(1) (2) (3) (4) (5) (6)

LL 3 v-44uj/ts, fp, tm

- (1), (3) pen recorder
- (2) 3 channels
- (3) bezel 144mm x 144mm
- (4) door with lock (IP54)
- (5) fanfold chart cassette
- (6) housing with carrying handle

### Standard accessories

- 1 Operating Manual B 95.3535
- 2 mounting brackets
- 1 fibre pen, disposable, for each channel
- 2 chart rolls 16m long  
or
- 1 chart roll 32m long  
(with Code r32)  
or
- 1 fanfold chart pack 16m long  
(with Code fp)

## 3 Installation

---

### 3.1 Location and climatic conditions

The instrument location should as far as possible be free from shock and vibration. Stray electromagnetic fields, e.g. from motors, transformers etc., should be avoided.

The ambient temperature at the location may be between -10 and +50°C at a relative humidity not exceeding 75%, without condensation.

Corrosive air and fumes may interfere with the function and life of the recorder.


 Section 4.1

# 3 Installation


## 3.2 Fitting in position

Side view


(when using the IP65 seal, dimension 26 increases to 27)




Front view



Panel cut-out



- \* Insert the pen recorder from the front into the panel cut-out.
- \* From the back of the panel, hook the mounting brackets (1) into the cut-outs in the sides of the housing. The flat bracket faces must lie against the housing.
- \* Place the brackets against the rear of the panel and tighten them evenly.



## 4 Electrical connection

---

### 4.1 Notes on installation


- ❑ The choice of cable, the installation and the electrical connection of the instrument must conform to the requirements of VDE 0100 “Regulation on the Installation of Power Circuits with nominal voltages below 1000V” or the appropriate local regulations.
- ❑ Earth the instrument at the PE terminal to the earth conductor. This line should have at least the same cross-section as the supply lines. Earth lines should be run in a star layout to a common earth point which is connected to the earth conductor of the supply. Do not loop the earth connections, i.e. do not run them from one instrument to another.
- ❑ Work inside the instrument must only be carried out to the extent described and, like the electrical connection, only by properly qualified personnel.
- ❑ Do not connect any additional loads to the supply terminals of the instrument.
- ❑ If contact with live parts is possible when working on the instrument, it has to be isolated on both poles from the supply.
- ❑ The instrument is not suitable for installation in hazardous areas.
- ❑ Electromagnetic compatibility (EMC) conforms to the standards and regulations listed under Technical Data.
- ❑ Inductive loads in the neighbourhood of the instrument, such as contactors or solenoid valves, should be fitted with RC modules for interference suppression.
- ❑ Run input, output and supply lines separately and not parallel to each other.
- ❑ The supply of the instrument must additionally be fused. Depending on the supply voltage, the following fuse values apply:
  - 20 — 53V AC/DC, 48 — 63Hz  
fuse 2A slow
  - 93 — 263V AC, 48 — 63Hz  
fuse 1A slow
- ❑ All input and output cables without connection to the supply network must be arranged as screened and twisted cables. The screen must be grounded to the earth potential on the instrument side.

# 4 Electrical connection

## 4.2 Connection diagram



The electrical connection must only be carried out by qualified personnel.



Rear view with screw-clamp connectors


Terminals				
Supply as on label	N neutral L1 line PE protective earth		N (L-) L1 (L+) PE	(L-) (L+) N L1 PE PE PE 1 2 3 4 5 6
<b>Analogue inputs</b>	<b>Input 1</b>	<b>Input 2</b>	<b>Input 3</b>	
Voltage input up to 170mV	Field	Field	Field	1 2 3 4 5 - U <sub>x</sub> ≤ 170mV
Voltage input above 170mV	1.	2.	3.	1 2 3 4 5 + U <sub>x</sub> > 170mV -
Current input				1 2 3 4 5 + I <sub>x</sub> -

Inputs 8 and 9 are not available for LOGOLINE 500 junior.

## 5 Starting up


### 5.1 Display and controls

- (1) 4-digit 7-segment LED display
- (2) fibre pen, channel 3, green
- (3) fibre pen, channel 2, red
- (4) fibre pen, channel 1, blue
- (5) chart
- (6) keys for operation and programming
- (7) door
- (8) housing to DIN 43700 for flush-panel mounting, galvanised steel
- (9) channel marker label




### 5.2 Opening and closing the door

Turn the knob in order to open or close the door.



### 5.3 Marking the channel label

Please mark the channel label (1) with the measurement channel designation and the corresponding range.




## 5 Starting up

---

### 5.4 Fitting the fibre pens

- \* Open the recorder door
- \* Stop recording  
(press **S** key)
- \* Swing scale upwards
- \* Slide the fibre pen into the holder  
up to the stop
- \* Swing scale down again



## 6 Preparation

---

### 6.1 Operating modes and status

Operating mode/status	Notes
<b>Basic status</b>	<p>Basic status of the pen recorder with signal acquisition and processing. The display shows</p> <ul style="list-style-type: none"><li>- time (can be switched off via the parameter <i>parameter level</i> → <i>display time</i>)</li><li>- and system error messages, where appropriate.</li></ul> <p>In the stop status the display flashes “STOP”. If there is a system error message, it is shown flashing at regular intervals instead of the time.</p>
<b>Stop</b>	
Stop by key	Recording is stopped and continued using key <b>S</b> . In the stop status, the display flashes “STOP”.
<b>Chart speeds</b>	
Normal chart speed	The chart is advanced with the speed programmed under chart speed. ⇒ Section 8.3

# 6 Preparation

## 6.2 Operating principle

The individual parameters and functions are divided into four levels for clearer operation of the recorder.

### Basic status

Basic status of the pen recorder with signal acquisition, recording and processing.

The display shows:

- the time (can be switched off via the parameter *parameter level* → *display time*)
- and system error messages, where appropriate.


If there is a system error message, it is shown flashing at regular intervals instead of the current display.

### Operating level

At this level, signal acquisition and processing remain activated.

The following parameters can be activated at the operating level:

- chart speed
- print test
- service print



## 6 Preparation

---

### Parameter level

The parameter level and the subsequent configuration level are protected by a code-number to prevent unauthorised access.

The codenumber is: 9200.



Section 8.6

If a wrong codenumber is input, the individual parameters can be viewed, but can not be programmed.

Following input of the correct codenumber, signal acquisition and recording are interrupted at this level.

The following parameters are altered at the parameter level:

- language
- date and time
- summer time
- display time

### Configuration level

At the configuration level, the following parameters are altered:


- signal inputs

An overview of all parameters of the recorder is given in the Appendix.



Section 12.4

## 6 Preparation



The levels, parameters and sub-parameters are arranged in a tree structure. Starting from the basic status, the program branches out into the individual levels, and from there into the corresponding parameters and, if there are any, into the sub-parameters.

To alter a specific parameter, run through the relevant levels up to this parameter.

The editing process is started with **[ENTER]**.

If a parameter has several sub-parameters, these are reached with **[ENTER]**.

### Coding the parameters

The parameters and sub-parameters are indicated in code form on the 7-segment display. Coding involves up to four digits. The first digit is a letter, the others are numbers.

Digit	Notes
1	A = operating level b = parameter level C = configuration level
2	indicates the parameter
3	indicates the sub-parameter
4	channel number

## 6 Preparation

### Entering parameters

If there are no further sub-parameters, **ENTER** transfers all the data of the parameter to the memory.

### Aborting programming

Programming can be aborted within a parameter by pressing the key **↓P/E**.



If the last sub-parameter has not yet been entered, the parameter data which have already been edited are rejected. The old contents of the sub-parameters are retained.

### Error messages during programming

If there are error messages during programming due to incorrect inputs, these have to be acknowledged with **ENTER** before programming can be repeated.

### Key functions



<b>↓P/E</b>	<ul style="list-style-type: none"> <li>- Chart fast forward when recording is stopped</li> <li>- Abort parameter input (<b>Exit</b>)</li> <li>- Level change backwards</li> </ul>
<b>S</b>	<ul style="list-style-type: none"> <li>- <b>Start/Stop</b> recording</li> <li>- Decimal place selection during value input</li> </ul>
<b>F</b>	<ul style="list-style-type: none"> <li>- not used</li> </ul>
<b>◀</b>	<ul style="list-style-type: none"> <li>- Move cursor to the left (select digit)</li> </ul>
<b>▲</b>	<ul style="list-style-type: none"> <li>- Parameter selection</li> <li>- Channel selection</li> <li>- Value selection from value table</li> <li>- Increment current digit</li> </ul>
<b>ENTER</b>	<ul style="list-style-type: none"> <li>- Initiate parameter input</li> <li>- Enter input</li> <li>- Acknowledge error message</li> </ul>
<b>▲ + ENTER</b>	<ul style="list-style-type: none"> <li>- Level change forwards</li> </ul>


## 6 Preparation

### Selection

Selection consists of a list of several options.





Two keys are used to select an option:


- \* select option with the  key
- \* enter selection with 



### Value input

Three keys are used to input values:

- \* select the digit to be altered with the  key
- \* increment the selected digit with the  key
- \* shift the decimal point with the  key
- \* enter value input with 



An incorrect input produces an error message on the display.

⇒ Section 12.1

The error message must be acknowledged with .

The value can then be entered again.

# 7 Text printing

---



The pen recorder can print text in addition to the trace using the fibre pen of channel 1. Text printing is used for comments on the trace and for event recording. The characters are written in dots on a 7 x 9 matrix.

## 7.1 Printing priorities

There are various types of text with different priorities. These priorities determine abort criteria where printing of several texts is requested simultaneously.

The printing of text with low priority is aborted when text with high priority is to be printed.

List of priorities:

Priority	Text
higher	- Stop by key <b>S</b> , no chart, configuration by keys, end-of-recording text
	- Service print
	- Print test
	- start-of-recording text
	- chart speed change
	- time
lower	

All printing requests which are still present are rejected and fresh ones ignored in the following events:

- Pen recorder moves to stop status
- Print test is started
- Service print is started
- Pen recorder is switched off

## 7 Text printing

---


### 7.2 Time

Printing is performed cyclically at intervals of approx. 4 cm. Since time is not printed at “irregular” times, the interval mentioned above is only an approximation.

With every fourth time printing, the current chart speed, the instrument name or the date are printed alternately following the time.

At a change of date, the date is generally included in the printing at 00:00 hours.

In order to obtain an exact time reference on the chart, the time is preceded by a time reference mark (“\_”).



If a “?” is printed after the time, the time has to be checked and, if necessary, freshly programmed. (⇒ Section 8.9).



Time printing only occurs when the chart speed is in the range of 5 — 360mm/h.

## 7 Text printing

---


### 7.3 Change of chart speed

Every change of chart speed is reported by printing a line, the current time and the new chart speed.



Setting the printing priorities (⇒ Section 7.1) affects not only the printing of the chart speed change marking, but also the change itself.

There is no chart speed change as long as a text with a higher priority is being printed.



The line for marking the chart speed change is always printed, the text (time and new speed) only when the chart speed is in the range of 5 — 360mm/h.

# 7 Text printing


---


## 7.4 Recording start and end

Recording start and end are reported by a start and end text.



Printing the end text is omitted when the chart sensor recognises "end of chart".



Printing the end text is aborted by pressing the /E key.

## 7 Text printing

### 7.5 Print test

The print test can only be initiated on the recorder using the keys (operating level). It is used to check the function of the writing system and the fibre pens.




Section 8.4



Started text printing is aborted and not continued after the print test.



All text printing requests arriving during the print test are rejected.




## 7 Text printing

---

### 7.6 Service print

The service print can be initiated on the recorder using the keys (operating level).

It prints the software version, the number of supply interruptions and the total operating time of the recorder in hours.



Section 8.5



Started text printing is aborted and not continued after the service print.




All text printing requests arriving during the service print are rejected.

# 8 Programming

## 8.1 Basic status

The recorder is in the basic status after the supply has been applied, and it has been initialised. The measurement signals are acquired, processed and recorded.



In the basic status the following are indicated:


- the clock time and
- status/error messages, as appropriate.

Status and error messages are flashing regularly instead of the current display.

Using the **S** key, the recording is stopped and re-started. In the stop status, the display flashes "STOP".

Pressing the **↓%/E** key in the stop status activates the chart fast forward.

It is possible to change into the operating level by simultaneously pressing the **▲ + ENTER** keys.



# 8 Programming

## 8.2 Operating level

The operating level serves for performing simple operating actions.

It is reached from the basic status by pressing the  $\blacktriangle + \text{ENTER}$  keys simultaneously, from the parameter level by pressing the  $\downarrow \text{E}$  key.

The operating level is identified in the display by the letter "R".


The operating level includes the following parameters:

- chart speed
- print test
- service print



While the operating level is activated, signal acquisition, processing and recording are continuing.

A summary of all parameters of the recorder is given in the Appendix ( $\Rightarrow$  Section 12.4).



Display	Edit	Selection/input	with keys	Enter	Continue with
<b>R</b>					$\blacktriangle$ forwards

# 8 Programming


## 8.3 Chart speed

The chart speed for recording the measurement is set here.

The chart speed is selected from a table.

The chart speeds are:

0, 5, 10, 20, 60, 120, 240, 300, 360, 600, 720, 1800, 3600 und 7200mm/h.



Display	Edit	Selection/input	with keys	Enter	Continue with
A1	ENTER	240 Select chart speed: 0, 5, 10, 20, 60, 120, 240, 300, 360, 600, 720, 1800, 3600, 7200mm/h	▲	ENTER	▲ forwards

# 8 Programming



## 8.4 Print test

Print test is used to check the function of the writing system and the fibre pens.

☞ PRINTTEST = **On** continues until it is terminated by PRINTTEST = **OFF**.

☞ Started text printing is aborted and not continued after the print test.

☞ All text printing requests arriving during the print test are ignored or rejected.





Display	Edit	Selection/input	with keys	Enter	Continue with
A2	<input type="text" value="ENTER"/>	OFF, On Select status of print test	<input type="checkbox"/> ▲	<input type="text" value="ENTER"/>	<input type="checkbox"/> ▲ forwards



# 8 Programming

## 8.5 Service print

The service print informs about the software version, the number of supply interruptions and the total operating time of the recorder.

 Started text printing is aborted and not continued after the service print.

 All text printing requests arriving during the service print are ignored or rejected.



Display	Edit	Selection/input	with keys	Enter	Continue with
A3	ENTER	no, YES Service print no, yes	▲	ENTER	▲ forwards

## 8 Programming

---

### 8.6 Level inhibit and code request


The parameter level is protected by a 4-digit codenumber.

The codenumber is: 9200.

If the codenumber is entered, the following are interrupted:

- signal acquisition and
- recording.

The parameters can now be programmed.



If an incorrect codenumber has been entered, the recorder remains in normal operation. Signal acquisition, processing and recording remain activated.

The parameters can be viewed, but not programmed.

# 8 Programming

## 8.7 Parameter level

At the parameter level, it is possible to configure general parameters.

From the operating level, the parameter level is reached by simultaneously pressing keys  $\blacktriangle + \text{ENTER}$ , from the configuration level by pressing the  $\downarrow \text{p/E}$  key at the parameter level.

The parameter level comprises the following parameters:

- language
- date and time
- summer time
- display time




If an incorrect codenumber is entered, the recorder remains in normal operation. Signal acquisition, processing and recording are activated.

The parameters can be viewed, but not programmed.



Following entry of a correct codenumber, the normal operation is interrupted.

There is no signal acquisition, processing or recording.



Display	Edit	Selection/input	with keys	Enter	Continue with
CODE	$\text{ENTER}$	0000 Input codenumber	$\blacktriangle$ , $\blacktriangleleft$	$\text{ENTER}$	$\Rightarrow$ 2
$\Rightarrow$ 2 b					$\blacktriangle$ forwards


# 8 Programming

## 8.8 Language

The following languages can be selected:

- English
- German
- French

The language setting affects the texts which are printed.



Display	Edit	Selection/input	with keys	Enter	Continue with
b 1	ENTER	Select language: GEr (GERMAN) EnGL (ENGLISH) FrEn (FRENCH)	▲	ENTER	▲ forwards

# 8 Programming

## 8.9 Date and time


Programming the system clock of the recorder. The following are programmed: day, month, year, weekday, hour and minute.

The current clock time is printed at certain events and is shown on a 7-segment display in the basic status.



Date and time are checked for plausibility after input. An error message is output, when appropriate.

The error message is acknowledged with **ENTER** and the data can then be re-entered.



Display	Edit	Selection/input	with keys	Enter	Continue with
b 2	<b>ENTER</b>				⇒ 2
⇒ 2 b 2 1	<b>ENTER</b>	09.02. Input day and month: DD.MM.	▲, ◀	<b>ENTER</b>	⇒ 3
⇒ 3 b 2 2	<b>ENTER</b>	98 Input year: YY	▲, ◀	<b>ENTER</b> Check date	⇒ 4
⇒ 4 b 2 3	<b>ENTER</b>	1 Select weekday: 1 Monday 2 Tuesday 3 Wednesday 4 Thursday 5 Friday 6 Saturday 7 Sunday	▲	<b>ENTER</b>	⇒ 5
⇒ 5 b 2 4	<b>ENTER</b>	00.00 Input clock time: hh.mm	▲, ◀	<b>ENTER</b> Check time	▲ forwards

# 8 Programming

## 8.10 Summer time

Input of a time period during which the system clock of the recorder is changed to summer time.

Example:

Summer time start: 29.03.98, 2:00 hrs

Summer time end: 25.10.98, 3:00 hrs


On 29.03.98 at 2:00 hrs the system clock is put forward automatically by an hour to 3:00 hrs.

On 25.10.98 at 3:00 the clock is put back automatically by an hour to 2:00 hrs.



The time interval for the summer time always applies only to the period indicated.

It has to be re-programmed for each year.



## 8 Programming

Display	Edit	Selection/input	with keys	Enter	Continue with
b3	<input type="text" value="ENTER"/>				⇒ 2
⇒ 2 b31	<input type="text" value="ENTER"/>	Off, On Input status	<input type="text" value="▲"/>	<input type="text" value="ENTER"/>	On ⇒ 3 Off: <input type="text" value="▲"/> forwards
⇒ 3 b32 (On)	<input type="text" value="ENTER"/>	<u>29.03.</u> Input day and month of start date: DD.MM.	<input type="text" value="▲"/> , <input type="text" value="◀"/>	<input type="text" value="ENTER"/>	⇒ 4
⇒ 4 b33	<input type="text" value="ENTER"/>	<u>98</u> Input start year: YY	<input type="text" value="▲"/> , <input type="text" value="◀"/>	<input type="text" value="ENTER"/> Check date	⇒ 5
⇒ 5 b34	<input type="text" value="ENTER"/>	<u>02.00</u> Input time for start: hh.mm	<input type="text" value="▲"/> , <input type="text" value="◀"/>	<input type="text" value="ENTER"/> Check time	⇒ 6
⇒ 6 b35	<input type="text" value="ENTER"/>	<u>25.10.</u> Input date and month of end date: DD.MM.	<input type="text" value="▲"/> , <input type="text" value="◀"/>	<input type="text" value="ENTER"/>	⇒ 7
⇒ 7 b36	<input type="text" value="ENTER"/>	<u>98</u> Input year of end date: YY	<input type="text" value="▲"/> , <input type="text" value="◀"/>	<input type="text" value="ENTER"/> Check date	⇒ 8
⇒ 8 b37	<input type="text" value="ENTER"/>	<u>03.00</u> Input time for end: hh.mm	<input type="text" value="▲"/> , <input type="text" value="◀"/>	<input type="text" value="ENTER"/> Check time	<input type="text" value="▲"/> forwards

# 8 Programming


## 8.11 Display of time

The parameter “Display time” has been added to the parameter level with effect from the instrument version 116.01.02.2.

The time is indicated on the display when the recorder is in the basic status. The time display can be suppressed (status = OFF) by using this parameter.



The instrument version can be determined by the parameter *Operating level* → *Service print*.





Display	Edit	Selection/input	with keys	Enter	Continue with
b5	ENTER	Off, ON Select status	▲	ENTER	▲ forwards

# 8 Programming

## 8.12 Configuration level

The signal inputs are configured at the configuration level.

It can be reached from the parameter level by simultaneously pressing the  +  keys.




If an incorrect codenumber has been entered, the recorder remains in normal operation. Signal acquisition, processing and recording remain activated.



The parameters can be viewed, but not programmed.



If a correct codenumber is entered, the normal operation is interrupted.

There is no signal acquisition, processing or recording.




Display	Edit	Selection/input	with keys	Enter	Continue with
					 forwards

# 8 Programming

## 8.13 Signal inputs

The input signal is selected, and the ranges as well as the filter constants for each signal input are determined here.



Display	Edit	Selection/input	with keys	Enter	Continue with
[ 1	[ENTER]	<u>C101</u> Select input channel: C101 channel 1 C102 channel 2 C103 channel 3	▲	[ENTER]	⇒ 2n with n = 1 — 3
⇒ 2n [ 111 [ 112 [ 113	[ENTER]	<u>CA00</u> Select input signal: CA00 voltage Cb00 current	▲	[ENTER]	Voltage ⇒ 31n Current ⇒ 41n
Voltage: ⇒ 31n [A 11 [A 12 [A 13	[ENTER]	<u>1</u> Select unit: 0 (mV) 1 (V)	▲	[ENTER]	⇒ 32n
⇒ 32n [A2 1 [A22 [A23	[ENTER]	<u>0.000</u> Enter range start	▲, ◀, [S]	[ENTER]  check range start (-10.0V ≤ range start < 10.0V or 0.0V ≤ range start < 22.0V)	⇒ 33n

## 8 Programming

Display	Edit	Selection/input	with keys	Enter	Continue with
⇒ 33n [A3 1 [A3 2 [A3 3	[ENTER]	<u>1.000</u> Input range end	▲, ◀, [S]	[ENTER]  Check (-10.0V < range end ≤ 10.0V or 0.0V < range end ≤ 22.0V) span ≥ 5mV	⇒ 5n (FILTER)
Current: ⇒ 41n [b 11 [b 12 [b 13	[ENTER]	<u>0.000</u> Input range start	▲, ◀, [S]	[ENTER]  Check range start (-20.5mA ≤ range start < 20.5mA or 0.0mA ≤ range start < 45.0mA or -4.0mA ≤ range start < 21.0mA)	⇒ 42n
⇒ 42n [b 21 [b 22 [b 23	[ENTER]	<u>020.0</u> Input range end	▲, ◀, [S]	[ENTER]  Check range end (-20.5mA < range end ≤ 20.5mA or 0.0mA < range end ≤ 45.0mA or -4.0mA < range end ≤ 21.0mA) span ≥ 0.5mA	⇒ 5n (FILTER)
⇒ 5n [ 12 1 [ 12 2 [ 12 3	[ENTER]	<u>0.800</u> Input filter constant (value range: 0.0 — 10.0sec)	▲, ◀, [S]	[ENTER]  Check value range 0.0 — 10.0sec	▲ forwards

## 9 Consumables

---

### 9.1 Summary of consumables

#### Fibre pens, disposable

blue, Part No.: 00309750  
red, Part No.: 00309751  
green, Part No.: 00309753

#### Roll chart

overall width: 120mm

no name, % graduation, linear

overall length: 16m

Packing unit: 5 rolls

Part No.: 00331497

no name, % graduation, linear

overall length: 32m

Packing unit: 5 rolls

Part No.: 00331499

no name, special graduation  
(printing as order specification)

overall length: 16m/32m

#### Fanfold chart

overall width: 120mm

overall length: 16m

no name, % graduation, linear



Packing unit: 5 packs

Part No.: 00331490

no name, special graduation  
(printing as order specification)









# 9 Consumables

## 9.2 Removing and replacing the chart cassette








# 9 Consumables

## 9.2.1 Changing the roll chart







# 9 Consumables

## 9.2.2 Changing the fanfold chart



# 10 Accessories

## 10.1 Converting the chart cassette



# 11 Fault finding

## 11.1 What to do if...

Fibre pens on 0%	<ul style="list-style-type: none"> <li>- The value is outside the measuring range (Out Of Range)</li> <li>- The transducer has been connected incorrectly</li> <li>- The signal inputs are configured incorrectly</li> <li>- Sensor break</li> </ul>
No recording	<ul style="list-style-type: none"> <li>- Key <b>S</b> has been pressed ⇒ Section 6.1</li> <li>- The chart cassette has not been fitted correctly ⇒ Section 9.2 Caution: Insert the chart cassette by applying light upwards pressure</li> <li>- The take-up roll has not properly engaged with the chart cassette ⇒ Section 9.2.1</li> <li>- The end of the chart has been reached ⇒ Section 9.2.1, Section 9.2.2</li> <li>- The chart speed has been programmed as 0 mm/h ⇒ Section 8.3</li> </ul>
Fibre pen does not write	<ul style="list-style-type: none"> <li>- The fibre pen has not been fitted correctly ⇒ Section 5.4</li> <li>- The fibre pen has run out of ink</li> </ul>
No chart feed	<ul style="list-style-type: none"> <li>- The chart cassette has not been fitted correctly ⇒ Section 9.2</li> <li>- The chart has not been fitted correctly</li> <li>- The chart speed has been programmed as 0mm/h</li> <li>- The pin roller does not engage with the chart perforations</li> <li>- The tear-off edge is not correctly engaged</li> <li>- The pen recorder is in the STOP status</li> </ul>
Measurements are not recorded	<ul style="list-style-type: none"> <li>- Check that the connecting terminals are tightened properly</li> <li>- Check the supply</li> <li>- Check the input configuration (range)</li> <li>- Check the transducers and their cables, measure them where appropriate</li> </ul>

# 12 Appendix

## 12.1 Error messages

All error messages flash on the 7-segment display at regular intervals.

All other instrument functions remain unaffected as far as possible.

Display	Cause / Remedy
<b>Status message</b>	
Er 13	The chart cassette has been removed or the end of the chart has been reached; a fresh chart must be fitted. ⇒ Section 9.2 ff
<b>Error or fault on module</b>	
Er 10	The battery for the real time clock and for RAM backup is discharged. Please contact the nearest office or the factory.
<b>Errors on parameter input</b>	
Err	<ul style="list-style-type: none"><li>- Date is invalid An invalid date has been input. The input must be repeated.</li><li>- Time is invalid An invalid time has been input. The input must be repeated.</li><li>- Error in value input The input is outside the range of values. The input must be repeated.</li></ul>

## 12.2 Hardware fault

If one of the following faults occurs, the recording is aborted and the error message flashes on the display.


The recorder does not react to any event and can not be operated.

Please contact the nearest office or the main factory.

<b>Display</b>	<b>Cause / Remedy</b>
Er 12	The EEPROM in the recorder is faulty, the configuration data can no longer be stored.
Er 17	The A/D converter of the recorder is faulty.
Er 18	One of the Hall sensors in the recorder is faulty.

## 12.3 Status messages

The following status messages are indicated on the 7-segment display:

<b>Display</b>	<b>Description</b>
<i>in it</i>	The recorder is being initialised. Please wait.
<i>STOP</i>	The recorder is in the Stop status, because the  key has been pressed.
<i>busy</i>	The configuration data are being written to the EEPROM. During this time the recorder does not respond to any inputs.

## 12.4 Overview of the parameters

Parameter	Description
Chart speed	Chart speed in mm/h
Language	Language (for printing)
Date and time	System clock of the recorder
Summer time	Start and end of summer time
Display time	Switch on/off display of time in the basic status
Signal inputs	Selection of the analogue input signals

# Index

---

## A

Analogue inputs *15*

## B

Basic status *19, 30*

## C

Change of chart speed *26*

Channel label *16*

Chart cassette

    changing fanfold chart *48*

    changing roll chart *47*

    converting *49*

    removing and replacing *46*

Chart fast forward *30*

Chart speed *32*

Clock time *25, 38*

Codenummer *20, 35*

Configuration level *42*

Connection diagram *15*

Consumables *45*

Current *15, 43*

## D

Decimal place *23*

Display and controls *16*

Display time *41*

Documentation *6*

Door *16*

## E

Earth line, protective *14*

Electrical connection *15*

Electrostatic discharge (ESD) *5*

Entering parameters *22*

Error messages *22, 51*

Extra Codes *10*

## F

Fanfold chart *45*

Faults, remedy of *50*

Fibre pen *45*

Fibre pen, fitting of *17*

Filter constants *43*

Fitting in position *13*

Front view *13*

## H

Hardware fault *52*

Hazardous area (EX) *14*

## I

Input signals *43*

Installation notes *14*

Instrument description *9*

## K

Key functions *22*

## L

Language *37*

LED display *16*

Level inhibit and code request *35*

Levels *19*

    basic status *19*

    configuration level *20*

    operating level *19*

    parameter level *20*

Location of recorder *12*

## O

Operating level *19, 31*

Operating mode

    basic status *18, 19*

    chart speed *18*

# Index

---

stop *18*

Operation *19*

Overview of parameters *54*

## P

Panel cut-out *13*

Parameter coding *21*

Parameter level *20, 36*

Parameter overview *54*

Parameters, entering *22*

Print test *28, 33*

Printing priority *24*

Programming

  abort *22*

  chart speed *32*

  date and time *38*

  language *37*

  level inhibit and code request *35*

  print test *33*

  selection *23*

  service print *34*

  signal inputs *43*

  summer time *39*

  value input *23*

## R

Range *43*

Recording start *27*

Recording start and end *27*

Returning the recorder *5*

Roll chart *45*

## S

Selection *23*

Sensor *14*

Sensor break *50*

Service print *29, 34*

Side view *13*

Signal inputs *43*

Starting up *5*

Status messages *53*

Stop *18*

Sub-parameters *21*

Summer time *39*

System clock *38, 39*

## T

Text printing *24*

  abort criteria *24*

  chart speed *26*

  clock time *25*

  print test *28*

  printing priority *24*

  service print *29*

Time reference mark *25*

Tree structure *21*

Type designation *10*

Typographical conventions *7*

## V

Value input *23*

Voltage *15, 43*

## W

Warranty *5*









**JUMO GmbH & Co. KG**

Street address:  
Moltkestraße 13 - 31  
36039 Fulda, Germany  
Delivery address:  
Mackenrodtstraße 14  
36039 Fulda, Germany  
Postal address:  
36035 Fulda, Germany  
Phone: +49 661 6003-0  
Fax: +49 661 6003-607  
e-mail: [mail@jumo.net](mailto:mail@jumo.net)  
Internet: [www.jumo.net](http://www.jumo.net)

**JUMO Instrument Co. Ltd.**

JUMO House  
Temple Bank, Riverway  
Harlow, Essex CM20 2TT, UK  
Phone: +44 1279 635533  
Fax: +44 1279 635262  
e-mail: [sales@jumo.co.uk](mailto:sales@jumo.co.uk)  
Internet: [www.jumo.co.uk](http://www.jumo.co.uk)

**JUMO PROCESS CONTROL INC.**

885 Fox Chase, Suite 103  
Coatesville, PA 19320, USA  
Phone: 610-380-8002  
1-800-554-JUMO  
Fax: 610-380-8009  
e-mail: [info@JumoUSA.com](mailto:info@JumoUSA.com)  
Internet: [www.JumoUSA.com](http://www.JumoUSA.com)