

JUMO LOGOSCREEN nt
Paperless Recorder
with TFT display and
CompactFlash card

B 70.6580.1
Operating Instructions

08.06/00453819

Menu structure of the paperless recorder



⇒ Device manager, Chapter 7, Page 51



⇒ Memory manager, Chapter 6, Page 47



⇒ Alarm and event lists, Chapter 5, Page 43



⇒ Operator level (visualization), Chapter 3, Page 23



⇒ Memory presentation (History), Chapter 4, Page 39

Contents

1	Introduction	5
1.1	Preface	5
1.2	Arrangement of the documentation	6
1.3	Typographical conventions	8
2	Device description	11
2.1	Displays and controls	12
2.2	Operating principle and graphic elements	14
2.3	Operating example	18
2.4	Group and plant management (batches)	20
3	Operator level (visualization)	23
3.1	Activate operator level	23
3.2	Overview of header lines	24
3.3	Curve presentation	25
3.4	Bar graph presentation	26
3.5	Textual presentation	27
3.6	Process diagram	28
3.7	Binary presentation	28
3.8	Report	29
3.9	Batches/plants	30
3.9.1	Current batches	30
3.9.2	Completed batches	32
3.9.3	Batch control through barcode reader	33
3.10	Counters and integrators	36
3.11	Comment entry	37
4	Memory presentation (History)	39

Contents

5	Alarm and event lists	43
5.1	Call from one of the visualization modes	44
5.2	Call from the memory presentation	46
5.3	Symbols	46
6	Memory manager	47
7	Device manager	51
7.1	Logging in and logging off	53
8	Entering text and values	55
8.1	Text entry	55
8.1.1	Entering characters	55
8.1.2	Insert space	57
8.1.3	Delete character.	57
8.1.4	Move cursor.	57
8.1.5	Enter text from text list	57
8.1.6	Finish entry	57
8.1.7	Reject entry	58
8.2	Entry via selection field	58
8.3	Entering values	59
8.3.1	Whole numbers (integers)	59
8.3.2	Real numbers (floating point)	60
9	Index	61

1.1 Preface



Please read these operating instructions before commissioning the instrument. Keep the operating instructions in a place which is accessible to all users at all times.

Please assist us to improve these operating instructions, where necessary.

Your comments will be appreciated.



If any difficulties should arise during commissioning, you are asked not to carry out any manipulations that could endanger your rights under the instrument warranty!

Please contact the nearest subsidiary or the head office in such a case.



When returning modules, assemblies or components, the regulations of EN 61340-5-1 and EN 61340-5-2 “Protection of electronic devices from electrostatic phenomena” must be observed. Use only the appropriate **ESD** packaging for transport.

Please note that we cannot accept any liability for damage caused by ESD.

ESD=Electro Static Discharge

1 Introduction

1.2 Arrangement of the documentation

The documentation for this instrument is addressed to equipment manufacturers (OEMs) and users with appropriate technical expertise. It consists of the following parts:

Instrument documentation in printed form

B 70.6580.1 Operating Instructions

The operating instructions are an extract from the operating manual and cover the basic operation of the paperless recorder.

B 70.6580.4 Installation Instructions

The installation instructions describe the installation of the recorder and the connection of the supply and signal cables. The instructions also contain a list of the technical data.

Instrument documentation in the form of PDF files

The “Instrument documentation in the form of PDF files” is on the CD that is included in the delivery.

B 70.6580.0 Operating Manual

It contains information about commissioning, operation, parameterization and configuration on the instrument.

B 70.6580.1 Operating Instructions

The operating instructions are an extract from the operating manual and cover the basic operation of the paperless recorder.

B 70.6580.2.0 Interface Description (serial interfaces)

This provides information on communication (RS232, RS485) with supervisory systems.

Interface Description (Ethernet interface)

This provides information on the connection of a paperless recorder to a company-internal network. This description is integrated into B 70.6580.2.0

B 70.6580.2.3 Interface Description (PROFIBUS-DP interface)

This provides information on the connection of a paperless recorder to a PROFIBUS-DP system.

B 70.6580.4 Installation Instructions

The installation instructions describe the installation of the recorder and the connection of the supply and signal cables. The instructions also contain a list of the technical data.

B 70.6580.6 Setup Program

The manual describes the function of the setup program. The setup program is available as an option.

T 70.6580 Data Sheet

The data sheet contains general information, the order details and the technical data.

B 70.9701.0 PC evaluation software (PCA3000)

The operating manual describes the operation and the features of the PC evaluation software.

The PC evaluation software serves to visualize and evaluate process data (measurement data, batch data, messages ...). The process data can be read in via the CompactFlash memory card, or made available through the PCC software.

B 70.9702.0 PCA communications software (PCC)

The operating manual describes the operation and the features of the PCA communications software.

The PCA communications software is responsible for the data transfer from the paperless recorder to a PC, or across a network.



All documents are available for downloading at www.jumo.de

- * Start the product search on the home page.
- * Enter 70.6580 and start the search.
- * Select the paperless recorder
- * Select the download section
- * Download the PDF file.

1 Introduction

1.3 Typographical conventions

Warning signs

The signs for **Danger** and **Caution** are used in this manual under the following conditions:



Danger

This symbol is used when there may be **danger to personnel** if the instructions are ignored or not followed correctly!



Caution

This symbol is used when there may be **damage to equipment or data** if the instructions are ignored or not followed correctly!



Caution

This symbol is used where special care is required when handling **components liable to damage through electrostatic discharge**.

Note signs



Note

This symbol is used when your **special attention** is drawn to a remark.



Reference

This symbol refers to **further information** in other manuals, chapters or sections.

abc¹

Footnote

Footnotes are remarks that **refer to specific points** in the text. Footnotes consist of two parts:

A marker in the text, and the footnote text.

The markers in the text are arranged as continuous superscript numbers.

Action instruction

*

This symbol indicates that an **action to be performed** is described.

The individual steps are marked by this asterisk, e.g.

* Rotate control knob

* Press control knob

Presentation modes

*Program
Manager*

Screen texts

Texts that are displayed in the setup program are indicated by **italic script**.

*Edit →
Device data*

Menu items

Menu items in the setup and instrument software referred to in this manual are shown in italics. Menu name, menu item and submenu item are separated from each other by “→”.

1 Introduction


2 Device description

After the paperless recorder has been started up by switching on the supply (power ON), the start logo is the first item that appears.




During screen build-up, the recorder is initialized with the data of the last configuration. After the initialization phase, the presentation mode that was last selected is shown in the visualization level (factory setting). Please note that the start-up behavior is configurable, so you can alter it.

Normal display This mode of presentation is known as “Normal display”.




2 Device description

2.1 Displays and controls



1. CompactFlash[®] is a registered trademark of SanDisk Corporation.

2 Device description



The CompactFlash memory card must not be removed while it is being accessed (signal LED is on).




The life of the background illumination can be prolonged by using the parameter "Screen off".

2 Device description

2.2 Operating principle and graphic elements

Header



Function is activated when the control knob is pressed.

The functions of the paperless recorder are selected in the header. The selected function is indicated by a blue background.




- Function selection by rotating the control knob (to right or left).



- Function is activated by pressing the control knob.

The symbols and variable functions alter according to the function that is currently active.

The following diagram shows the header for normal display when the vertical diagram (curve display) has been selected.



2 Device description

Device manager	⇒ Chapter 7
Memory manager	⇒ Chapter 6
Alarm and event lists	⇒ Chapter 5
Operator level (Visualization)	⇒ Chapter 3
Group selection	⇒ See “Group selection” on Page 25.
Memory presentation	⇒ Chapter 4
Numerical measurement display	⇒ See “Numerical measurement display” on Page 25.
Channel step-on	⇒ See “Channel step-on” on Page 26.
Group step-on	⇒ See “Group step-on” on Page 26.

Status line and title line


This line bar shows alarm and error messages, as well as events, general information, and information about the current presentation mode (e.g. sampling rate). It is automatically blanked out by the system if necessary.


If the text is shown in red, this indicates an error message.



Sampling rate and operating mode:

5s = normal mode

1s  = event mode

1s  = timed mode



A data-read by the PCA communications software (PCC) is currently in progress.

2 Device description

Numerical measurement display (diagram header)

The numerical measurement display is available for the presentation modes:

- Curves
- History (curve display) and
- Digital diagram

In the **curve presentation**, the numerical display can be switched on and off. This on and off switching also applies to the history representation.



An alarm for a channel is shown in red (MAX alarm) or orange (MIN alarm).

If the numerical measurement display is switched on in the **history (curve presentation)**, you can switch between MIN and MAX display. Whether or not MIN and MAX values are both available at the same time, depends on the settings for the group operating mode.




In the **digital presentation**, the diagram header can be switched on and off.







2 Device description

Visualization window (diagram)



Symbols for data acquisition:

-  Comment has been entered
-  Event occurred
-  Alarm is no longer present
-  Alarm has been signaled


In the visualization window, the measurements are shown in graphical form. Alarms are indicated by a red or orange color for the curve (can be configured in the setup program).

Communication with the operator (device configuration, checking alarm and event lists etc.) also takes place through the visualization window.

2 Device description

2.3 Operating example

Start The normal display is active.




Operation



- * Select the operator level by rotating the control knob.




- * Activate the operator level by pressing the control knob.



2 Device description




- * Select bar graph display by rotating the control knob.



- * Activate bar graph display by pressing the control knob.


Result

The bar graph display is now started.



2 Device description

2.4 Group and plant management (batches)



Within the recorder, all analog inputs, binary inputs, counters and integrators, are collected together into groups. A maximum of nine groups is available as a total. Each group can consist of a maximum of 6 analog inputs, 6 binary inputs/outputs, and 4 counters/integrators.

The presentation of the analog inputs and binary inputs/outputs is always made on a group basis.

If plants (batches) are used, then the groups have a fixed assignment to the plants (batches).

Plant number	Group	Plant (batch)
1	1 – 9	1
2	1 – 3 4 – 6 7 – 9	1 2 not assigned
3	1 – 3 4 – 6 7 – 9	1 2 3

2 Device description



In order for a batch to be usable, its main group must be active (status = “Display” or “Display, save”) and at least one analog channel in the group must be assigned.

Batch for plant	Main group
1	1
2	4
3	7

The number of plants is configured by the parameter *Device manager* → *Configuration* → *Batches/plants* → *Gen. plant parameters* → *Number of plants*.

2 Device description

3 Operator level (visualization)

3.1 Activate operator level


The type of visualization (curve presentation, bar graph etc.) is selected at the operator level. Note that the appearance of the operator level can be influenced by the configuration.

- * Select the operator level by rotating the control knob.
- * Activate the operator level by pressing the control knob.



Operator level

You can alter the visualization after activating the operator level.



The functions in the header line will change, depending on the visualization. The following types of visualization are available:

Curves	⇒ Chapter 3.3
Bar graph	⇒ Chapter 3.4
Text screen	⇒ Chapter 3.5
Process screen	⇒ Chapter 3.6
Binary	⇒ Chapter 3.7
Report	⇒ Chapter 3.8
Batches	⇒ Chapter 3.9
Counters and integrators	⇒ Chapter 3.10
Comment entry	⇒ Chapter 3.11

3 Operator level (visualization)

3.2 Overview of header lines

Curve presentation	2006/08/04 11:25:32 38%
Bar graph presentation	2006/08/04 11:13:35 38%
Textual presentation	2006/08/04 11:29:22 38%
Process diagram	2006/08/04 11:27:16 38%
Digital presentation	2006/08/04 11:24:00 38%
Report	2006/08/04 11:25:32 38%
Batches (current)	2006/08/04 11:22:41 38%
Batches (finished)	2006/08/04 11:21:11 38%
Counters and integrators	2006/08/04 11:31:18 38%

Comment entry The comment entry does not have its own header. The current header will remain when this function is activated. The comment that has been input is entered in the event list.




The first four functions in the header are identical for all types of visualization. These are supervisory functions (see Page 14 and Page 15).

Differences only arise in the last five functions.

3 Operator level (visualization)

3.3 Curve presentation

In the curve presentation, the individual signal traces run from top to bottom of the display (vertical presentation).



Group selection You can use this function to directly select and display any one of the groups.

Memory presentation This function starts the presentation of the data that are available in the history memory.


⇒ Chapter 4 “Memory presentation (History)”

Numerical measurement display This function is used to switch the numerical measurement display or diagram header on or off.

3 Operator level (visualization)

Channel step-on

This function activates the scaling display. Repeated activation steps through the scaling for the channels within the group, and then blanks it out again.




Group step-on

Unlike “Group selection”, where any group can be selected, this function selects the groups one after another.



3.4 Bar graph presentation

In this visualization mode, the analog inputs are presented both numerically and in bar graph form. In addition to the analog channels, the digital inputs can also be visualized at the bottom of the display.



An alarm (Alarm 1 or Alarm 2) is indicated by an orange or red background. The colors can be configured in the setup program.


If only digital channels are to be presented, then Chapter 3.7 “Binary presentation” is recommended.

3 Operator level (visualization)


3.5 Textual presentation

In presentation, the analog channels are presented numerically, together with the channel name and the channel description. In addition to the analog channels, the digital inputs can also be visualized at the right-hand edge of the display.

Group presentation




1-channel presentation



3 Operator level (visualization)


3.6 Process diagram

In the presentation, selected measurement signals and background pictures are shown in a process diagram (one group per process diagram). The preparation and configuration of the diagram can only be carried out by the device manufacturer.



3.7 Binary presentation

In the presentation, the analog channels are left out and only the digital channels are visualized.




3 Operator level (visualization)

3.8 Report

Each one of the reports covers all the analog channels in a group. An individual and configurable report is provided for each group.

The current reports are visualized in the presentation.



Group selection You can use this function to directly select any one of the groups and display the report data.

Report step-on This function is used to switch between the various types of report for the current channel.

Channel step-on This function can be used to switch between the individual channels of the currently active group.

Group step-on Unlike "Group selection", where any group can be selected, this function is used to select the groups one after another.

3 Operator level (visualization)


3.9 Batches/plants

When recording batch processes, a distinction is made between the plant and the batch.


The instrument can combine and record the data from up to 3 plants as a batch (batch protocol). The number of batches for a plant is not limited. The instrument distinguishes between “current batch” and the most recently “completed batch” for a plant. The number of plants that are used and the texts in the batch template can be configured on the instrument or in the setup program.

3.9.1 Current batches

⇒ This display shows the current data for the batch(es). Further information about entering the texts in the left and right columns can be found in the Operating Manual B 70.6580.0.



The batch texts on the right-hand side can be entered by using one of the following options:



3 Operator level (visualization)

Edit batch

This function can be used to edit the batch text fields that are available (configured for this purpose). When the function has been called up, the first editable field in the screen will be activated.



- * Press the control knob to start editing.
- * Enter the text (Chapter 8 “Entering text and values”).



- * Rotate the control knob to select a new field or button, and activate it by pressing the control knob.

Change batch/plant

Changeover between the individual batches/plants. A maximum of 3 plants can be configured.

Start/stop batch

Use the parameter *Device manager* → *Configuration* → *Batches/plants* → *Plant X* → *General* → *Batch start* to configure how a batch starts and stops. The following are available:

- start/stop by a binary signal (control signal),
- start/stop by a bar code reader, and
- manual start/stop by control knob.



At least 5 seconds must elapse between the stop of a batch (batch end) and the next start (batch start). A new batch can only be started when this time has elapsed.

Batch status




The batch report that is displayed is active.



The batch report that is displayed is **not** active.

3 Operator level (visualization)


3.9.2 Completed batches



Analyze batch

Completed batches can be analyzed in three different ways:

- batch data (graphical presentation)
- report (numerical presentation)
- attachments (e.g. recipes).



- * Rotate the control knob to select a type of presentation, then press the knob to activate this type.



Activating the door symbol in the header closes the selected presentation, and the batch data will be displayed again.

Change batch/plant

The corresponding batch data will be shown in its own batch screen template, depending on how many plants have been configured.

3 Operator level (visualization)

3.9.3 Batch control through barcode reader

If a barcode reader is connected to the interface “RS232 for barcode reader” (extra code, connector 2) or “RS232/RS485” (connector 7), then the batch start, batch stop, and input of batch texts in a current batch report, can be controlled by the barcode reader. The bar codes that are used all correspond to the type “Code39”.

Preconditions

- The interface must be configured for barcode operation.
Example:
Configuration → Interface → RS232 for barcode reader → General → Protocol = Bar code.
- The batch start (= batch stop) must be configured.
Example for batch start/stop:
Configuration → Batches/plants → Plant 1 → General → Batch start = Bar code.
- Every line that is to be set by the bar code must be configured.
Example for plant 1, line 1 (program name):
Configuration → Batches/plants → Plant 1 → Line 1 → content of right column = Bar code.

Activate batch



Before entering commands through a barcode reader, the corresponding plant 1 – 3 must be prepared by scanning in “BATCH1 – 3” for the bar code commands, regardless of whether or not they are automatically displayed.

Show batch report

If one of the visualizations is active, and nothing is being entered or edited at the moment, then the current batch report can be shown via the barcode reader. The precondition is that the batch is active and the parameter is set to *Configuration → Screen → Barcode -> act. batch = Yes.*

Active and display (if required) batch report for plant 1:



BATCH1

Activate and display (if required) batch report for plant 2:



BATCH2

3 Operator level (visualization)

Activate and display (if required) batch report for plant 3:



Start/stop batch report

If the batch report is configured for start/stop via barcode reader, then it will be started and stopped as follows.

Start batch

- * Scan bar code for “Batch report for Plant 1 — 3”.
- * Start scan.



Stop batch

- * Scan bar code for “Batch report for Plant 1 — 3”.
- * Stop scan.



If a batch report is stopped, then texts that have been activated by a bar code will be reset to the standard (default) text in the batch report that is currently active.
In the completed batch report, the texts will be saved.

Activate batch texts

If a line in a batch report is configured for bar code activation, the activation proceeds as follows.

Activate text:

- * Scan bar code for “Batch report for Plant 1 — 3”.

Scan text.



3 Operator level (visualization)

The first line of the activated batch report that has been configured for text input via bar code will automatically be filled with the text that corresponds to the bar code. If several line have been configured for bar code activation, then they will be processed one after another, from top to bottom.

Reset entry

Execution of the following bar code will reset the activation of the batch texts. The standard (default) texts (parameter *Factory setting*) will be displayed, and the first line will be prepared for input.



RESET

Summary of the bar codes

All the bar codes that are required are also collected together in the appendix of the operating manual B 70.6580.0.




The codes for batch control (BATCH1, BATCH2, BATCH3, START, STOP, RESET) cannot be used for setting batch texts.

3 Operator level (visualization)


3.10 Counters and integrators

In this presentation, the current states of the counters and integrators are displayed, as well as the operating hours counter. Up to 9 counters and integrators can be shown in one screen template. The functional characteristics, as counter, integrator or operating hours counter, are defined in the device configuration.

Overview presentation




Individual presentation



3 Operator level (visualization)

3.11 Comment entry

This function can be used to enter a text (max. length 31 characters) that is entered in the event list when the input is completed.



In the curve presentation (in the displayed group), the text entry is marked by a pencil symbol.



- ⇒ Chapter 5 “Alarm and event lists”
- ⇒ Chapter 3.3 “Curve presentation”
- ⇒ Chapter 3.11 “Comment entry”

The text can now be found in the event list, under the heading “All events”, and also under the corresponding batch.



If plants (batches) are used (parameter: *Device manager* → *Configuration* → *Batches/plants* → *Gen. plant parameters* → *Number of plants* is larger than 0), then the groups have a fixed assignment to the plants (batches).

Plant number	Group	Plant (batch)
1	1 – 9	1
2	1 – 3 4 – 6 7 – 9	1 2 not assigned
3	1 – 3 4 – 6 7 – 9	1 2 3

3 Operator level (visualization)

4 Memory presentation (History)

The memory presentation (History) function can be used to display and check data from the internal main memory of the instrument. The size of the memory for memory presentation can be configured.

The memory presentation can be activated in the visualization modes “Curve display” and “Digital presentation”, and is also used for the display of completed batches.


Activate memory presentation



- * In “Curve display” or “Digital presentation”, rotate and press the “H” symbol to select and activate the History presentation.



End memory presentation
Channel step-on
Numerical measurement display
(MIN / MAX changeover)
Zoom and Search
Scroll pages
Scroll lines
Alarm and event list



Present cursor position

A cursor is now shown in the center of the visualization window. The corresponding measurements are shown in the line for “Numerical measurement display”.

Alarm and event lists

This function is used to present the alarm and event lists for the group that is being displayed.

⇒ Chapter 5 “Alarm and event lists”

4 Memory presentation (History)

Scroll lines Rotating the control knob moves the cursor through the visualization window. The data in the “Numerical measurement display” are updated for every shift. If you move right up to the edge of the window, the measurement curve will automatically be shifted and the required data will be presented.


“Scroll lines” is ended by pressing the control knob.

Scroll pages Rotating the control knob moves the cursor an entire screen (=page) at a time. The data in the “Numerical measurement display” are updated for every shift. The system automatically positions the cursor at the end of the page, as required.

“Scroll pages” is ended by pressing the control knob.

Zoom and search This function affects how many measurements are used to calculate a point in the diagram, and to search for measurements according to date and time.

Zoom



The factory setting is “1:1”, which means that every measurement in the History memory will be displayed. “1:2” means that two measurements are combined into one, which is then displayed, and so on.

- * Select the zoom factor by rotating the control knob.
- * Pressing the control knob closes the dialog window and activates the new Zoom factor.
- * Selecting “Exit” closes the dialog window, and the presentation remains unchanged.

Adjust


This function is only available for presenting the data for a completed batch.

If you select this function, all the available measurements for the completed batch are displayed in a window. In this way, you can get a quick overview of all the recorded measurements.

Search

If you select “Search”, the dialog window for entering the date will be shown.

4 Memory presentation (History)



- * Select the date and time, and use OK to close the dialog.


If the date that you entered is in the History memory, the cursor will move to this position and the data will be shown.

Numerical measurement display

This function decides whether the MAX or MIN values are shown in the “Numerical measurement display”. MIN or MAX values arise when more measurements are recorded than are displayed. This will be the case if “MIN/MAX recording” is activated in the operating mode for a group.

Channel step-on

This function activates the scaling display. Repeatedly activating the function steps through the scaling for the channels within the group, and then blanks it out again.



Close memory presentation

This function ends the presentation of the data that are available in the internal main memory of the instrument.

4 Memory presentation (History)

5 Alarm and event lists

The alarm and event lists can be called up in two ways:

- a call from one of the visualizations, e.g. curve presentation (Chapter 3.2 “Overview of header lines”)

or

- a call from the memory presentation (Chapter 4 “Memory presentation (History)”).

Alarm lists

Alarm lists contain only the alarms that are currently present.



The alarm list will not be updated as long as the window is open.
Remedy: close once, and open again. This will update the alarms.

Event lists

Events list contain all the events that have occurred, as well as all alarms.



A maximum of 150 entries can be fitted into the two lists. The lists will be deleted if a reconfiguration takes place.



The following description assumes that three batches are being used. The number of batches may vary, because it can be configured by the user.

5 Alarm and event lists

5.1 Call from one of the visualization modes




- * In the header line, rotate the control knob to select the bell symbol, and press the knob to activate the symbol.



- * Select the required list.

Activate alarm list



Complete list of alarms

Batch-related alarm lists.


If the number of batches is reduced, then fewer entries will be displayed.

- * Rotate the control knob to select a list, then press the knob to activate the list.

Activate event list

First, it is necessary to “fold down” the directory tree for the event lists.

- * Rotate the control knob to select an event list, then press the knob to activate the list.



Complete list of events


Batch-related event lists

5 Alarm and event lists

- * Rotate the control knob to select a list, then press the knob to activate the list.

Example

In the example you can see a complete event list.



The screenshot shows a control panel interface. At the top, it displays the date and time '2006/08/04 10:21:16' and the status 'Master'. Below this is a battery level indicator at '36%'. The main display area is titled 'Event list-All events' and contains a table with the following data:

Date	Time		Description
2006/08/04	10:21:00	▲	High Alarm Count 01 off
2006/08/04	10:20:56		CF card in place
2006/08/04	10:20:53		CF card removed
2006/08/04	10:19:43		Ethernet: email error inde...
2006/08/04	10:19:36	▼	Alarm B I/O 09 off
2006/08/04	10:19:35	▲	High Alarm Count 01 on
2006/08/04	10:19:35	▲	Alarm B I/O 09 on
2006/08/04	10:19:33	▼	Batch 01 end

Close list

- * Close the event list by pressing the control knob.

The visualization that was active before the list was called up will now be displayed again.

5 Alarm and event lists

5.2 Call from the memory presentation



- * In the header line, rotate the control knob to select the bell symbol, and press the knob to activate the symbol.



In memory presentation mode, only the event list for the active group will be shown.

Close list

- * Close the event list by pressing the control knob.

The memory presentation that was active before the list was called up will now be displayed again.

5.3 Symbols

	Power on (instrument has been switched on)
	Power off (instrument has been switched off)
	Error
	Alarm disappears (alarm is no longer present)
	Alarm occurs (an alarm is present)
	Comment
	Event occurs (e.g. binary input has been closed)
	Event disappears (e.g. binary input has been opened)
(no symbol)	other messages

6 Memory manager

The symbol for the memory manager (menu: Memory manager) can be shown in different ways.



This shows the available memory of the CompactFlash memory card that has been inserted.

If no CF card has been inserted, then one of the following symbols will be shown, depending on the type of data read-out that was configured.



The display shows the available internal memory for data read-out via a CompactFlash memory card.



This shows the available internal memory for data read-out via the interface.



The memory manager can only be accessed when a CF card has been plugged into the instrument. After the card has been plugged in, the menu will appear automatically.


If not all functions are available, then you have to log in to the device first, in order to obtain the required access rights.

⇒ Chapter 7.1 “Logging in and logging off”



- * Select the memory manager by rotating the control knob, and then press it to activate the function.

6 Memory manager



Close memory manager

Close the memory manager and reactivate the previous visualization.

Update CF card

Measurement data that have not yet been saved are written onto the CompactFlash memory card.

Backup -> CF card

All measurement data in the memory (also those which have already been fetched) are written to the CompactFlash memory card.

Config data -> CF card

The configuration data and the user list (for password management) are written to the CompactFlash memory card.

CF card -> config data

The configuration data are read in from the CompactFlash memory card. This will give the recorder a new configuration.

Save all + CF card update

All current reports will be concluded and written to the CompactFlash memory card, together with the measurement data that have not yet been saved. The present counter and integrator states will also be saved.

CF card -> user list

The user list is read in from the CompactFlash memory card.

General note



The function *Update CF card* reads out data that have not yet been read out. After read-out, the data will be marked as read in the instrument, but not deleted.



The function *Backup → CF card* reads out all the data from the internal memory, including those that had already been read out. After read-out, the data are **not** marked as read in the recorder. This means that they remain available for the function *CF card → Update*. The function *Backup → CF card* is therefore ideal for test and service work.

6 Memory manager


7 Device manager

The functions of the Device manager vary, depending on whether a user is logged in or not.



No user
logged in



“User”
logged in



“Master”
logged in



The differences between “No user logged in” and “User logged in” only become visible in the submenu “Parameterization”.

7 Device manager

Close device manager

Close the device manager and reactivate the previous visualization.

Log-in and log-off

⇒ Chapter 7.1 “Logging in and logging off” (Page 53)

Device information

This function provides you with information on the hardware and software components of the instrument. The momentary values of all the internal and external inputs can also be checked.

The control knob can be rotated to display every single table. The function is ended by pressing the control knob.

Device audit trail

This function can be used to display the audit trail for the device.

The audit trail differs from the alarm and event lists.

⇒ Further information can be obtained from the Operating Manual B 70.6580.0.

The function is ended by pressing the control knob.

Configuration

This function can be used to alter the configuration of the recorder.

⇒ Further information can be obtained from the Operating Manual B 70.6580.0.



An alteration of the configuration results in the current recording being closed down and the new data being recorded in a separate time frame from the “old” data. It is not possible to present the data before reconfiguration and the data after reconfiguration as a single entity.

Parameterization

For parameterization, some functions will not be available if no user is logged in, or the user who is logged in does not have the access rights for these functions.

Only the setting of individual current batch numbers is enabled in the factory (default) setting.

The following functions may also be available, depending on the rights owned by the user who is logged in.

- Fine adjustment of internal analog inputs,
- Setting of counter and integrators states, and
- Setting the date and time.


Service

The Service functions will also not be available if no user is logged in, or the user who is logged in does not possess access rights for these functions.

⇒ Further information can be obtained from the Operating Manual B 70.6580.0.

7.1 Logging in and logging off

- * Select the *Device manager* in the header line, by rotating the control knob.
- * Activate the *Device manager* by pressing the control knob.
- * Activate the *Security* function in *Device manager*.



Standard user




The paperless recorder is delivered ex-factory with an internal user list which contains two users.

User 1: Master password: 9200
User 2: User password: 0


The setup program can be used to alter the two user names and their passwords and access rights, and transfer this information to the device.

Log-in

- * In the menu *Device manager* → *Log-in*, activate the function *Log-in*.




- * Select the user. The user name can be changed by rotating the control knob.
- * Select "OK" with the control knob, and press the control knob.



7 Device manager

- * Enter the password by rotating and pressing the control knob, and finish the entry with "OK".

You are now logged in to the system.



8 Entering text and values


8.1 Text entry

8.1.1 Entering characters

If a text entry field is selected, and then activated by pressing the control knob, then a text can be entered or altered.



The cursor (position marker) is at the end of the current setting. The active key or function that will be performed when the control knob is pressed is shown in blue.



Available characters




The characters that are shown as available are just an example. They can be adjusted to suit your needs through the setup program.


8 Entering text and values

Character entry

- * Move the cursor onto the required character, and press the control knob. Another selection window will open.



- * Rotate the control knob to select upper case (capital) or lower case (small) letters, activate/confirm the choice by pressing the control knob.




Entering special characters

Special characters are entered as text.

- * Select the # symbol, and press the control knob.

All the special characters that can be selected will now be shown.




Here, too, the selection and confirmation of the characters are made, by rotating and pressing the control knob.

Numerical entry

- * Select number "1", and press the control knob.

All the numbers that can be selected will now be shown.




The selection and confirmation of the numbers are made by rotating and pressing the control knob.

8 Entering text and values

Select temperature unit

- * Select “°” and press the control knob.

All the temperature units that can be selected will now be shown. For better legibility, the degree sign (°) and the unit (C or F) are separated, and must be individually selected.



The selection and confirmation of the symbol is made by rotating and pressing the control knob.

8.1.2 Insert space

- * Select the space button () and press the control knob.

The space character will be inserted to the right of the cursor.

8.1.3 Delete character.

- * Select the delete button () and press the control knob.

The character to the left of the cursor will be deleted.

8.1.4 Move cursor.

- * Select the cursor positioning button () and press the control knob.

The cursor can now be moved. The shifting is ended by operating the control knob again.

8.1.5 Enter text from text list

All the texts that have already been entered (confirmed by *OK*) are stored in the recorder in an internal text list. This function can be used to call up the list and select a text for current application.

- * Call text list ().

The selection and confirmation of the required text are made by rotating and pressing the control knob.

8.1.6 Finish entry

- * Select the *OK* button () and press the control knob.

Character entry will now be ended. The text that was entered is accepted, and the dialog window is closed.

8 Entering text and values

8.1.7 Reject entry

- * Select the “Cancel” button () and press the control knob.

Character entry will now be ended. The text that was entered is **not** accepted, and the dialog window is closed. The previously active setting is retained.


8.2 Entry via selection field

If a selection field is selected, and then activated by pressing the control knob, then the text (value) can be entered from a previously defined list.



The cursor (position marker) is on the current setting.

- * Make the selection by rotating and pressing the control knob.



8 Entering text and values

8.3 Entering values


8.3.1 Whole numbers (integers)

There are two possibilities for entering integer numbers:


- selection by altering the individual digits of a number, or
- selection by incrementing and decrementing.


Selection by altering the individual digits of a number

For this entry, each digit of the number (units, tens, ...) and the sign are selected with the control knob.




Example

- * Select "2" (the tens digit) by rotating the control knob ()
- * Press the control knob.


The tens digit is now shown in red, to indicate that this digit can now be altered ()

- * Rotate the control knob to alter the tens digits, and then confirm the entry by pressing the control knob.


The tens digit has now been altered, and is shown in blue again ()

Selection by incrementing and decrementing

For this entry, the complete number is reduced by 1 (decremented) or increased by 1 (incremented) with the control knob.



Example

- * Select the hour by rotating the control knob ()
- * Press the control knob.

The number is now shown in red, to indicate that it can now be altered ()

- * Rotate the control knob to alter the number, and then confirm the entry by pressing the control knob.

The number has now been altered, and is shown in blue again ()

8 Entering text and values

8.3.2 Real numbers (floating point)

To enter real numbers (with a decimal point) for each digit of the number (units, tens, ...) the decimal point position and the sign are selected with the control knob.

Sequence

- Position the cursor.
- Enter the number, or define the decimal point position.

For number entry, the number is inserted at the right of the cursor.

Cursor positioning

- * Select "Cursor" and press the control knob.

The real number is indicated by a blue background.

- * Rotate the control knob to move the cursor to the required position, and then press the control knob.




When a number is entered, it is inserted at the right of the cursor.
When deleting, the digit to the left of the cursor is deleted.

Character deletion

- * Position the cursor.
- * Select "Delete" and press the control knob.

The character to the left of the cursor will be deleted.

Set decimal point position | Change sign.



Character to left of cursor is deleted.

To move the cursor within the entry template.

Close entry and reject the text input.

Close entry and confirm the text entered.

Numerics

1-channel presentation 27

A

Alarm and event list 39
Alarm and event lists 14–15, 43
Alarm limits 26–27
Alarm lists 43
Audit trail 52
Average 29

B

Bar graph presentation 23–24, 26
Batches 20, 23–24, 37, 43
 analyze 32
 automatic start 31
 change 30, 32
 edit 30
 manual start 30

C

Change password 53
Channel description 27
Channel name 27
Channel step-on 14–15, 25, 29, 39
Color display 12
Comment entry 23–24, 37
Commissioning 5
CompactFlash 7, 12–13
Configuration 52
Control knob 12
Counters and integrators 23–24, 36
Cursor 39
Curve presentation 23–25

D

Data read-out
 via interface 47
 with a CF memory card 47
Device information 52
Device manager 14–15, 51
Diagram header 14, 28
Digital presentation 24, 28
Display 12
Display off 13

9 Index

Displays and controls *12*
Documentation, arrangement *6*

E

Electrostatic discharge (ESD) *5*
Entering values *59*
Event lists *43*
Event operation *25*

G

Group *37*
Group presentation *27*
Group selection *14–15, 25, 29*
Group step-on *14–15, 25, 29*
Groups *20*

H

Header *13–14*
History *14, 39*

I

Initialization phase *11*
Instrument documentation in printed form *6*
Instrument documentation in the form of PDF files *6*
Introduction *5*

K

Keys *9*

L

Logging in and logging off *52*
Log-in *53*
Log-off *53*

M

MAX value *29*
Memory manager *14–15, 47*
Memory presentation *14–15, 25, 39*
MIN value *29*

N

Normal display *11, 18*
Normal operation *25*
Note signs *8*
Numerical measurement display *13–16, 25, 39*

O

Operating mode *25*
Operator level *14–15, 23*

P

Parameterization *52*
Password *53*
Password management *48*
Power LED *12*
Presentation modes *9*
Process diagram *23–24, 28*

R

Report *23–24, 29*
Report step-on *29*
Returning *5*
Rights *53*

S

Sampling rate *25*
Screen saver *13*
Screen texts *9*
Scroll *39*
Search *39*
Service *52*
Setup plug *13*
Start logo *11*
Status LED *12*
Status line *13, 15*
Symbols *17, 46*

T

Text entry field *55*
Textual presentation *23–24, 27*
Time period *29*
Timed operation *25*
Title line *13, 15*

9 Index

Typographical conventions 8

U

User

logged in 51

User list 48

Users 53

logged off 51

standard password 53

standard user 53

V

Visualization 15, 23

Visualization window 13, 17

W

Warning signs 8

Warranty 5

Writing configuration data to CF card / reading from CF card 48

Z

Zoom 39



JUMO GmbH & Co. KG

Street address:
Moltkestraße 13 - 31
36039 Fulda, Germany
Delivery address:
Mackenrodtstraße 14
36039 Fulda, Germany
Postal address:
36035 Fulda, Germany
Phone: +49 661 6003-0
Fax: +49 661 6003-607
e-mail: mail@jumo.net
Internet: www.jumo.net

JUMO Instrument Co. Ltd.

JUMO House
Temple Bank, Riverway
Harlow, Essex CM20 2TT, UK
Phone: +44 1279 635533
Fax: +44 1279 635262
e-mail: sales@jumo.co.uk
Internet: www.jumo.co.uk

JUMO Process Control, Inc.

8 Technology Boulevard
Canastota, NY 13032, USA
Phone: 315-697-JUMO
1-800-554-JUMO
Fax: 315-697-5867
e-mail: info@jumo.us
Internet: www.jumo.us