

Setpoint Adjuster for Thermostats (606715)

Order details

(1) Basic type	
606715/10	Setpoint adjuster W1/M3x8
606715/80	Setpoint adjuster W8/M3x8
606715/81	Setpoint adjuster W8/M3x6
606715/82	Setpoint adjuster W8/M4x8
(2) Control range 1	
013	-20...+40 °C
021	0 to 50 °C
025	0 to 100 °C
026	0..120°C
027	0...150 °C
028	0...200 °C
041	20 to 90 °C
045	20...400 °C
046	20...500 °C
052	30 to 110 °C
062	50...200 °C
063	50...250 °C
064	50...300 °C

Order code

 (1) / (2)
For orders < EUR 100 a processing fee of EUR 25 applies.


Stock versions

Order code	Basic type	Control range 1	Part no.
606715/10-013/000	Setpoint adjuster W1/M3x8	-20...+40 °C	60002447
606715/10-021/000	Setpoint adjuster W1/M3x8	0 to 50 °C	60002448
606715/10-041/000	Setpoint adjuster W1/M3x8	20 to 90 °C	60002450
606715/10-025/000	Setpoint adjuster W1/M3x8	0 to 100 °C	60002451
606715/10-052/000	Setpoint adjuster W1/M3x8	30 to 110 °C	60002452
606715/10-027/000	Setpoint adjuster W1/M3x8	0...150 °C	60002453
606715/10-028/000	Setpoint adjuster W1/M3x8	0...200 °C	60002454
606715/10-063/000	Setpoint adjuster W1/M3x8	50...250 °C	60002456
606715/10-064/000	Setpoint adjuster W1/M3x8	50...300 °C	60002457
606715/10-045/000	Setpoint adjuster W1/M3x8	20...400 °C	60002111
606715/10-046/000	Setpoint adjuster W1/M3x8	20...500 °C	60002110
606715/80-013/000	Setpoint adjuster W8/M3x8	-20...+40 °C	60002459
606715/80-021/000	Setpoint adjuster W8/M3x8	0 to 50 °C	60002460
606715/80-041/000	Setpoint adjuster W8/M3x8	20 to 90 °C	60002461
606715/80-025/000	Setpoint adjuster W8/M3x8	0 to 100 °C	60002462
606715/80-052/000	Setpoint adjuster W8/M3x8	30 to 110 °C	60002463
606715/80-027/000	Setpoint adjuster W8/M3x8	0...150 °C	60002464
606715/80-028/000	Setpoint adjuster W8/M3x8	0...200 °C	60002465
606715/80-062/000	Setpoint adjuster W8/M3x8	50...200 °C	60002466
606715/80-064/000	Setpoint adjuster W8/M3x8	50...300 °C	60002468
606715/80-045/000	Setpoint adjuster W8/M3x8	20...400 °C	60002116
606715/82-021/000	Setpoint adjuster W8/M4x8	0 to 50 °C	60003090
606715/82-041/000	Setpoint adjuster W8/M4x8	20 to 90 °C	60003091
606715/82-025/000	Setpoint adjuster W8/M4x8	0 to 100 °C	60003092
606715/82-026/000	Setpoint adjuster W8/M4x8	0..120°C	60003227
606715/82-027/000	Setpoint adjuster W8/M4x8	0...150 °C	60003094
606715/82-028/000	Setpoint adjuster W8/M4x8	0...200 °C	60003095
606715/82-063/000	Setpoint adjuster W8/M4x8	50...250 °C	60003097
606715/82-064/000	Setpoint adjuster W8/M4x8	50...300 °C	60003098
606715/82-046/000	Setpoint adjuster W8/M4x8	20...500 °C	60003109