

**Type 202550**  
 $\mu$ P indicator/controller  
for  
analytical measurement

B 20.2550.0  
Operating Instructions

07.08/00403097



---

<b>1</b>	<b>General</b>	<b>6</b>
1.1	Preface	6
<b>2</b>	<b>Typographical conventions</b>	<b>7</b>
2.1	Warning signs	7
2.2	Note signs	7
<b>3</b>	<b>Application</b>	<b>8</b>
3.1	Type 202550	8
3.2	Operating Instructions B 20.2550.0	9
<b>4</b>	<b>Instrument identification</b>	<b>10</b>
4.1	Type designation	11
<b>5</b>	<b>Instrument description</b>	<b>12</b>
5.1	Technical data	12
5.2	Dimensions	16
5.3	Optional accessories	16
<b>6</b>	<b>Assembly</b>	<b>18</b>
6.1	Location	18
6.2	Fitting	18
6.3	Removing the controller module	19
6.4	Cleaning the front panel	19
<b>7</b>	<b>Installation</b>	<b>20</b>
7.1	Electrical connection	20
7.2	Connection diagram	21
<b>8</b>	<b>Commissioning</b>	<b>24</b>
8.1	Self-test	24
<b>9</b>	<b>Operation</b>	<b>25</b>
9.1	Basics	25
9.2	Principle of operation	26
9.3	Operation within levels	27
9.4	General	28
9.5	Programming	29
<b>10</b>	<b>pH indicator</b>	<b>30</b>
10.1	pH measurement circuit	30
10.2	Calibration	30
10.3	Preparation	31
10.4	1-point calibration	32
10.5	2-point calibration	33
<b>11</b>	<b>Operator level of the pH indicator</b>	<b>35</b>
11.1	Settings	35
<b>12</b>	<b>Parameter level of the pH indicator</b>	<b>36</b>
12.1	Settings	36
<b>13</b>	<b>Configuration level of the pH indicator</b>	<b>38</b>
13.1	General	38

---

---

13.2	Analog inputs - C111	38
13.3	Electrode type - C112	39
13.4	Electrode monitoring - C114	39
13.5	nuLL - SLoP	40
13.6	Configuration parameter for general (not pH-specific) functions	40
<b>14</b>	<b>Redox indicator</b>	<b>41</b>
14.1	Redox measurement circuit	41
14.2	Calibration	41
14.3	1-point calibration	43
14.4	2-point calibration	44
<b>15</b>	<b>Operator level of the redox indicator</b>	<b>45</b>
15.1	Settings	45
<b>16</b>	<b>Parameter level of the redox indicator</b>	<b>46</b>
16.1	Settings	46
<b>17</b>	<b>Configuration level of the redox indicator</b>	<b>48</b>
17.1	General	48
17.2	Analog inputs - C111	48
17.3	nuLL - SLoP	49
17.4	Configuration parameter for general (not redox-specific) functions	49
<b>18</b>	<b>Conductivity indicator</b>	<b>50</b>
18.1	Conductivity measurement circuit	50
18.2	Conductivity measurement	50
18.3	Measurement with manual temperature compensation	51
18.4	Manual temperature entry	52
18.5	Measurement with automatic temperature compensation	52
18.6	Calibration	53
18.7	<b>Calibrating the relative cell constant</b>	<b>55</b>
18.8	Calibrating the temperature coefficient	57
<b>19</b>	<b>Operator level of the conductivity indicator</b>	<b>60</b>
19.1	Settings	60
<b>20</b>	<b>Parameter level of the conductivity indicator</b>	<b>61</b>
20.1	Settings	61
<b>21</b>	<b>Configuration level of the conductivity indicator</b>	<b>63</b>
21.1	General	63
21.2	Analog inputs - C111	63
21.3	Process value output for conductivity - C311	64
21.4	rAnG - CELL - ALPH	64
21.5	Configuration parameter for general (not conductivity-specific) functions	65
<b>22</b>	<b>Universal indicator</b>	<b>66</b>
22.1	Measurement circuit for the universal indicator	66
22.2	Display range / select application	66
22.3	Calibration	67
22.4	“Zero point” for 1-point calibration	69
22.5	“End value” for 1-point calibration	69

---

---

22.6	<b>2-point calibration</b>	70
<b>23</b>	<b>Operator level of the universal indicator</b>	<b>71</b>
23.1	Settings	71
<b>24</b>	<b>Parameter level of the universal indicator</b>	<b>72</b>
24.1	Settings	72
<b>25</b>	<b>Configuration level of the universal indicator</b>	<b>74</b>
25.1	General	74
25.2	Analog inputs - C111	74
25.3	Configuration parameter for general functions (not specific to the universal indicator)	75
25.4	nuLL - SLoP - SiL - SiH	75
<b>26</b>	<b>Configuration level (not instrument-specific)</b>	<b>76</b>
26.1	General	76
26.2	Logic inputs... - C112	76
26.3	Serial interface... - C113	77
26.4	Controller options - C211	78
26.5	Controller outputs - C212	79
26.6	Other outputs I - C213	80
26.7	Other outputs II - C214	81
26.8	Response for HOLD / Overrange - C215	82
26.2	SoL - SoH - SPL - SPH - OFFS - SiL - SiH	83
<b>27</b>	<b>Controller</b>	<b>85</b>
27.1	Configuration	85
27.2	Controller optimization	87
<b>28</b>	<b>Manual operation</b>	<b>88</b>
28.1	Manual operation for outputs K1, K2 or K3	88
28.2	Simulated process value output	89
<b>29</b>	<b>Hold</b>	<b>90</b>
29.1	Hold controller	90
<b>30</b>	<b>Version</b>	<b>91</b>
30.1	Display software version and temperature unit	91
<b>31</b>	<b>Logic inputs</b>	<b>92</b>
31.1	Functions	92
<b>32</b>	<b>Interface</b>	<b>93</b>
32.1	MODbus /Jbus	93
32.2	Profibus-DP	94
<b>33</b>	<b>Glossary</b>	<b>95</b>
<b>34</b>	<b>Warnings – Errors</b>	<b>103</b>
34.1	Messages	103
<b>35</b>	<b>Appendix</b>	<b>105</b>
35.1	Programming the controller	105

---

# 1 General

---

## 1.1 Preface

Please read these Operating Instructions before commissioning the instrument. Keep the manual in a place that is accessible to all users at all times.

Please assist us to improve these operating instructions, where necessary.

Your suggestions will be welcome.

Phone +49 661 6003-0

Fax +49 661 6003-607



All necessary settings are described in this manual. However, if any difficulties should still arise during start-up, please do not carry out any unauthorized manipulations on the instrument. You could endanger your rights under the instrument warranty!

Please contact the nearest subsidiary or the main factory in such a case.



When returning modules, assemblies or components, the rules of EN 100 015 "Protection of electrostatically sensitive components" must be observed. Use only the appropriate **ESD** packaging for transport.

Please note that we cannot accept any liability for damage caused by ESD (electrostatic discharge).

---

## 2 Typographical conventions

---

### 2.1 Warning signs



#### Danger

This symbol is used when there may be **danger to personnel** if the instructions are ignored or not followed correctly!



#### Caution

This symbol is used when there may be **damage to equipment or data** if the instructions are ignored or not followed correctly!

### 2.2 Note signs



#### Note

This symbol is used when your **special attention** is drawn to a remark.

*see abcd*

#### Reference

The cursive (italic) text refers to **further information** in other chapters or sections.

abc<sup>1</sup>

#### Footnote

Footnotes are remarks that **refer to specific points** in the text. Footnotes consist of two parts:

A marker in the text, and the footnote text.

The markers in the text are arranged as continuous superscript numbers.

\*


#### Action


This symbol indicates that an **action to be performed** is described.

The individual steps are marked by this asterisk.


Example:

\* Remove crosspoint screws.

\* Press the  key.



#### Key combinations

If key symbols are shown connected by a plus sign, this means: first press and hold down the  key, and then press the next key.

## 3 Application

---

### 3.1 Type 202550

**Description** The compact microprocessor indicator/controller, with 96mm x 48mm bezel and plug-in controller module visualizes and controls variables in analytical measurement (pH value, redox voltage, conductivity, chlorine, chlorine dioxide, ozone and mA).

**Inputs** The indicator has two analog and two logic inputs.  
The first analog input is suitable for connecting a 0(4) – 20 mA signal, which can be provided by any type of transmitter (including 2-wire types). The input signal is conditioned as determined by the configuration, and displayed.  
The second analog input can be used to connect Pt100 or Pt1000 resistance thermometers.

**Calibration procedure** One special feature of the instrument is that the calibration procedures for pH, redox and conductivity are internally programmed. This permits the connection of simple transmitters (without their own calibration facilities) to the dTRANS Az 01. In this case, the indicator/controller has to be configured accordingly.

Examples of simple transmitters:

- for pH JUMO type 202701
- for redox voltage JUMO type 202702
- for conductivity JUMO type 202754/xx-xxx/263

**Standard signals** The dTRANS Az 01 is also suitable for the connection of transmitters that produce a standard output signal. In this case, the dTRANS Az 01 must be configured as a universal indicator.

Examples of JUMO transmitters with standard output signals:

- for dissolved oxygen JUMO dTRANS O2 01
- for free chlorine, chlorine dioxide and ozone JUMO Typ 202630
- JUMO pressure transmitters

**Display** The instrument features two 4-digit 7-segment displays for indicating the main variable (red) and the temperature (green). The temperature display is switched off in the default setting. A separate temperature sensor (Pt100 or Pt1000) can be connected to the second analog input. This can then be used to display the temperature of the medium and, if required, monitor it by means of a limit comparator (limit switch). During programming, the displays provide comments on the inputs.

**Outputs** The instrument has a maximum of 5 outputs

Out-put	Stand-ard	Description / configurable	Output
K1	yes	Controller / controller off, limit controller, pulse width controller, pulse frequency controller, modulating controller with P, PI, PD or PID action	relay, make

## 3 Application

---

K2	yes	Controller / controller off, limit controller, pulse width controller, pulse frequency controller, modulating controller with P, PI, PD or PID action	relay, make
K3	option	Analog output / proportional controller	-- / analog
K3	option	Limit comparator	relay, changeover contact
K4	yes	Logic output	0/5 V 0/12V
K5	option	Analog output / proportional controller	-- / analog
K5	option	Limit comparator	relay, changeover contact
K5	option	Serial interface / Profibus-DP or MODbus/Jbus	RS422 / RS485

### Interface

A MODbus/Jbus (RS422 / RS485) or Profibus-DP interface can be supplied as an option, for integrating the instrument into a data network.

The instrument can also be delivered with a power supply for a 2-wire transmitter in place of the interface board.

---

## 3.2 Operating Instructions B 20.2550.0

These operating instructions provide full instructions on the installation, electrical connection, commissioning, operation, parameter setting and configuration of the microprocessor indicator/controller for analytical measurement, type 202550.

### Layout of the operating instructions

These operating instructions are arranged as follows:

- 1) General information  
(applies to the indicator/controller, **regardless** of the application)
  - 2) Description of the
    - Operation
    - Parameterization
    - Configurationof the indicator/controller, **specially** for a specific application (pH, redox, conductivity, chlorine, chlorine dioxide, ozone, or general mA signals)
  - 3) Description of the controller functions  
(applies to the indicator/controller, **regardless** of the application)
  - 4) Description of the
    - Configurationof the indicator/controller, **regardless** of the application
  - 5) - Glossary
    - Warnings / Errors
    - Appendix**regardless** of the application
-

## 4 Instrument identification

---


### Check for completeness

You should have received at least the following:

- Indicator/controller for analytical measurement, Type 202550
- 2 mounting brackets
- Seal (housing/panel)
- Operating Instructions B 20.2550.0

### Nameplate

The nameplate is glued to the housing.



Explanation of the type designation (1)

⇒ Chapter 4.1 “Type designation”, page 11.

The type designation (1) contains all the factory settings, such as the controller function, the measurement inputs and extra codes. The extra codes are listed in sequence and separated by commas.



The supply voltage must correspond to the voltage given on the nameplate (2).

## 4 Instrument identification

### 4.1 Type designation

	<b>(1) Basic type</b>
202550	JUMO dTRANS Az 01 Microprocessor indicator/controller for analytical measurement
	<b>(2) Basic type extensions</b>
00	controller off <sup>1</sup>
10	limit controller <sup>1</sup>
	<b>(3) Input</b>
660	0/4 – 20 mA front-panel print: pH and mV, °C
661	0/4 – 20 mA front-panel print: mV, °C
662	0/4 – 20 mA front-panel print: mS/cm and µS/cm, °C
664	0/4 – 20 mA front-panel print: none, °C
665	0/4 – 20 mA front-panel print: mg/l, °C
	<b>(4) Output I</b>
000	no output
140	supply for 2-wire transmitter
310	relay, changeover contact
888	process value output, freely configurable
	<b>(5) Output II</b>
000	no output or interface
140	supply for 2-wire transmitter <sup>2</sup>
310	relay, changeover contact <sup>2</sup>
888	process value output, freely configurable <sup>2</sup>
	<b>(6) Supply voltage</b>
22	20 – 53 V AC/DC ±0%, 48 – 63/0 Hz
23	110 – 240 V AC +10%/-15%, 48 – 63 Hz
	<b>(7) Interface</b>
00	no interface
54	serial interface RS422/485 <sup>2</sup>
64	serial interface Profibus-DP <sup>2</sup>
	<b>(8) Extra codes</b>
000	none
015	logic output 0/12 V DC, instead of standard 0/5 V DC

#### Order example

(1) (2) (3) (4) (5)<sup>2</sup> (6) (7)<sup>2</sup> (8)  
202550/  -  ,  ,  -  -  /

<sup>1</sup> **Generally**, the following configurations can be freely selected by the user on **all** instruments of the 202550 series:

- Controller off
- Limit controller
- Pulse width controller with P, PI, PD, PID control action
- Pulse frequency controller with P, PI, PD, PID control action
- Modulating controller

<sup>2</sup> If output II (4) = “140”, “310” or “888”, then the interface option (6) “54” or “64” is not possible (or the other way round).

# 5 Instrument description

---

## 5.1 Technical data

---

<b>Analog input 1</b>	Input resistance approx. 40Ω Deviation from characteristic: ≤ 0.5% of the measurement range 0(4) — 20 mA.
<b>Analog input 2</b>	Pt100 or Pt1000 resistance thermometer, in 2-wire or 3-wire circuit, -50 to +250•C Measurement display in •C or •F (option) Deviation from characteristic: ≤ 0.25% of measurement range. Ambient temperature error: ≤ 0.1% per 10 •C
<b>Lead compensation, analog input 2</b>	The lead resistance can be compensated in software by a correction of the process value. This is not required if the resistance thermometer is connected in a 3-wire circuit. Alternatively, when a resistance thermometer is connected in a 2-wire circuit, lead compensation can be provided by using an external compensation resistor.
<b>Logic input 1</b>	The following functions can be assigned as selected: Key inhibit, setpoint switching, alarm stop, alarm time reset, hold, reverse hold, freeze measurement, range expansion (x10), no function for logic input 1.
<b>Logic input 2</b>	As for logic input 1.
<b>Measurement and control range</b>	<u>Current</u> 0(4) — 20 mA <u>pH value</u> -1.00 to 14.00 pH <u>Redox voltage</u> -1999 to +1999 mV <u>Conductivity</u> 0 — 9999 mS/cm or μS/cm 0 — 9.999 mS/cm or μS/cm 0 — 99.99 mS/cm or μS/cm 0 — 999.9 mS/cm or μS/cm <u>Free chlorine, chlorine dioxide, ozone</u> -1999 to +9999 mg/l -1.999 to +9.999 mg/l -19.99 to +99.99 mg/l -199.9 to +999.9 mg/l <u>Universal display</u> -1999 to +9999 digit -1.999 to +9.999 digit -19.99 to +99.99 digit -199.9 to +999.9 digit

---

## 5 Instrument description

---

<b>Reference temperature</b>	25°C (for conductivity indicator/controller)
<b>Deviation from characteristic</b>	≤ 0.15% of measurement range
<b>Temperature display</b>	-50 to +250•C (option •F)
<b>Outputs</b>	5 outputs are available:
<b>Output 1 / 2 relay (standard)</b>	Make contact (can also be configured as break contact) Contact rating: 3A, 250V AC, with resistive load Contact life: > 5x10 <sup>5</sup> operations at rated load Status indication: relay K1 => LED K1; relay K2 => LED K2
<b>Output 4 logic output (standard)</b>	0/5V (standard) $R_{load} \geq 250\Omega$ 0/12V (option) $R_{load} \geq 650\Omega$ Status indication: LED K4
<b>Output 3 or output 5 process value output (option)</b>	Can be used as analog process value output or as proportional controller. 0(2) – 10V $R_{load} \geq 500\Omega$ 0(4) – 20mA $R_{load} \leq 500\Omega$ electrically isolated from the inputs: $\Delta u \leq 30V$ AC $\Delta u \leq 50V$ DC
<b>Output 3 or output 5 relay (option)</b>	(changeover contact) Contact rating: 3A, 250V AC, with resistive load Contact life: > 5x10 <sup>5</sup> operations at rated load Status indication: K3 => LED K3; K5 => no visible indication
<b>Output 5, interface RS422 / RS485 (option)</b>	electrically isolated; baud rate: 4800 / 9600bps; Protocol: MODbus/Jbus or Profibus-DP

---

## 5 Instrument description

---

### 5.1.1 General controller data

---

<b>A/D converter</b>	resolution > 15 bit
<b>Controller type</b>	Output 1 and output 2: limit controller and/or pulse width or pulse frequency controller, or modulating controller, freely configurable and selectable. K3 / K5: proportional controller
<b>Control action</b>	P, PI, PID or PD, freely configurable and selectable
<b>Sampling time</b>	210 msec
<b>Meas. circuit monitoring</b>	Input 1: out-of-range, sensor monitoring Input 2: out-of-range, probe short-circuit, probe break The outputs move to a defined (configurable) status.
<b>Data backup</b>	EEPROM
<b>Supply voltage</b>	110 — 240 V AC +10%/-15%, 48 — 63 Hz or 20 — 53 V AC/DC ±0%, 48 — 63/0 Hz
<b>Power consumption</b>	approx. 8VA
<b>Electrical connection</b>	via gold-plated faston connectors to DIN 46 244/A; 4.8mm x 0.8mm
<b>Permissible ambient temperature</b>	0 to +50°C
<b>Permissible ambient temperature limits</b>	-10 to +55°C
<b>Permissible storage temperature</b>	-40 to +70°C
<b>Climatic conditions</b>	rel. humidity ≤ 75 %, no condensation
<b>Enclosure protection</b>	to EN 60 529, front IP65 / back IP20

---

## 5 Instrument description

---


<b>Electrical safety</b>	to EN 61 010, clearance and creepage distances for - overvoltage category II - pollution degree 2
<b>Electro-magnetic compatibility (EMC)</b>	to EN 61 326
<b>Housing</b>	panel-mounting housing in conductive plastic to DIN 43 700, base material ABS, with plug-in controller module
<b>Operating position</b>	unrestricted
<b>Weight</b>	approx. 320g

---

# 5 Instrument description


## 5.2 Dimensions

Type 202550/...



## 5.3 Optional accessories

Additional housing, no door at front, enclosure IP65, Type 2FGE-125-2/125




### Restricted external temperature range!

The ambient temperature for the surface-mounting housing must not exceed 45°C.

## 5 Instrument description

### Additional housing, door at front, enclosure IP65, Type 2FGE-150-2/185



#### Restricted external temperature range!

The ambient temperature for the surface-mounting housing must not exceed 45°C.

# 6 Assembly

---


## 6.1 Location

### Conditions

The location should be as free from vibration as possible. Electromagnetic fields, e. g. from motors, transformers etc. should be avoided. The ambient temperature at the location can be from 0 to 50 °C, with a relative humidity of not more than 75 %.


---

### Panel cut-out for close mounting




## 6.2 Fitting

---



- \* Fit the seal (1) that is supplied onto the body of the instrument.
  - \* Insert the controller from the front into the panel cut-out.
  - \* From behind the panel, slide the mounting brackets into the guides on the sides of the housing. The flat faces of the mounting brackets must lie against the housing.
  - \* Push the mounting brackets up to the back of the panel, and tighten them evenly with a screwdriver.
-

### 6.3 Removing the controller module



The controller module can be removed from its housing for servicing.

- \* Press together the ribbed surfaces at right and left and pull the controller module out of the housing.
- 

### 6.4 Cleaning the front panel

The front panel can be cleaned with normal commercial washing, rinsing and cleaning agents.

It has a limited resistance to organic solvents (e.g. methylated spirits, white spirit, P1, xylol etc.).



Do not use high-pressure cleaning equipment!

---

# 7 Installation

---

## 7.1 Electrical connection

---



**The electrical connection may only be carried out by properly qualified personnel**

---

- The choice of cable, the installation and the electrical connection must conform to the requirements of VDE 0100 “Regulations on the Installation of Power Circuits with Nominal Voltages below 1000 V” or the appropriate local regulations.
  - The electrical connection may only be carried out by properly qualified personnel.
  - The instrument must be completely disconnected from the electrical supply if contact with live parts is possible.
  - A current-limiting resistor interrupts the supply circuit in the event of a short-circuit. Any additional external fusing of the supply should not be rated below 1A (slow).
  - The load must be fused for the maximum relay current, in order to prevent the contacts of the output relay becoming welded in the event of a short-circuit.
  - The level of electromagnetic compatibility conforms to EN 61 326.
  - Run input, output and supply cables separately, not parallel to one another.
  - Sensor and interface cables should be shielded cables with twisted conductors. Do not run them close to current-carrying components or cables. Ground shielding at one end, to the TE terminal on the instrument.
  - The TE terminal on the instrument must be earthed. This lead must have at least the same conductor cross-section as that used for the supply cables. Grounding and earthing leads must be wired in a star configuration to a common earth point that is connected to the protective earth of the electrical supply. Do not loop earth or ground connections, i.e. do not run them from one instrument to another.
  - Do not connect any additional loads to the supply terminals of the instrument.
  - The instrument is not suitable for use in areas with an explosion hazard (Ex areas).
  - In addition to faulty installation, incorrect settings on the controller (setpoint, data of the parameter and configuration levels, internal alterations) can also interfere with the correct operation of dependent processes, or even cause damage. The stability of the actual value that is produced should therefore be checked. Safety devices should always be provided that are independent of the controller (such as overpressure valves or temperature monitors/limiters) and only capable of adjustment by specialist personnel. Please observe the relevant safety regulations for such matters.
  - The measurement inputs of the controller must not exceed a maximum potential of 30 V AC or 50 V DC against TE.
  - Sensor leads should only be implemented as uninterrupted cables (**not** routed through terminal strips etc.).
  - If frequent relay switching is expected (> 5/min), the system must be fitted with appropriate suppressor devices against switching interference.
-




After the supply voltage has been applied, the instrument will operate according to the factory-set parameters (unless the instrument was ordered with “controller off”).

It is therefore advisable to program the instrument as required **before connecting the actuators.**





⇒ Chapter 9 “Operation”, page 25ff.




## 7.2 Connection diagram









Outputs	K	Terminal assignments	Symbol
Relay 1 (K1) Status indication LED K1	1	23 common 22 make	
Relay 2 (K2) Status indication LED K2	2	21 common 20 make	
Relay 3 (K3) Status indication LED K3	3	16 break 15 common 14 make	
<b>or</b> process value output (electrically isolated)		15 - 14 +	

# 7 Installation

Outputs	K	Terminal assignments	Symbol
Supply for 2-wire transmitter	3	15 + 14 -	
Logic output 1 (K4) Status indication LED K4	4	19 - 17 +	
Supply for 2-wire transmitter	5	3 + 2 -	
Relay 4 (K5)  <b>or</b> process value output (electrically isolated)	5	3 break 2 common 1 make  2 - 1 +	

Inputs		Terminal assignments	Symbol
Input for standard signal Ix (0(4) – 20 mA)		7 - 8 +	
Resistance thermometer in 3-wire circuit	9 10 11		
Resistance thermometer in 2-wire circuit	10 9 11		

## 7 Installation

Inputs/outputs		Terminal assignments		Symbol
Serial interface RS422 (option)	RxD	5	RxD +	Receive data 
		4	RxD -	
	TxD	2	TxD +	
	1	TxD -		
GND	3	GND		
Serial interface RS485 (option)	+	2	TxD/RxD +	
	-	1	TxD/RxD -	
	GND	3	GND	
Serial interface Profibus-DP (option)	VP	4	supply voltage plus, (P5V)	
	RxD/TxD-P	1	receive/transmit data positive, B conductor	
	RxD/TxD-N	2	receive/transmit data negative, A conductor	
	DGND	3	ground for data transmission	
Logic input 1		13		
		19		
Logic input 2		12		
		19		
Supply voltage see nameplate	AC/ DC	AC: L1 phase N neutral TE technical earth	DC: L + L -	

# 8 Commissioning

---

## 8.1 Self-test



---

After the supply voltage has been applied, the instrument will operate according to the factory-set parameters.  
(unless the instrument was ordered with “controller off”)

It is therefore advisable to program the instrument as required **before connecting the actuators.**

⇒ Chapter 9 “Operation”, page 25.

---

**After the supply voltage has been applied,**

the instrument performs a self-test, during which all displays will light up.

---

**OK**

If the self-test was OK, then the instrument switches over to the measurement mode in about 10 seconds.

The measured current signal (proportional to the measured value) is displayed, as is the measured temperature (if the temperature sensor has been connected and configured); the controller operates according to the factory-set parameters!

In measurement mode, manual operation, hold, and calibration can be activated, as well as the display of the software revision level and the dimensional unit (•C /•F) for the temperature input.

---


**Error**

If an error code (e.g. F010) or “Err” is displayed,  
⇒ Chapter 34 “Warnings – Errors”, page 103ff.

---

## 9.1 Basics

### Displays and keys



<sup>1</sup> LED K3 has no function if the instrument was ordered with process value output (output "888") or with a power supply for a 2-wire transmitter (output "140").

# 9 Operation

---

## 9.2 Principle of operation

### Operating modes and states

---

Measurement mode (normal operation)	The process value and temperature are displayed.
Self-test (after power-on)	All indicators light up; the temperature display blinks.
Manual mode	The process value display continually switches between the process value and the text "HAnd", the temperature is displayed.
Hold operation	The process value display continually switches between the process value and the text "HoLd", the temperature is displayed.
Operation, parameters, configuration	The temperature display shows the parameters from the various levels; the process value display shows the corresponding values and codes.
Error	The temperature display continually switches between the temperature and the error code (e.g. F010), ⇒ Chapter 34 "Warnings – Errors", page 103ff.

---

### Levels

The instrument functions are arranged in four levels (see diagram on next page):

- Measurement mode
  - Operating level
  - Parameter level
  - Configuration level
- 

### Measurement mode<sup>1</sup> (normal operation)

The measurements are displayed at this level. Manual operation, hold and calibration can be activated.

---

### Operating level<sup>1</sup>

Setpoints, alarm tolerance, alarm delay and the limits for the limit comparators are entered and displayed at this level.

---

### Parameter level<sup>1</sup>

Controller parameters and other settings are programmed here. The display of the individual parameters depends on the type of controller action.

---

### Configuration level<sup>1</sup>


The basic functions of the instrument are configured at this level.

---

<sup>1</sup> Entries can only be made after the correct code word has been entered.  
⇒ "Unlocking the levels", page 29.

---

## 9.3 Operation within levels



<sup>1</sup> A change of level can only take place after stepping through all the parameters of the level concerned.

# 9 Operation

---

## 9.4 General


---



### Level protection



Changes at the operating level, parameter level and configuration level can only be made after entering a code word,  
⇒ “Unlocking the levels”, page 29.

The code word has been entered correctly if the decimal point in the temperature display starts to blink when a parameter has been selected for modification.

Within a level, you can step on to the next parameter by pressing the  key.




### Cancel

You can change back to the measurement mode at any time, by pressing the  key. For parameters that have been altered, but **not** confirmed by , the changes will **not** be accepted.





### Time-out

The controller will automatically return to the measurement mode if no operation occurs for about 50 seconds. For parameters that have been altered, but **not** confirmed by , the changes will **not** be accepted.

**Exception:** Time-out does not apply during calibration!


### Entering parameters

The entry and modification of parameters and setpoints is made continuously. The value changes at a faster rate if the key is kept pressed for a longer time.

- \* Increase the value with 
- \* Decrease the value with 






The value is only altered within the permissible range of values.

- \* Accept the entry with  – the upper display “winks” to confirm it (the display switches off briefly)


or

- \* cancel with 

### Entering a configuration parameter or code word

- \* Select the digit with  (digit blinks).
- \* Alter the code, with 
- \* Accept the change with  – the upper display “winks” to confirm it (the display switches off briefly)

or

- \* cancel with 

## 9.5 Programming

### Procedure

The following procedure is recommended to avoid a “time-out” (50 seconds without an action) while entering data:

- \* Fold out the last page of these operating instructions  
     ⇒ Chapter 35.1 “Programming the controller”, page 105ff.
- \* Enter all the codes and parameters to be changed in the table
- \* Unlock all the affected levels, see below
- \* Program all the settings right through from top to bottom, in one session
- \* Inhibit all the levels, see below






Depending on the type of controller that is configured, some parameters cannot be set and will therefore not be displayed.

After changing the controller type (C211), the controller parameters must be checked.


⇒ Chapter 20.1 “Settings”, page 61ff.

### Unlocking the levels

Initial condition: The instrument is in the measurement mode.

- \* Press the  briefly and repeatedly, until “CodE” appears in the lower display.
- \* Use the  and  keys to set the required code.

Function	Code word <sup>1</sup>
Enable operating level, CAL, and manual activation of “hold”	0110
Enable operating and parameter levels	0020
Enable all levels	0300
Activate edit protection	xxxx <sup>2</sup>

- \* Press the  key (confirmation) – “0000” appears in the display

The code word has been entered correctly if the decimal point in the temperature display starts to blink when a parameter has been selected for modification.



<sup>1</sup> Code word 0020 includes 0110; code word 0300 includes 0020 and 0110.

<sup>2</sup> The relevant levels remain enabled until the edit protection is reactivated, either by entering a “wrong” code word (other than 0000) or the supply voltage to the instrument is switched off and then on again.

# 10 pH indicator

---

## 10.1 pH measurement circuit


The JUMO dTRANS Az 01 indicator/controller (1) requires a standard input signal (0(4) – 20 mA) that is proportional to the pH.

The 2-wire pH transmitter (2) provides this standard signal.

The pH combination electrode (3) is connected to the 2-wire pH transmitter (2), which in its turn is connected to the JUMO dTRANS Az 01 (1). A temperature probe (4) can be connected to the indicator/controller as an option. This temperature probe can be used to measure the temperature of the liquid. The dTRANS Az 01 can indicate this temperature, control it, and/or use it for temperature compensation of the pH value.

As a further option, the JUMO dTRANS Az can supply the voltage for the 2-wire transmitter.

### Example



A combination of:



- (1) JUMO dTRANS Az 01, (configured as a pH indicator, **rAnG 21**)
  - (2) JUMO 202701 (2-wire transmitter for pH)
  - (3) pH combination electrode
  - (4) optional temperature probe (Pt100 or Pt1000)
- 

## 10.2 Calibration





### Calibration options

The electrode parameters of a pH combination electrode are subject to manufacturing tolerances and variations depending on usage. To compensate for these changing electrode parameters, the indicator/controller offers two calibration procedures:

---



<b>1-point calibration</b>	<p>In 1-point calibration, <b>only the electrode zero</b> is freshly determined using a buffer solution (solution with a known pH value).          Problems arising from an incorrect electrode slope will not be detected by the user!          This method should only be adopted in cases where the electrode is not subject to significant chemical and mechanical influences.</p>
<b>2-point calibration</b>	<p>2-point calibration makes a fresh determination of the <b>electrode zero and slope</b> using two buffer solutions.          This method should be given preference!</p>
<b>Manual entry</b>	<p>In addition to the calibration procedure described above, the indicator/controller offers the facility of manually entering the zero point and slope (as determined by a laboratory, for example).</p>
<b>Temperature</b>	<p>The measurement of the pH value depends on temperature; the temperature of the solution to be measured must therefore be known for calibration. The temperature can either be measured automatically, with a Pt100 or Pt1000 temperature probe, or set manually by the user.</p>
	<p><b>Cancel</b>          You can change back to the measurement mode at any time, by pressing the  key.</p>

## 10.3 Preparation

<b>Preparation for calibration</b>	<p>Before the <u>first</u> calibration, the following has to be determined:</p> <ul style="list-style-type: none"> <li>- the type of temperature acquisition during calibration</li> <li>- the calibration procedure (1-point or 2-point calibration)</li> <li>- process value output is frozen or not during calibration</li> </ul>																				
	<p>If subsequent calibrations are carried out with the same settings, the parameters mentioned above will not have to be reconfigured.</p>																				
<b>Select type of temperature acquisition</b>	<p>The instrument is in the measurement mode.</p> <ul style="list-style-type: none"> <li>* Unlock the configuration level, if necessary,              ⇨ “Unlocking the levels”, page 29, (code word 0300).</li> <li>* Press the  key twice, for more than 2 seconds, to access the configuration level.              The lower display shows “C111”.</li> </ul> <p>Use the  and  keys to set the configuration parameter:</p>																				
<table border="1"> <tr> <td>Type of temperature acquisition</td> <td>X</td> <td>X</td> <td>X</td> <td>0</td> </tr> <tr> <td>Manual temperature compensation</td> <td></td> <td></td> <td></td> <td>0</td> </tr> <tr> <td>Automatic temperature compensation with Pt100</td> <td></td> <td></td> <td></td> <td>1</td> </tr> <tr> <td>Automatic temperature compensation with Pt1000</td> <td></td> <td></td> <td></td> <td>2</td> </tr> </table>		Type of temperature acquisition	X	X	X	0	Manual temperature compensation				0	Automatic temperature compensation with Pt100				1	Automatic temperature compensation with Pt1000				2
Type of temperature acquisition	X	X	X	0																	
Manual temperature compensation				0																	
Automatic temperature compensation with Pt100				1																	
Automatic temperature compensation with Pt1000				2																	

# 10 pH indicator


---

- \* Press the  key (confirmation)
- \* Press the  key (return to the measurement mode).

## Calibration with / without “frozen process value output”

“Freezing” the process value output means that, during calibration, the output signal is held at the value that was produced immediately before calibration started. This is to avoid an uncontrolled reaction from any PLC that may be connected to the output of the indicator/controller.


While the process value output is frozen, the lower display shows “donE” after the last calibration step, and the upper display shows the latest measurement. The process value output remains unchanged!

After the electrode has been installed once more, the  key must be pressed again. The process value output is now coupled to the display again.





The factory setting is: “Calibration without frozen process value output”.

## Select calibration procedure

- \* Press the  key repeatedly, until “C211” appears in the lower display.

Use the  and  keys to set the configuration parameter:

Calibration procedure	X	X	0	X
1-point calibration, process value output not frozen			0	
1-point calibration, process value output frozen			1	
2-point calibration, process value output not frozen			2	
2-point calibration, process value output frozen			3	

- \* Press the  key (confirmation)
- \* Press the  key (return to the measurement mode).

## 10.4 1-point calibration

### You will need

- a buffer solution with a pH value which roughly corresponds to the medium measured later.
- a thermometer, if you want to use manual temperature compensation.
- a Pt100 or Pt1000 temperature probe, if you require automatic temperature compensation.

### Initial condition

A pH combination electrode connected to the 2-wire transmitter that is attached to the dTRANS Az 01, as well as a Pt100 or Pt1000 temperature probe (if required),

⇒ Chapter 10.1 “pH measurement circuit”, page 30ff.

Select calibration procedure,

⇒ Chapter 10.3 “Preparation”, page 31ff.









The operating level is unlocked,

⇒ “Unlocking the levels”, page 29, (code word 0110)

The instrument is in the measurement mode,  
⇒ “Operating modes and states”, page 26.

---

## Calibration

- \* Press the  +  (Cal) keys  
The lower display shows “•C”.  
If the decimal point flashes, manual temperature acquisition is configured.
  - \* Immerse the pH electrode and, if needed, the temperature probe in the buffer solution.
  - \* Set the temperature of the buffer solution with the  or  keys.
  - \* If the decimal point does not flash, then automatic temperature acquisition is configured
  - \* Wait until the temperature reading has stabilized.
  - \* Press the  key.  
The lower display shows “Cal1” with the decimal point flashing.
  - \* When the pH value display has stabilized, set the displayed value to the value of the reference buffer using the  or  keys.
  - \* Press the  key.  
The instrument stores the new zero.  
The instrument is in the measurement mode again.
- 



If, on completion of calibration, the instrument shows “Err” in the temperature display,  
⇒ Chapter 34.1 “Messages”, page 103ff.

---

## 10.5 2-point calibration

### You will need

- a buffer solution, pH 7, for example
  - a buffer solution with a pH value that differs from the first buffer solution by **at least 2 pH**, for instance pH 10.  
Both buffer solutions must have the same temperature.
  - a thermometer, if you want to use manual temperature compensation for calibration.
  - a Pt100 or Pt1000 temperature probe, if you want to calibrate with automatic temperature compensation.
- 

### Initial condition

A pH combination electrode connected to the 2-wire transmitter that is attached to the dTRANS Az 01, as well as a Pt100 or Pt1000 temperature probe (if required),  
⇒ Chapter 10.1 “pH measurement circuit”, page 30ff.

Select calibration procedure,  
⇒ Chapter 10.3 “Preparation”, page 31ff.

The operating level is unlocked,  
⇒ “Unlocking the levels”, page 29, (code word 0110)












The instrument is in the measurement mode, see “Operation / Basics / Operating modes and states”, page 20.

---

# 10 pH indicator

---

## Calibration

- \* Press the  +  (Cal) keys  
The lower display shows “•C”.  
If the decimal point flashes, manual temperature acquisition is configured.
- \* Immerse the pH electrode and, if needed, the Pt100 or Pt1000 temperature probe in the first buffer solution (pH 7).
- \* With manual temperature acquisition, set the temperature of the buffer solution using the  or  keys.
- \* If the decimal point does not flash, then automatic temperature acquisition is configured
- \* Wait until the temperature reading has stabilized.
- \* Press the  key.  
The lower display shows “Cal1” with the decimal point flashing.
- \* When the pH value display has stabilized, use the  or  keys to set the displayed value to the value of the first reference buffer.
- \* Press the  key.  
The lower display shows “Cal2” with the decimal point flashing.
- \* Take the pH electrode and, if necessary, the temperature probe out of the first buffer solution and rinse with water.
- \* Immerse the pH electrode and, if required, the Pt100 or Pt1000 temperature probe in the second buffer solution.
- \* When the pH value display has stabilized, use the  or  keys to set the displayed value to the value of the second reference buffer.
- \* Press the  key.  
The instrument stores the new zero and the new slope.  
The instrument is in the measurement mode again.



If, on completion of calibration, the instrument shows “Err” in the temperature display,  
⇒ Chapter 34.1 “Messages”, page 103ff.

---

# 11 Operator level of the pH indicator

## 11.1 Settings

### Pre-conditions

How to access the operating level, or leave this level,  
 ⇨ Chapter 9.2 “Principle of operation”, page 26ff.

The operating level must be unlocked,  
 ⇨ “Unlocking the levels”, page 29, (code word 0110).



It is possible that not all of the following parameters are needed or displayed, depending on the configuration of the controller functions.



For an explanation of the terminology used,  
 ⇨ Chapter 33 “Glossary”, page 95ff.

How to configure controllers,  
 ⇨ Chapter 27.1 “Configuration”, page 85ff.

Designation	Parameter (display)	Value range	Factory setting	displayed if ... is configured	see Configuration parameter
Setpoint 1	SP(r)1	-1.00 to 14.00 pH	-1.00	K1	C211
Setpoint 2	SP(r)2		14.00	K2	
Setpoint 3	SP(r)3		-1.00	Setpoint changeover	C112
Setpoint 4	SP(r)4		14.00		
Code word	CodE	4-digit	0000		
Limit SP A (K1)	SP A	-1.00 to 14.00 pH or -50 to 250°C	-1.00	K1	C214
Limit SP b (K2)	SP b			K2	
Limit SP C (K3)	SP C			K3	C113
Limit SP d (K4)	SP d			K4	
Limit SP E (K5)	SP E			K5	C214
Temperature for compensation (manually adjustable or automatic, depending on the configuration)	InP2	(•C)	25		C111
Alarm tolerance	AL1	0.00 to 99.99 pH	0	Controller alarm messages	C211 or C213
Alarm delay	AL2	0 to 9999 sec	300		

# 12 Parameter level of the pH indicator

## 12.1 Settings



If it is necessary to reconfigure a number of instrument parameters,  
 ⇒ Chapter 35.1 “Programming the controller”, page 105ff.

### Pre-conditions

How to access the parameter level, or leave this level,  
 ⇒ Chapter 9.2 “Principle of operation”, page 26ff.

The parameter level must be unlocked,  
 ⇒ “Unlocking the levels”, page 29, (code word 0020).



It is possible that not all of the following parameters are needed or displayed, depending on the configuration of the controller functions.



For an explanation of the terminology used,  
 ⇒ Chapter 33 “Glossary”, page 95ff.

How to configure controllers,  
 ⇒ Chapter 27.1 “Configuration”, page 85ff.

Parameter	Display	Value band	Factory setting	displayed if ... is configured
Proportional band 1	Pb1	0.01 to 99.99 pH	7.00	Relay 1, pulse frequency or pulse width C211
Proportional band 2	Pb2			Relay 2, pulse frequency or pulse width C211
Derivative time 1	dt1	0 to 9999 sec	0	Relay 1, pulse frequency or pulse width C211
Derivative time 2	dt2			Relay 2, pulse frequency or pulse width C211
Reset time 1	rt1			Relay 1, pulse frequency or pulse width C211
Reset time 2	rt2			Relay 2, pulse frequency or pulse width C211
Minimum ON time 1 (for limit controller or pulse width controller) or minimum pulse width 1 (for pulse frequency controller)	tr1	0.2 to 999.9 sec	0.2	Controller 1, pulse width C211
Minimum ON time 2 (for pulse width controller) or minimum pulse width 2 (for pulse frequency controller)	tr2			pulse frequency C211
				Relay 2, pulse width C211
				pulse frequency C211

## 12 Parameter level of the pH indicator

Parameter	Display	Value band	Factory setting	displayed if ... is configured
Switching differential 1	HYS1	0.00 to 99.99 pH or °C	0.30	Relay 1, limit value C211
Switching differential 2	HYS2			Relay 2, limit value C211
Switching differential 3	HYS3			Relay 3, limit value C213
Switching differential 4	HYS4			Relay 4, limit value C213
Switching differential 5	HYS5			Relay 5, limit value C214
Pull-in delay 1	Ond1	0.00 to 999.9 sec	1.0	Relay 1, limit value C211
Pull-in delay 2	Ond2			Relay 2, limit value C211
Pull-in delay 3	Ond3			Relay 3, limit value C213
Pull-in delay 4	Ond4			Relay 4, limit value C213
Pull-in delay 5	Ond5			Relay 5, limit value C214
Drop-out delay 1	Ofd1		0.2 sec	Relay 1, limit value C211
Drop-out delay 2	Ofd2			Relay 2, limit value C211
Drop-out delay 3	Ofd3			Relay 3, limit value C213
Drop-out delay 4	Ofd4			Relay 4, limit value C213
Drop-out delay 5	Ofd5			Relay 5, limit value C214
Maximum pulse frequency 1	Fr1	0 to 150 pulse/min	100	Relay 1, pulse frequency C211
Maximum pulse frequency 2	Fr2			Relay 2, pulse frequency C211
Pulse period 1	CY1	1.0 to 999.9 sec	20.0	Relay 1, pulse width C211
Pulse period 2	CY2			Relay 2, pulse width C211
Output level limit Relay 1	Y1	0 to 100%	100	Relay 1, pulse frequency or pulse width C211
Output level limit Relay 2	Y2			Relay 2, pulse frequency or pulse width C211
Filter constant	dF	0 to 100 sec	0.6	
Actuator time	tt	15 to 3000 sec	60	Modulating controller C211

# 13 Configuration level of the pH indicator

## 13.1 General

The basic functions of the instrument can be displayed and/or altered at the configuration level.



If it is necessary to reconfigure a number of instrument parameters,  
 ⇒ Chapter 35.1 “Programming the controller”, page 105ff.



For an explanation of the terminology used,  
 ⇒ Chapter 33 “Glossary”, page 95ff.  
 How to configure controllers,  
 ⇒ Chapter 27.1 “Configuration”, page 85ff.

### Pre-conditions

How to access the configuration level, or leave this level,  
 ⇒ Chapter 9.2 “Principle of operation”, page 26ff.

The configuration level is unlocked,  
 ⇒ “Unlocking the levels”, page 29, (code word 0300).

## 13.2 Analog inputs - C111

	a	b	c	d
<b>C111*</b>	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
<b>Unit</b>				
mV <sup>1</sup>	0			
pH	1			
<b>Analog input 1</b>				
0 – 20 mA		0		
4 – 20 mA		1		
<b>Slope</b>				
Electrode slope (%)			0	
Electrode slope (mV/pH)			1	
<b>Type of temperature acquisition</b>				
Manual temperature compensation				0
Automatic temperature compensation with Pt100				1
Automatic temperature compensation with Pt1000				2

\*The factory-set parameters are shown in the position boxes.

<sup>1</sup> If mV is selected as the measurement unit, refer to Chapter 14!

# 13 Configuration level of the pH indicator

## 13.3 Electrode type - C112

	a	b	c	d
<b>C112*</b>	<b>x</b>	<b>x</b>	<b>0</b>	<b>x</b>
<b>Electrode type</b>				
Standard electrode			0	
Special electrode (antimony)			1	

\*The factory-set parameters are shown in the position boxes.

## 13.4 Electrode monitoring - C114

	a	b	c	d
<b>C114*</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>
<b>Not used</b>				
	0			
<b>Not used</b>				
		0		
<b>Not used</b>				
			0	
<b>Electrode monitoring<sup>1</sup></b>				
Off				0
On				1

\* The factory-set parameters are shown in the position boxes.



<sup>1</sup> The measurement is monitored for changes. If the measurement does not change within a defined period, then it can be assumed that an electrode fault (e.g. glass fracture, wiring fault, short-circuit) has occurred. A false alarm may be generated by operational states that are stationary or change very slowly. Electrode monitoring should then be switched off.

## 13 Configuration level of the pH indicator

---

### 13.5 nuLL - SLoP

---

<b>SLoP</b>	<p>Slope correction</p> <p>The slope of the output signal of a pH electrode changes during operation. The electrode slope can be determined automatically during 2-point calibration (see chapter “Calibration”), or it can be entered manually.</p> <p>Value range: 75.0 – 110.0%, if standard electrode is configured, ⇒ Chapter 13.3 “Electrode type - C112”, page 39.</p> <p>Value range: 10.0 – 110.0%, if special electrode (antimony) is configured, ⇒ Chapter 13.3 “Electrode type - C112”, page 39.</p> <p>Factory setting: 100.0%</p>
<b>nuLL</b>	<p>Zero point correction</p> <p>The zero point of the <b>ideal</b> pH electrode is pH 7. Because of manufacturing variations, and also because the electrode parameters change during operation, the <b>real</b> electrode zero deviates from pH 7. This deviation from the ideal zero can be corrected with “nuLL”.</p> <p>Value range: 5.00 – 9.00 pH if standard electrode is configured, ⇒ Chapter 13.3 “Electrode type - C112”, page 39.</p> <p>Value range: -2.00 – 16.00 pH if special electrode (antimony) is configured, ⇒ Chapter 13.3 “Electrode type - C112”, page 39.</p> <p>Factory setting: 7.00 pH</p>
<b>SiL</b>	<p>Start of transmission range</p> <p>This value is taken from the operating instructions for the attached instrument.</p> <p>Example for JUMO 202701: SiL = 600 mV</p>
<b>SiH</b>	<p>End of transmission range</p> <p>This value is taken from the operating instructions for the attached instrument.</p> <p>Example for JUMO 202701: SiL = -600 mV</p>

---

### 13.6 Configuration parameter for general (not pH-specific) functions

⇒ Chapter 26 “Configuration level (not instrument-specific)”, page 76.

---

## 14.1 Redox measurement circuit


The JUMO dTRANS Az 01 (1) indicator/controller requires a standard 0(4) – 20 mA input signal that is proportional to the redox voltage.

The 2-wire redox transmitter (2) provides this standard signal.

The metal combination electrode (3) is connected to the 2-wire redox transmitter (2), which in its turn is connected to the JUMO dTRANS Az 01 (1). A temperature probe (4) can be connected to the indicator/controller as an option. This temperature probe can be used to measure the temperature of the liquid. The dTRANS Az 01 can indicate and control this temperature.

As a further option, the JUMO dTRANS Az can supply the voltage for the 2-wire transmitter.

### Example



A combination of:

- (1) JUMO dTRANS Az 01,  
(configured as a redox voltage indicator, **rAnG 20**)
- (2) JUMO 202702 (2-wire transmitter for redox)
- (3) metal combination electrode
- (4) optional temperature probe (Pt100 or Pt1000)

## 14.2 Calibration

The delivery condition of the electrode is such that generally no calibration of the transmitter for the electrode parameters is required. Through usage, however, the electrode parameters may change. To compensate for this, the indicator/controller can be adjusted to the zero point of the electrode. If a new electrode is connected to an indicator/controller that has already been

# 14 Redox indicator

---

calibrated, either the zero point on the instrument should be set to 0.0 mV (see below, **manual entry**) or single-point calibration should be performed.

---

## 1-point calibration

In 1-point calibration **the electrode zero** is freshly determined using a buffer solution (solution with a known redox voltage).

The display unit [mV] must have been selected in C111!

⇒ Chapter 17.2 “Analog inputs - C111”, page 48.

---

## 2-point calibration

In 2-point calibration, the start and end values can be freely defined (for applications such as decontamination control).

The display unit [%] must have been selected in C111!

⇒ Chapter 17.2 “Analog inputs - C111”, page 48.

---

## Manual entry

In addition to the calibration procedure described above, the indicator/controller offers the facility of manually entering the zero point (as determined by a laboratory, for example),

⇒ Chapter 17.3 “nuLL - SLoP”, page 49.


---

## Temperature

The measurement of the redox voltage does not take temperature into account; neither automatic nor manual temperature compensation is required.



### Cancel

You can change back to the measurement mode at any time, by pressing the  key.

---

## Preparation for calibration

Before the first calibration, the following has to be determined:

- the calibration procedure (1-point or 2-point calibration) whether the process value output is frozen or not during calibration.  
⇒ Chapter 26.4 “Controller options - C211”, page 78.




If subsequent calibrations are carried out with the same settings, then it will not be necessary to set them again.

---

## Calibration with / without “frozen process value output”

“Freezing” the process value output means that, during calibration, the output signal is held at the value that was produced immediately before calibration started. This is to avoid an uncontrolled reaction from any PLC that may be connected to the output of the indicator/controller.


While the process value output is frozen, the lower display shows “donE” after the last calibration step, and the upper display shows the latest measurement. The process value output remains unchanged!



After the electrode has been installed once more, the  key must be pressed again. The process value output is now coupled to the display again.



The factory setting is: “Calibration without frozen process value output”.

## Select calibration procedure


\* Press the  key repeatedly, until “C211” appears in the lower display.


Use the  and  keys to set the configuration code:

Calibration procedure	X	X	0	X
1-point calibration, process value output not frozen			0 <sup>1</sup>	
1-point calibration, process value output frozen			1 <sup>1</sup>	
2-point calibration, process value output not frozen			2 <sup>2</sup>	
2-point calibration, process value output frozen			3 <sup>2</sup>	

<sup>1</sup> select display unit [mV] in C111!

<sup>2</sup> select display unit [%] in C111!

\* Press the  key (confirmation)

\* Press the  key (return to the measurement mode).

## 14.3 1-point calibration

### You will need

- a buffer solution (measurement solution) with a redox voltage which roughly corresponds to the medium measured later.

### Initial condition

A metal combination electrode is connected to a 2-wire transmitter for redox voltage, that in its turn is attached to a JUMO dTRANS Az 01,  
 ⇨ Chapter 14.1 “Redox measurement circuit”, page 41.


The calibration procedure has been selected,  
 ⇨ Chapter 14.2 “Calibration”, page 41.

The operating level is unlocked,  
 ⇨ Chapter 9.5 “Programming”, page 29, (code word 0110)



The instrument is in the measurement mode,  
 ⇨ Chapter 9.2 “Principle of operation”, page 26.

### Calibration

\* Immerse the metal combination electrode in the buffer solution

\* Press the  +  (Cal) keys

\* The lower display shows “Cal1” with the decimal point flashing.

\* Using the  or  keys, set the displayed value to the value of the reference buffer solution.

When the redox voltage has stabilized, the calibration procedure is complete.

\* Press the  key.

The instrument stores the new zero.

The instrument is in the measurement mode again.



If, on completion of calibration, the instrument shows “Err” in the temperature display,

⇨ Chapter 34.1 “Messages”, page 103.

# 14 Redox indicator

---

## 14.4 2-point calibration

### You will need

- A vessel with a sample of the medium to be decontaminated.
- A vessel with clean water.
- A vessel with a sample of the decontaminated medium.



The samples must be checked in accordance with the legal requirements!

### Initial condition

A metal combination electrode, or a metal electrode and a reference electrode are connected to the redox transmitter,

⇒ Chapter 14.1 “Redox measurement circuit”, page 41.

The calibration procedure has been selected,

⇒ Chapter 14.2 “Calibration”, page 41.









The operating level is unlocked,

⇒ Chapter 9.5 “Programming”, page 29, (code word 0110)

The instrument is in the measurement mode,

⇒ Chapter 9.2 “Principle of operation”, page 26.

### Calibration

- \* Press the  +  (Cal) keys
- \* Immerse the redox electrode in the vessel containing a sample of the medium to be decontaminated.
- \* The lower display shows “Cal1”, with the decimal point flashing.
- \* When the % value display has stabilized, set the displayed value to e.g. 20% using the  or  keys.
- \* Press the  key.  
The lower display shows “Cal2”, with the decimal point flashing.
- \* Remove the redox electrode from the sample of the medium to be decontaminated and rinse with water.
- \* Immerse the redox electrode in the vessel containing a sample of the decontaminated medium.
- \* When the % value display has stabilized, set the displayed value to e.g. 80% using the  or  keys.
- \* Press the  key.  
The instrument stores the new zero and the new slope.  
The instrument is in the measurement mode.



If, on completion of calibration, the instrument shows “Err” in the temperature display,

⇒ Chapter 34.1 “Messages”, page 103.

# 15 Operator level of the redox indicator

## 15.1 Settings

### Pre-conditions

How to access the operating level, or leave this level,  
 ⇨ Chapter 9.2 “Principle of operation”, page 26ff.

The operating level must be unlocked,  
 ⇨ “Unlocking the levels”, page 29, (code word 0110).



It is possible that not all of the following parameters are needed or displayed, depending on the configuration of the controller functions.



For an explanation of the terminology used,  
 ⇨ Chapter 33 “Glossary”, page 95ff.

How to configure controllers,  
 ⇨ Chapter 27.1 “Configuration”, page 85ff.

Designation	Parameter (display)	Value range	Factory setting	displayed if ... is configured	see Configuration parameter
Setpoint 1	SP(r)1	-1999 to 1999 mV	-1999	K1	C211
Setpoint 2	SP(r)2		1999	K2	
Setpoint 3	SP(r)3		-1999	Setpoint changeover	C112
Setpoint 4	SP(r)4		1999		
Code word	CodE	4-digit	0000		
Limit LK A (K1)	SP A	-1999 to 1999 mV or -50 to 250°C	-1999	K1	C214
Limit LK b (K2)	SP b			K2	
Limit LK C (K3)	SP C			K3	C113
Limit LK d (K4)	SP d			K4	
Limit LK E (K5)	SP E			K5	
Temperature for compensation (manually adjustable or automatic, depending on the configuration)	InP2	(•C)	25		C111
Alarm tolerance	AL1	0.00 to 9999 mV	0	Controller alarm messages	C211 or C213
Alarm delay	AL2	0 to 9999 sec	300		

# 16 Parameter level of the redox indicator

## 16.1 Settings



If it is necessary to reconfigure a number of instrument parameters,  
 ⇒ Chapter 35.1 “Programming the controller”, page 105ff.

### Pre-conditions

How to access the parameter level, or leave this level,  
 ⇒ Chapter 9.2 “Principle of operation”, page 26ff.

The parameter level must be unlocked,  
 ⇒ “Unlocking the levels”, page 29, (code word 0020).



It is possible that not all of the following parameters are needed or displayed, depending on the configuration of the controller functions.



For an explanation of the terminology used,  
 ⇒ Chapter 33 “Glossary”, page 95ff.

How to configure controllers,  
 ⇒ Chapter 27.1 “Configuration”, page 85ff.

Parameter	Display	Value range	Factory setting	displayed if ... is configured
Proportional band 1	Pb1	0001 to 9999 mV	1000	Relay 1, pulse frequency or pulse width C211
Proportional band 2	Pb2			Relay 2, pulse frequency or pulse width C211
Derivative time 1	dt1	0 to 9999 sec	0	Relay 1, pulse frequency or pulse width C211
Derivative time 2	dt2			Relay 2, pulse frequency or pulse width C211
Reset time 1	rt1			Relay 1, pulse frequency or pulse width C211
Reset time 2	rt2			Relay 2, pulse frequency or pulse width C211
Minimum ON time 1 (for limit controller or pulse width controller) or minimum pulse width 1 (for pulse frequency controller)	tr1	0.2 to 999.9 sec	0.2	Controller 1, pulse width C211
				pulse frequency C211
Minimum ON time 2 (for pulse width controller) or minimum pulse width 2 (for pulse frequency controller)	tr2			Relay 2, pulse width C211
				pulse frequency C211

## 16 Parameter level of the redox indicator

Parameter	Display	Value range	Factory setting	displayed if ... is configured
Switching differential 1	HYS1	0001 to 9999 mV or °C	80	Relay 1, limit value C211
Switching differential 2	HYS2			Relay 2, limit value C211
Switching differential 3	HYS3			Relay 3, limit value C213
Switching differential 4	HYS4			Relay 4, limit value C213
Switching differential 5	HYS5			Relay 5, limit value C214
Pull-in delay 1	Ond1	0.00 to 999.9 sec	1.0	Relay 1, limit value C211
Pull-in delay 2	Ond2			Relay 2, limit value C211
Pull-in delay 3	Ond3			Relay 3, limit value C213
Pull-in delay 4	Ond4			Relay 4, limit value C213
Pull-in delay 5	Ond5			Relay 5, limit value C214
Drop-out delay 1	Ofd1		0.2 sec	Relay 1, limit value C211
Drop-out delay 2	Ofd2			Relay 2, limit value C211
Drop-out delay 3	Ofd3			Relay 3, limit value C213
Drop-out delay 4	Ofd4			Relay 4, limit value C213
Drop-out delay 5	Ofd5			Relay 5, limit value C214
Maximum pulse frequency 1	Fr1	0 to 150 pulse/min	100	Relay 1, pulse frequency C211
Maximum pulse frequency 2	Fr2			Relay 2, pulse frequency C211
Pulse period 1	CY1	1.0 to 999.9 sec	20.0	Relay 1, pulse width C211
Pulse period 2	CY2			Relay 2, pulse width C211
Output level limit Relay 1	Y1	0 to 100%	100	Relay 1, pulse frequency or pulse width C211
Output level limit Relay 2	Y2			Relay 2, pulse frequency or pulse width C211
Filter constant	dF	0 to 100 sec	0.6	
Actuator time	tt	15 to 3000 sec	60	Modulating controller C211

# 17 Configuration level of the redox indicator

## 17.1 General

The basic functions of the instrument can be displayed and/or altered at the configuration level.



If it is necessary to reconfigure a number of instrument parameters,  
 ⇨ Chapter 35.1 “Programming the controller”, page 105ff.



For an explanation of the terminology used,  
 ⇨ Chapter 33 “Glossary”, page 95ff.  
 How to configure controllers,  
 ⇨ Chapter 27.1 “Configuration”, page 85ff.

### Pre-conditions

How to access the configuration level, or leave this level,  
 ⇨ Chapter 9.2 “Principle of operation”, page 26ff.

The configuration level is unlocked,  
 ⇨ “Unlocking the levels”, page 29, (code word 0300).

## 17.2 Analog inputs - C111

	a	b	c	d
<b>C111*</b>	<b>1</b>	<b>1</b>	<b>0</b>	<b>0</b>
<b>Unit</b>				
mV	0			
pH <sup>1</sup>	1			
<b>Analog input 1</b>				
0 – 20 mA		0		
4 – 20 mA		1		
<b>Display unit</b>				
in %			0	
in mV			1	
<b>Type of temperature acquisition<sup>2</sup></b>				
Manual temperature compensation				0
Automatic temperature compensation with Pt100 <sup>3</sup>				1
Automatic temperature compensation with Pt1000 <sup>3</sup>				2

\*The factory-set parameters are shown in the position boxes.

<sup>1</sup> If pH is selected as the measurement unit, refer to Chapter 13!

<sup>2</sup> The redox voltage is independent of temperature; no provision is made for temperature compensation. The temperature indication is switched

## 17 Configuration level of the redox indicator

---

off in this configuration.

The temperature measurement does not affect the indicated redox voltage.

- 3 As an option, a Pt100 or Pt1000 can be connected. The measured temperature of the process is then shown in the lower display. In this mode, the temperature can be monitored with a limit comparator, see also configuration codes C211 or 213.
- 

### 17.3 nuLL - SLoP

#### nuLL

---

Zero point correction (display unit [mV])

The zero point of an ideal metal electrode is 0 mV. Because of manufacturing variations, and also because the electrode parameters change during operation, the real electrode zero deviates from 0 mV. This deviation from the ideal zero can be corrected with “nuLL”.

Value range: -199.9 to 1999 mV

Factory setting: 0 mV

Zero point correction (display unit [%])

A value is calculated with display unit [%], which, however, does not reflect the state of the electrode.

---

#### SLoP

Slope correction (display unit [%])

A value is calculated, but this does not reflect the true state of the electrode.

---

#### SiL

Start of transmission range

This value is taken from the operating instructions for the attached instrument.

Example for JUMO 202701:

SiL = -1000 mV

---

#### SiH

End of transmission range

This value is taken from the operating instructions for the attached instrument.

Example for JUMO 202701:

SiH = 1000 mV

---

### 17.4 Configuration parameter for general (not redox-specific) functions

---

⇒ Chapter 26 “Configuration level (not instrument-specific)”, page 76.


---

# 18 Conductivity indicator

## 18.1 Conductivity measurement circuit

The JUMO dTRANS Az 01 (3) indicator/controller requires a standard 0(4) – 20 mA input signal that is proportional to the conductivity.

The conductivity transmitter JUMO CTI-Junior, type 202754 (2) provides such a standard signal. The temperature probe that is integrated into the JUMO CTI-Junior performs the temperature compensation for the conductivity measurement and can also be used to control the temperature of the substance being measured.



A combination of:

- (3) JUMO dTRANS Az 01,  
(configured as a conductivity indicator, **rAnG 22 to 25**)  
rAnG 22 -> no decimal places      0 – 9999  
rAnG 23 -> one decimal place      0.0 – 999.9  
rAnG 24 -> two decimal places      0.00 – 99.99  
rAnG 25 -> three decimal places      0 – 9.999
- (2) JUMO CTI-Junior, type 202754/xx-xxx/263 (conductivity transmitter)
- (1) Power supply for the JUMO CTI-Junior  
(e.g. JUMO type PS5R-A-24)

## 18.2 Conductivity measurement


### 18.2.1 Display range / select application

#### Initial condition



The configuration level is unlocked,  
⇒ “Unlocking the levels”, page 29 (code word 0300)

The instrument is in the measurement mode,  
⇒ “Operating modes and states”, page 26.





#### Procedure

- \* Press the  key twice, for more than 2 seconds, to access the configuration level.  
The lower display shows “C111”.

# 18 Conductivity indicator

Use the  and  keys to set the configuration code for the measurement unit:

Unit	0	X	X	X
μS/cm	0			
mS/cm	1			



- \* Press the  key (confirmation)
- \* Press the  key briefly and repeatedly, until “rAnG” appears in the lower display
- \* Use the  and  keys to set the range number for the display range

Display range	Application	Range (rAng)
0 – 9999	Conductivity – no decimal places	22
0.0 – 999.9	Conductivity – one decimal place	23
0.00 – 99.99	Conductivity – two decimal places	24
0.000 – 9.999	Conductivity – three decimal places	25



The **rAnG** settings 22 to 25 are designed for connecting the indicator/controller to a 2-wire transmitter that does not have or cannot use its own calibration routine.

If a transmitter is connected that does have its own calibration routine for the attached probe, then the **rAnG** settings 27 to 30 must be used.

- \* Press the  key (confirmation).
- \* Press the  key (return to the measurement mode).

For several seconds, both displays will indicate “bUSY” (the upper display blinks).

Afterwards, the upper display shows the measured conductivity (if a cell is connected, with an appropriate medium for measurement). If the measurement unit is configured as mS/cm, the LED for “mS/cm” lights up.

The lower display shows the temperature measured for the medium, or the manually set compensation temperature.



If an error number appears,  
 ⇨ Chapter 34 “Warnings – Errors”, page 103.

## 18.3 Measurement with manual temperature compensation

### Initial condition

A conductivity cell is attached to the Type 202540 transmitter,  
 ⇨ Chapter 7.1 “Electrical connection”, page 20.

The temperature acquisition is configured as  
 “Manual temperature compensation”,

# 18 Conductivity indicator

---

⇒ Chapter 21.2 “Analog inputs - C111”, page 63.

The instrument is in the measurement mode,

⇒ “Operating modes and states”, page 26.

## Procedure

The upper display shows the compensated conductivity value of the solution being measured.

The indicated conductivity depends on the manually set temperature, see **Temperature setting, below**

and the set (or automatically acquired) temperature coefficient (TC),

⇒ Chapter 18.8.1 “Automatic determination of the temperature coefficient, using manual temperature entry”, page 57.

The lower display shows the manually entered temperature setting.

## 18.4 Manual temperature entry

---

### Initial condition

The temperature acquisition is configured as

“Manual temperature compensation”,

⇒ Chapter 21.2 “Analog inputs - C111”, page 63.

The operating level is unlocked,



⇒ “Unlocking the levels”, page 29, (code word 0110)

The instrument is in the measurement mode,


⇒ “Operating modes and states”, page 26.

### Procedure

\* Press  briefly and repeatedly, until “InP2” is displayed.

Use the  and  keys to set the temperature that is shown

\* Press the  key (confirmation)

\* Press the  key (to return to measurement mode) or cancel the entry

## 18.5 Measurement with automatic temperature compensation

---

### Initial condition

The temperature acquisition has been configured as

“Automatic temperature compensation with Pt100 or Pt1000”,

⇒ Chapter 21.2 “Analog inputs - C111”, page 63.

The instrument is in the measurement mode,

⇒ “Operating modes and states”, page 26.

### Procedure

The temperature measurement for the medium cannot be altered manually.

## 18.6 Calibration

The cell constants of conductivity cells vary somewhat from one example to another, and also drift with use (because of deposits and wear). This results in a change of the output signal from the cell. It is therefore necessary that the user is able to compensate for the deviations of the cell constant from the nominal value, either by manual input or an automatic calibration of the relative cell constant  $K_{rel}$ ,




The time interval between two calibrations depends on the conditions in which the cell is used.

The conductivity of a solution varies with the temperature, so for correct measurement both the temperature and the temperature coefficient of the solution being measured must be known. The temperature can either be measured automatically, with a Pt100 or Pt1000 temperature probe, or set manually by the user. The temperature coefficient can be determined automatically by the JUMO dTRANS Az 01, or entered manually.



### Cancel

You can change back to the measurement mode at any time, by pressing the  key.

### Preparation for calibration


Before the first calibration, it is necessary to select the method of temperature acquisition (automatic or manual) to be used during calibration.



If subsequent calibrations are carried out with the same settings, then it will not be necessary to set the temperature acquisition again.



### Select type of temperature acquisition

The instrument is in the measurement mode.

- \* Unlock the configuration level, if necessary,  
⇒ “Unlocking the levels”, page 29, (code word 0300).
- \* Press the  key twice, for more than 2 seconds, to access the configuration level.  
The lower display shows “C111”.

Use the  and  keys to set the configuration parameter:

Type of temperature acquisition	X X X 0
Manual temperature compensation	0
Automatic temperature compensation with Pt100	1
Automatic temperature compensation with Pt1000	2


- \* Press the  key (confirmation)
- \* Press the  key (return to the measurement mode).

# 18 Conductivity indicator

## Calibration with / without “frozen process value output”

“Freezing” the process value output means that, during calibration, the output signal is held at the value that was produced immediately before calibration started. This is to avoid an uncontrolled reaction from any PLC that may be connected to the output of the indicator/controller.



While the process value output is frozen, the lower display shows “donE” after the last calibration step, and the upper display shows the latest measurement. The process value output remains unchanged!

After the conductivity cell has been installed once more, the  key must be pressed. The process value output is now coupled to the display again.





The factory setting is:  
“Calibration without frozen process value output”.

## Select calibration procedure

- \* The instrument is in the measurement mode.
- \* Unlock the configuration level, if necessary,  
⇒ “Unlocking the levels”, page 29 (code word 0300).
- \* Press the  key twice, for more than 2 seconds (but less than 4 seconds), to access the configuration level.  
The lower display shows “C111”.
- \* Press the  key repeatedly, until “C211” appears in the lower display.







Use the  and  keys to set the configuration parameter:

Calibration procedure	X	X	0	X
Calibration of the cell constant, process value output not frozen			0	
Calibration of the cell constant, process value output frozen			1	
Determination of the temperature coefficient, process value output not frozen			2	
Determination of the temperature coefficient, process value output frozen			3	

- \* Press the  key (confirmation)
- \* Press the  key (return to the measurement mode).

## 18.7 Calibrating the relative cell constant

---

<b>General</b>	The relative cell constant $K_{rel}$ can be used to compensate for the deviation of the real cell constant over the range from 80 to 120% of the nominal cell constant.
<b>Manual entry</b>	If the deviation of the cell constant from the nominal value is known, then the relative cell constant $K_{rel}$ can be entered manually:
<b>Initial condition</b>	The operating level is unlocked, ⇒ “Unlocking the levels”, page 29.  The instrument is in the measurement mode, ⇒ “Operating modes and states”, page 26.
<b>Procedure</b>	<ul style="list-style-type: none"><li>* Press the  key twice, for more than 2 seconds, to access the configuration level. The lower display shows “C111”.</li><li>* Press the  key repeatedly, until “CELL” appears in the lower display.</li><li>* Use the  and  keys to set <math>K_{rel}</math> (in %).</li><li>* Press the  key (confirmation).</li><li>* Press the  key (return to the measurement mode).</li></ul>

---

### 18.7.1 Automatic determination of the relative cell constant with a calibration solution

If the cell constant is not known, it can be determined and automatically stored:

---






<b>You will need</b>	<ul style="list-style-type: none"><li>- A calibration solution, with a known conductivity at the prevailing temperature.</li><li>- A thermometer, if you want to use manual compensation.</li><li>- A Pt100 or Pt1000 temperature probe (not necessary if the conductivity cell is equipped with an integrated temperature sensor), if you want to use automatic temperature compensation.</li></ul>
<b>Initial condition</b>	A conductivity cell is attached to the JUMO dTRANS Az 01, as well as a Pt100 or Pt1000 temperature probe (if required), ⇒ Chapter 18.1 “Conductivity measurement circuit”, page 50ff.  The calibration procedure has been configured to “Calibration of the cell constant, process value output ...” – frozen or not frozen, ⇒ Chapter 26.4 “Controller options - C211”, page 78.  The instrument is in the measurement mode, see ⇒ “Operating modes and states”, page 26.
<b>Procedure</b>	<ul style="list-style-type: none"><li>* Unlock the instrument for calibration,</li></ul>

---

# 18 Conductivity indicator

---

⇒ “Unlocking the levels”, page 29, (code word 0110)

- \* Immerse the sensitive portions of the cell and the temperature probe or thermometer in the calibration solution
    - wait until the temperature and conductivity measurements have stabilized.
  - \* Press the  and  keys – “CAL.1” appears in the lower display, alternating with the measured or manually set temperature.
  - \* Use the  and  keys to set the indicated conductivity to the real conductivity of the calibration solution at the temperature now prevailing.
  - \* Press the  key (saves the new cell constant and returns to the measurement mode).
- 

## 18.7.2 Automatic determination of the relative cell constant with a reference instrument

If the deviation of the cell constant from its nominal value is not known, then it can be automatically determined.

### You will need

A conductivity measuring instrument to serve as a reference.



The temperature coefficient of the reference instrument must be set to “0” ! If this is not possible, then the solution being measured must be tempered to the reference temperature for the reference instrument.






### Initial condition

The conductivity transmitter is connected to the JUMO dTRANS Az 01  
⇒ Chapter 18.1 “Conductivity measurement circuit”, page 50ff.

The calibration procedure has been configured to “Calibration of the cell constant, process value output ...” – frozen or not frozen,  
⇒ Chapter 26.4 “Controller options - C211”, page 78.

The instrument is in the measurement mode,  
⇒ “Operating modes and states”, page 26.

### Procedure

- \* Unlock the instrument for calibration,  
⇒ “Unlocking the levels”, page 29, (code word 0110)
  - \* Immerse the sensitive portions of both cells in the calibration solution
    - wait until the measurements for both instruments have stabilized.
  - \* Press the  and  keys on the instrument – “CAL.1” appears in the lower display, alternating with the measured or manually input temperature.
  - \* Use the  and  keys to set the indicated conductivity to match the value shown on the reference instrument.
  - \* Press the  key (saves the new cell constant and returns to the measurement mode).
-

# 18 Conductivity indicator

---

## Manual entry of the temperature coefficient

If the temperature coefficient of the solution being measured is known, then it can be entered manually.







## Initial condition

The configuration level is unlocked,  
⇒ “Unlocking the levels”, page 29, (code word 0300)

The calibration procedure has been configured to “Determination of the temperature coefficient, process value output ...” – frozen or not frozen,  
⇒ Chapter 26.4 “Controller options - C211”, page 78.

The instrument is in the measurement mode,  
⇒ “Operating modes and states”, page 26.

## Procedure

- \* Press the  key twice, for more than 2 seconds, to access the configuration level.  
The lower display shows “C111”.
- \* Press the  key repeatedly, until “ALPH” appears in the lower display.
- \* Use the  and  keys to set the temperature coefficient (in % per °C).
- \* Press the  key (confirmation).
- \* Press the  key (return to the measurement mode).

## 18.8 Calibrating the temperature coefficient

### 18.8.1 Automatic determination of the temperature coefficient, using manual temperature entry

The instrument uses the non-temperature compensated measurements (TC = 0) at two different temperatures (the reference temperature of 25°C and a second temperature, usually that which will be used for later measurements) to determine the temperature coefficient of the solution being measured.

## You will need

- A sample of the medium to be measured
- A tempering setup
- A thermometer

## Initial condition

The conductivity transmitter is connected to the JUMO dTRANS Az 01  
⇒ Chapter 18.1 “Conductivity measurement circuit”, page 50ff.

The temperature acquisition is configured as “Manual temperature compensation”,  
⇒ Chapter 21.2 “Analog inputs - C111”, page 63.

The calibration procedure has been configured to “Determination of the temperature coefficient, process value output ...” – frozen or not frozen,  
⇒ Chapter 26.4 “Controller options - C211”, page 78.









The instrument is in the measurement mode,

# 18 Conductivity indicator

---

⇒ “Operating modes and states”, page 26.

## Procedure

- \* Unlock the instrument for calibration,  
⇒ “Unlocking the levels”, page 29, (code word 0110)
  - \* Immerse the sensitive portions of the cell and the thermometer in the solution to be measured.
  - \* Temper the solution to 25•C.
  - \* Press the  and  (CAL) keys.  
The upper display shows the uncompensated conductivity value for the measured solution at 25•C, alternating with “CAL1”; the lower display shows the temperature that was set manually.
  - \* Use the  and  keys to set 25.0 (•C).
  - \* Press the  key.  
The upper display shows the uncompensated conductivity value for the measured solution at the present temperature, alternating with “CAL2”.
  - \* Temper the solution to the future working temperature.
  - \* Use the  and  keys to set the future working temperature (•C).
  - \* Press the  key.  
The upper display shows the conductivity value (compensated for 25•C) for the measurement solution at the present temperature. The lower display shows the temperature that was set before the start of calibration.
- 

## 18.8.2 Automatic determination of the temperature coefficient, using automatic temperature entry

The instrument uses the non-temperature compensated measurements (TC = 0) at two different temperatures (the reference temperature of 25•C and a second temperature, usually that which will be used for later measurements) to determine the temperature coefficient of the solution being measured.

## You will need

- A sample of the medium to be measured
- A tempering setup
- A Pt100 or Pt1000 temperature probe (not necessary if the conductivity cell is equipped with an integrated temperature sensor).

## Initial condition

The conductivity transmitter is attached to the JUMO dTRANS Az 01, as well as a Pt100 or Pt1000 temperature probe (if required),  
⇒ “Electrical connection”, page 20ff.

The temperature acquisition is configured as “Automatic temperature compensation”,

⇒ Chapter 21.2 “Analog inputs - C111”, page 63.

The calibration procedure has been configured to “Determination of the temperature coefficient, process value output ...” – frozen or not frozen,

⇒ Chapter 26.4 “Controller options - C211”, page 78.





## 18 Conductivity indicator

---

The instrument is in the measurement mode,  
⇒ “Operating modes and states”, page 26.

---

### Procedure

- \* Unlock the instrument for calibration,  
⇒ “Unlocking the levels”, page 29, (code word 0110)
- \* Immerse the sensitive portions of the cell and the temperature probe in the solution to be measured.
- \* Temper the solution to 25•C.
- \* Press the  and  (CAL) keys.  
The upper display shows the uncompensated conductivity value for the measured solution at 25•C, alternating with “CAL1”; the lower display shows the temperature measured by the probe.
- \* Press the  key.  
The upper display shows the uncompensated conductivity value for the measured solution at the present temperature, alternating with “CAL2”. The lower display shows the temperature measured by the probe.
- \* Temper the solution to the future working temperature.
- \* When the temperature display has stabilized, press the  key.  
The upper display shows the conductivity value (compensated for 25•C) for the measurement solution at the present temperature. The lower display shows the temperature measured by the probe.

# 19 Operator level of the conductivity indicator

## 19.1 Settings

### Pre-conditions

How to access the operating level, or leave this level,  
 ⇨ Chapter 9.2 “Principle of operation”, page 26ff.

The operating level must be unlocked,  
 ⇨ “Unlocking the levels”, page 29, (code word 0110).



It is possible that not all of the following parameters are needed or displayed, depending on the configuration of the controller functions.



For an explanation of the terminology used,  
 ⇨ Chapter 33 “Glossary”, page 95ff.

How to configure controllers,  
 ⇨ Chapter 27.1 “Configuration”, page 85ff.

Designation	Parameter (display)	Value range	Factory setting	displayed if ... is configured	see Configuration parameter
Setpoint 1	SP(r)1	0 – 0.5µS	0.00	K1	C211
Setpoint 2	SP(r)2		1.00	K2	
Setpoint 3	SP(r)3	0 – 200mS <sup>1</sup>	-0.00	Setpoint changeover	C112
Setpoint 4	SP(r)4		1.00		
Code word	CodE	4-digit	0000		
Limit LK A (K1)	SP A	corresponds to “rAnG” ⇨ “rAnG”, page 64 or -50.0 to 250.0°C	-1.00	K1	C214
Limit LK b (K2)	SP b			K2	
Limit LK C (K3)	SP C			K3	C113
Limit LK d (K4)	SP d			K4	
Limit LK E (K5)	SP E			K5	
Process value input 2 (temperature)	InP2	(•C)	25		C111
Alarm tolerance	AL1	corresponds to “rAnG” ⇨ “rAnG”, page 64	0	Controller alarm messages	C211 or C213
Alarm delay	AL2	0 to 9999 sec	300		

<sup>1</sup> depending on the configured measurement range,  
 ⇨ “rAnG - CELL - ALPH”, page 64.

# 20 Parameter level of the conductivity indicator

## 20.1 Settings



If it is necessary to reconfigure a number of instrument parameters,  
 ⇒ Chapter 35.1 “Programming the controller”, page 105ff.

### Pre-conditions

How to access the parameter level, or leave this level,  
 ⇒ Chapter 9.2 “Principle of operation”, page 26ff.

The parameter level must be unlocked,  
 ⇒ “Unlocking the levels”, page 29, (code word 0020).



It is possible that not all of the following parameters are needed or displayed, depending on the configuration of the controller functions.



For an explanation of the terminology used,  
 ⇒ Chapter 33 “Glossary”, page 95ff.

How to configure controllers,  
 ⇒ Chapter 27.1 “Configuration”, page 85ff.

Parameter	Display	Value range	Factory setting	displayed if ... is configured
Proportional band 1	Pb1	mS or $\mu$ S	50% of full scale	Relay 1, pulse frequency or pulse width in C211
Proportional band 2	Pb2			Relay 2, pulse frequency or pulse width in C211
Derivative time 1	dt1	0 to 9999 sec	0 sec	Relay 1, pulse frequency or pulse width in C211
Derivative time 2	dt2			Relay 2, pulse frequency or pulse width in C211
Reset time 1	rt1		0 sec	Relay 1, pulse frequency or pulse width in C211
Reset time 2	rt2			Relay 2, pulse frequency or pulse width in C211
Minimum ON time 1 (for limit controller or pulse width controller) or minimum pulse width 1 (for pulse frequency controller)	tr1	0.2 to 999.9 sec	0,2	Controller 1, pulse width in C211
Minimum ON time 2 (for pulse width controller) or minimum pulse width 2 (for pulse frequency controller)	tr2			pulse frequency in C211
				Relay 2, pulse width in C211
				pulse frequency in C211

## 20 Parameter level of the conductivity indicator

Parameter	Display	Value range	Factory setting	displayed if ... is configured
Switching differential, controller 1	HYS1	0001 to 9999	2% of full scale	Relay 1, limit value in C211
Switching differential, controller 2	HYS2			Relay 2, limit value in C211
Switching differential, controller 3	HYS3			Relay 3, limit value in C213
Switching differential, controller 4	HYS4			Relay 4, limit value in C213
Switching differential, controller 5	HYS5			Relay 5, limit value in C214
Pull-in delay 1	Ond1	0.00 to 999.9 sec	1.0	Relay 1, limit value in C211
Pull-in delay 2	Ond2			Relay 2, limit value in C211
Pull-in delay 3	Ond3			Relay 3, limit value in C213
Pull-in delay 4	Ond4			Relay 4, limit value in C213
Pull-in delay 5	Ond5			Relay 5, limit value in C214
Drop-out delay 1	Ofd1		0.2 sec	Relay 1, limit value in C211
Drop-out delay 2	Ofd2			Relay 2, limit value in C211
Drop-out delay 3	Ofd3			Relay 3, limit value in C213
Drop-out delay 4	Ofd4			Relay 4, limit value in C213
Drop-out delay 5	Ofd5			Relay 5, limit value in C214
Maximum pulse frequency 1	Fr1	0 to 150 pulse/min	100	Relay 1, pulse frequency in C211
Maximum pulse frequency 2	Fr2			Relay 2, pulse frequency in C211
Pulse period 1	CY1	1.0 to 999.9 sec	20.0	Relay 1, pulse width in C211
Pulse period 2	CY2			Relay 2, pulse width in C211
Output level limit Relay 1	Y1	0 to 100%	100	Relay 1, pulse frequency or pulse width in C211
Output level limit Relay 2	Y2			Relay 2, pulse frequency or pulse width in C211
Filter constant	dF	0 to 100 sec	0.6	
Actuator time	tt	15 to 3000 sec	60	Modulating controller in C211

# 21 Configuration level of the conductivity indicator

## 21.1 General

The basic functions of the instrument can be displayed and/or altered at the configuration level.



If it is necessary to reconfigure a number of instrument parameters,

⇒ Chapter 35.1 “Programming the controller”, page 105ff.



For an explanation of the terminology used,

⇒ Chapter 33 “Glossary”, page 95ff.

How to configure controllers,

⇒ Chapter 27.1 “Configuration”, page 85ff.

### Pre-conditions

How to access the configuration level, or leave this level,

⇒ Chapter 9.2 “Principle of operation”, page 26ff.

The configuration level is unlocked,

⇒ “Unlocking the levels”, page 29, (code word 0300).

## 21.2 Analog inputs - C111

	C111*	1	1	0	0
<b>Unit</b>					
μS/cm		0			
mS/cm		1			
<b>Analog input 1</b>					
0 – 20 mA			0		
4 – 20 mA			1		
<b>Not used</b>					
				0	
<b>Type of temperature acquisition</b>					
Manual temperature compensation					0
Automatic temperature compensation with Pt100					1
Automatic temperature compensation with Pt1000					2

\*The factory-set parameters are shown in the position boxes.

## 21 Configuration level of the conductivity indicator

### 21.3 Process value output for conductivity - C311

	C311*			
	<input type="text" value="5"/>	<input type="text" value="0"/>	<input type="text"/>	<input type="text"/>
<b>Bilinear characteristic</b>				
0%	0	0		
1%	0	1		
...				
99%	9	9		

\*The factory-set parameters are shown in the position boxes.

### 21.4 rAnG - CELL - ALPH

#### rAnG

The range number is used to select the display range.

Display range	Application	Range (rAng)
0 – 9999	Conductivity – no decimal places	22
0.0 – 999.9	Conductivity – one decimal place	23
0.00 – 99.99	Conductivity – two decimal places	24
0.000 – 9.999	Conductivity – three decimal places	25



The **rAnG** settings 22 to 25 are designed for connecting the indicator/controller to a 2-wire transmitter that does not have or cannot use its own calibration routine.

If a transmitter is connected that does have its own calibration routine for the attached probe, then the **rAnG** settings 27 to 30 must be used.

#### CELL

The relative cell constant  $K_{rel}$  [%] can be used to compensate for the deviation of the cell constant from the nominal value (0.01; 0.1; 1.0; 3.0; 10.0) over the range from 80 to 120%.

## 21 Configuration level of the conductivity indicator

---

<b>ALPH</b>	<p>Temperature coefficient [% per °C] of the measured solution. Value range: 0.00 – 5.50% per °C</p> <p>The conductivity of a solution varies with the temperature, so for correct measurement both the temperature and the temperature coefficient of the solution being measured must be known.</p> <p>The temperature coefficient can be determined automatically by the conductivity transmitter, or entered manually. ⇒ “Calibrating the temperature coefficient”, page 57.</p>
<b>SiL</b>	<p>Start of transmission range</p> <p>This value is taken from the operating instructions for the attached instrument. Example for the JUMO CTI-Junior, type 202754 (transmission range 0 – 1.00 mS/cm): SiL = 0.00 mS/cm</p>
<b>SiH</b>	<p>End of transmission range</p> <p>This value is taken from the operating instructions for the attached instrument. Example for the JUMO CTI-Junior, type 202754 (transmission range 0 – 1.00 mS/cm): SiL = 1.00 mS/cm</p>

### 21.5 Configuration parameter for general (not conductivity-specific) functions

---

⇒ Chapter 26 “Configuration level (not instrument-specific)”, page 76.

---


## 22 Universal indicator

### 22.1 Measurement circuit for the universal indicator

The JUMO dTRANS Az 01 (1) indicator/controller requires a standard 0(4) – 20 mA input signal that is proportional to the conductivity.

The JUMO transmitter for free chlorine, type 202630 (2) provides such a standard signal. A optional temperature probe (3) makes it possible to display or control the temperature of the substance being measured.

As an option, the JUMO dTRANS Az can provide the supply voltage for the JUMO transmitter for free chlorine, type 202630.



Example: a combination of

- (1) JUMO dTRANS Az 01,  
(configured as a universal indicator, **rAnG 27 to 30**)  
rAnG 27 -> no decimal places      -1999 to 9999  
rAnG 28 -> one decimal place      -199.9 to 999.9  
rAnG 29 -> two decimal places      -19.99 to 99.99  
rAnG 30 -> three decimal places      -1.999 to 9.999
- (2) JUMO measuring cell for free chlorine, type 202630
- (3) optional temperature probe (Pt100 or Pt1000)

### 22.2 Display range / select application

#### Initial condition

The configuration level is unlocked,  
⇒ “Unlocking the levels”, page 29 (code word 0300)




The instrument is in the measurement mode,  
⇒ “Operating modes and states”, page 26.

#### Procedure



\* Press the  key twice, for more than 2 seconds, to access the

configuration level.

The lower display shows “C111”.

- \* Press the  key briefly and repeatedly, until “rAnG” appears in the lower display
- \* Use the  and  keys to set the range number for the required display range

Display range	Application	Range (rAng)
-1999 to 9999	Universal indicator – no decimal places	27
-199.9 to 999.9	Universal indicator – one decimal place	28
-19.99 to 99.99	Universal indicator – two decimal places	29
-1.999 to 9.999	Universal indicator – three decimal places	30

- \* Press the  key (confirmation).
- \* Press the  key (return to the measurement mode).

For several seconds, both displays will indicate “bUSY” (the upper display blinks). From then on, the upper display will show a value, if a transducer or sensor is attached.

The lower display is switched off, or will show the temperature measured for the medium, if it is appropriately configured (C111).



If an error number appears,  
⇒ Chapter 34 “Warnings – Errors”, page 103.

### 22.3 Calibration

It may be necessary to match the display to the values, depending on the probe or transmitter that is being used. For this reason, when configured as a universal indicator, the dTRANS Az 01 provides calibration procedures to suit a wide range of requirements.

#### 1-point calibration Zero point

The zero point is determined here, or an offset adjustment is made.

#### 1-point calibration End value

A single end value adjustment is made.

#### 2-point calibration

With 2-point calibration, the start and end values can be freely defined.

#### Manual entry

In addition to the calibration procedure described above, the indicator/controller offers the facility of manually entering the zero point and the slope,  
⇒ Chapter 25.4 “nuLL - SLoP - SiL - SiH”, page 75.

## 22 Universal indicator

### Temperature

The temperature is **not** taken into account for this measurement.



#### Cancel

You can change back to the measurement mode at any time, by pressing the key.

### Preparation for calibration

Before the first calibration, the following has to be determined:

- the calibration procedure (1-point or 2-point calibration) whether the process value output is frozen or not during calibration.
  - ⇒ Chapter 21.2 “Analog inputs - C111”, page 63.



If subsequent calibrations are carried out with the same settings, then it will not be necessary to set them again.

### Calibration with / without “frozen process value output”

“Freezing” the process value output means that, during calibration, the output signal is held at the value that was produced immediately before calibration started. This is to avoid an uncontrolled reaction from any PLC that may be connected to the output of the indicator/controller.

While the process value output is frozen, the lower display shows “donE” after the last calibration step, and the upper display shows the latest measurement. The process value output remains unchanged!

After the chlorine cell has been installed once more, the key must be pressed. The process value output is now coupled to the display again.



The factory setting is: “Calibration without frozen process value output”.

### Select calibration procedure

\* Press the key repeatedly, until “C211” appears in the lower display.

Use the and keys to set the configuration code:

Calibration procedure	X	X	0	X
Zero point for 1-point calibration Process value output not frozen			0	
Zero point for 1-point calibration Process value output is frozen			1	
End value for 1-point calibration Process value output not frozen			2	
End value for 1-point calibration Process value output is frozen			3	
2-point calibration, process value output not frozen			4	
2-point calibration, process value output frozen			5	

\* Press the key (confirmation)

\* Press the key (return to the measurement mode).






### 22.4 “Zero point” for 1-point calibration

#### Initial condition

A transmitter is connected to the dTRANS Az 01,  
⇒ Chapter 22.1 “Measurement circuit for the universal indicator”, page 66.  
The calibration procedure has been selected,  
⇒ Chapter 22.3 “Calibration”, page 67.  
The operating level is unlocked,  
⇒ Chapter 9.5 “Programming”, page 29, (code word 0110)  
The instrument is in the measurement mode,  
⇒ Chapter 9.2 “Principle of operation”, page 26.

---

#### Calibration

- \* Simulate the calibration point for the sensor on the transmitter, or determine the value by a comparison measurement.
- \* Press the  +  keys
- \* The lower display shows “Cal1” with the decimal point flashing.
- \* Using the  or  keys, adjust the displayed value to match the known value. When the display has stabilized, the calibration procedure can be completed.
- \* Press the  key.  
The instrument stores the new zero.  
The instrument is in the measurement mode again.



If, on completion of calibration, the instrument shows “Err” in the temperature display,  
⇒ Chapter 34.1 “Messages”, page 103.

---





### 22.5 “End value” for 1-point calibration

#### Initial condition

A transmitter is connected to the dTRANS Az 01,  
⇒ Chapter 22.1 “Measurement circuit for the universal indicator”, page 66.  
The calibration procedure has been selected,  
⇒ Chapter 22.3 “Calibration”, page 67.  
The operating level is unlocked,  
⇒ Chapter 9.5 “Programming”, page 29, (code word 0110)  
The instrument is in the measurement mode,  
⇒ Chapter 9.2 “Principle of operation”, page 26.

---


#### Calibration

- \* Simulate the calibration point for the sensor on the transmitter, or determine the value by a comparison measurement.
  - \* Press the  +  keys
  - \* The lower display shows “Cal2” with the decimal point flashing.
  - \* Using the  or  keys, adjust the displayed value to match the known
-

## 22 Universal indicator

---

value. When the display has stabilized, the calibration procedure can be completed.

- \* Press the  key.  
The instrument stores the new zero.  
The instrument is in the measurement mode again.



If, on completion of calibration, the instrument shows “Err” in the temperature display,  
⇒ Chapter 34.1 “Messages”, page 103.

---









### 22.6 2-point calibration

#### Initial condition

A transmitter is connected to the dTRANS Az 01,  
⇒ Chapter 22.1 “Measurement circuit for the universal indicator”, page 66.  
The calibration procedure has been selected,  
⇒ Chapter 22.3 “Calibration”, page 67.  
The operating level is unlocked,  
⇒ Chapter 9.5 “Programming”, page 29, (code word 0110)  
The instrument is in the measurement mode,  
⇒ Chapter 9.2 “Principle of operation”, page 26.

---

#### Calibration

- \* Press the  +  (Cal) keys  
the upper display shows a value.  
The lower display shows “Cal1”, with the decimal point flashing.
- \* Using the  or  keys, adjust the display value to the value that was simulated (or the value that was determined by comparison measurement).
- \* Press the  key.  
The upper display shows a value.  
The lower display shows “Cal2”, with the decimal point flashing.
- \* Using the  or  keys, adjust the display value to the value that was simulated (or the value that was determined by comparison measurement).
- \* Press the  key.  
The instrument stores the new zero and the new slope.  
The instrument is in the measurement mode again.



If, on completion of calibration, the instrument shows “Err” in the temperature display,  
⇒ Chapter 34.1 “Messages”, page 103.

---

# 23 Operator level of the universal indicator

## 23.1 Settings

### Pre-conditions

How to access the operating level, or leave this level,  
 ⇨ Chapter 9.2 “Principle of operation”, page 26ff.

The operating level must be unlocked,  
 ⇨ “Unlocking the levels”, page 29, (code word 0110).



It is possible that not all of the following parameters are needed or displayed, depending on the configuration of the controller functions.



For an explanation of the terminology used,  
 ⇨ Chapter 33 “Glossary”, page 95ff.

How to configure controllers,  
 ⇨ Chapter 27.1 “Configuration”, page 85ff.

Designation	Parameter (display)	Value range	Factory setting	displayed if ... is configured	see Configuration parameter
Setpoint 1	SP(r)1	SiL – SiH (start to end of the transmission range)	SiL	K1	C211
Setpoint 2	SP(r)2		SiH	K2	
Setpoint 3	SP(r)3		SiL	Setpoint changeover	C112
Setpoint 4	SP(r)4		SiH		
Code word	CodE	4-digit	0000		
Limit LK A (K1)	SP A	SiL – SiH (start to end of the transmission range) or -50 to 250°C	-1999	K1	C214
Limit LK b (K2)	SP b			K2	
Limit LK C (K3)	SP C			K3	C113
Limit LK d (K4)	SP d			K4	
Limit LK E (K5)	SP E			K5	
Temperature for compensation (manually adjustable or automatic, depending on the configuration)	InP2	(•C)	25		C111
Alarm tolerance	AL1	0.000 to 20.00 mA	0	Controller alarm messages	C211 or C213
Alarm delay	AL2	0 to 9999 sec	300		

# 24 Parameter level of the universal indicator

## 24.1 Settings



If it is necessary to reconfigure a number of instrument parameters,  
 ⇒ Chapter 35.1 “Programming the controller”, page 105ff.

### Pre-conditions

How to access the parameter level, or leave this level,  
 ⇒ Chapter 9.2 “Principle of operation”, page 26ff.

The parameter level must be unlocked,  
 ⇒ “Unlocking the levels”, page 29, (code word 0020).



It is possible that not all of the following parameters are needed or displayed, depending on the configuration of the controller functions.



For an explanation of the terminology used,  
 ⇒ Chapter 33 “Glossary”, page 95ff.

How to configure controllers,  
 ⇒ Chapter 27.1 “Configuration”, page 85ff.

Parameter	Display	Value range	Factory setting	displayed if ... is configured
Proportional band 1	Pb1	0000 to SiH	50% SiH	Relay 1, pulse frequency or pulse width C211
Proportional band 2	Pb2			Relay 2, pulse frequency or pulse width C211
Derivative time 1	dt1	0 to 9999 sec	0	Relay 1, pulse frequency or pulse width C211
Derivative time 2	dt2			Relay 2, pulse frequency or pulse width C211
Reset time 1	rt1			Relay 1, pulse frequency or pulse width C211
Reset time 2	rt2			Relay 2, pulse frequency or pulse width C211
Minimum ON time 1 (for limit controller or pulse width controller) or minimum pulse width 1 (for pulse frequency controller)	tr1	0.2 to 999.9 sec	0.2	Controller 1, pulse width C211
				pulse frequency C211
Minimum ON time 2 (for pulse width controller) or minimum pulse width 2 (for pulse frequency controller)	tr2			Relay 2, pulse width C211
				pulse frequency C211

## 24 Parameter level of the universal indicator

Parameter	Display	Value range	Factory setting	displayed if ... is configured
Switching differential 1	HYS1	00.01 to SiH or °C	2% SiH	Relay 1, limit value C211
Switching differential 2	HYS2			Relay 2, limit value C211
Switching differential 3	HYS3			Relay 3, limit value C213
Switching differential 4	HYS4			Relay 4, limit value C213
Switching differential 5	HYS5			Relay 5, limit value C214
Pull-in delay 1	Ond1	0.00 to 999.9 sec	1.0	Relay 1, limit value C211
Pull-in delay 2	Ond2			Relay 2, limit value C211
Pull-in delay 3	Ond3			Relay 3, limit value C213
Pull-in delay 4	Ond4			Relay 4, limit value C213
Pull-in delay 5	Ond5			Relay 5, limit value C214
Drop-out delay 1	Ofd1		0.2 sec	Relay 1, limit value C211
Drop-out delay 2	Ofd2			Relay 2, limit value C211
Drop-out delay 3	Ofd3			Relay 3, limit value C213
Drop-out delay 4	Ofd4			Relay 4, limit value C213
Drop-out delay 5	Ofd5			Relay 5, limit value C214
Maximum pulse frequency 1	Fr1	0 to 150 pulse/min	100	Relay 1, pulse frequency C211
Maximum pulse frequency 2	Fr2			Relay 2, pulse frequency C211
Pulse period 1	CY1	1.0 to 999.9 sec	20.0	Relay 1, pulse width C211
Pulse period 2	CY2			Relay 2, pulse width C211
Output level limit Relay 1	Y1	0 to 100%	100	Relay 1, pulse frequency or pulse width C211
Output level limit Relay 2	Y2			Relay 2, pulse frequency or pulse width C211
Filter constant	dF	0 to 100 sec	0.6	
Actuator time	tt	15 to 3000 sec	60	Modulating controller C211

# 25 Configuration level of the universal indicator

## 25.1 General

The basic functions of the instrument can be displayed and/or altered at the configuration level.



If it is necessary to reconfigure a number of instrument parameters,  
 ⇒ Chapter 35.1 “Programming the controller”, page 105ff.



For an explanation of the terminology used,  
 ⇒ Chapter 33 “Glossary”, page 95ff.  
 How to configure controllers,  
 ⇒ Chapter 27.1 “Configuration”, page 85ff.

### Pre-conditions

How to access the configuration level, or leave this level,  
 ⇒ Chapter 9.2 “Principle of operation”, page 26ff.

The configuration level is unlocked,  
 ⇒ “Unlocking the levels”, page 29, (code word 0300).

## 25.2 Analog inputs - C111

	a	b	c	d
<b>C111*</b>	<b>1</b>	<b>0</b>	<b>0</b>	<b>0</b>
<b>Not used</b>				
	0			
<b>Analog input 1 (current signal)</b>				
0 – 20 mA		0		
4 – 20 mA		1		
<b>Not used</b>				
			0	
<b>Type of temperature acquisition</b>				
Manual temperature compensation				0
Automatic temperature compensation with Pt100 <sup>1</sup>				1
Automatic temperature compensation with Pt1000 <sup>1</sup>				2

\*The factory-set parameters are shown in the position boxes.

<sup>1</sup> As a option, a Pt100 or Pt1000 can be connected. The measured temperature of the process is then shown in the lower display. In this mode, the temperature can be monitored with a limit comparator, see also configuration codes C211 or 213.

## 25 Configuration level of the universal indicator

---

### 25.3 Configuration parameter for general functions (not specific to the universal indicator)

---

⇒ Chapter 26 “Configuration level (not instrument-specific)”, page 76.

---

### 25.4 nuLL - SLoP - SiL - SiH

<b>SLoP</b>	Slope correction (end value) <sup>1</sup>
<b>nuLL</b>	Zero point correction (offset) <sup>1</sup>
<b>SiL</b>	Start of transmission range This value is taken from the operating instructions for the attached instrument. Example for a JUMO 202630 (transmitter for free chlorine -> transmission range = 0 – 2.0 mg/l): SiL = 0.00
<b>SiH</b>	End of transmission range This value is taken from the operating instructions for the attached instrument. Example for a JUMO 202630 (transmitter for free chlorine -> transmission range = 0 – 2.0 mg/l): SiL = 2.00

---

<sup>1</sup> This parameter does **not** provide any indication of the true state of the probe that is connected.

## 26 Configuration level (not instrument-specific)

---

### 26.1 General

The basic functions of the instrument can be displayed and/or altered at the configuration level.



If it is necessary to reconfigure a number of instrument parameters,  
 ⇨ Chapter 35.1 “Programming the controller”, page 105ff.



For an explanation of the terminology used,  
 ⇨ Chapter 33 “Glossary”, page 95ff.  
 How to configure controllers,  
 ⇨ Chapter 27.1 “Configuration”, page 85ff.

#### Pre-conditions

How to access the configuration level, or leave this level,  
 ⇨ Chapter 9.2 “Principle of operation”, page 26ff.

The configuration level is unlocked,  
 ⇨ “Unlocking the levels”, page 29, (code word 0300).

### 26.2 Logic inputs... - C112

	a	b	c	d
<b>C112*</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>
<b>Function of logic input 1<sup>1</sup></b>				
No function	0			
Key inhibit	1			
Alarm stop	2			
Hold	3			
Freeze measurement	4			
Setpoint changeover	5			
Range expansion (x10)	6			
HOLD reversed	7			
Reset alarm time	8			
<b>Function of logic input 2<sup>1</sup></b>				
No function		0		
Key inhibit		1		
Alarm stop		2		
Hold		3		
Freeze measurement		4		
Setpoint changeover		5		
Range expansion (x10)		6		
HOLD reversed		7		
Reset alarm time		8		

## 26 Configuration level (not instrument-specific)

<b>I component of the controller</b>	I
The I component of the controller is active between the two setpoints	0
The I component of the controller is not active between the two setpoints	1

\*The factory-set parameters are shown in the position boxes.

<sup>1</sup> Function description ⇒ Chapter 31.1 “Functions”, page 92.

### 26.3 Serial interface... - C113

	a	b	c	d
<b>C113*</b>	<b>0</b>	<b>1</b>	<b>0</b>	<b>0</b>
<b>Device address</b>				
Address 0	0	0		
Address 1	0	1		
...				
Address 99	9	9		
<b>Serial interface</b>				
MODbus / Jbus, 9600 bps, no parity			0	
MODbus / Jbus, 9600 bps, odd parity			1	
MODbus / Jbus, 9600 bps, even parity			2	
MODbus / Jbus, 4800 bps, no parity			3	
MODbus / Jbus, 4800 bps, odd parity			4	
MODbus / Jbus, 4800 bps, even parity			5	
<b>Response of the process value output to out-of-range or off-scale</b>				
Underrange		Overrange		
0%		100%		0
0%		110%		1
approx. -10% <sup>1</sup>		100%		2
approx. -10% <sup>1</sup>		110%		3

\*The factory-set parameters are shown in the position boxes.

<sup>1</sup> For 0 – 10V and 0 – 20mA output signals, output is approx. -4% for underrange.

## 26 Configuration level (not instrument-specific)

### 26.4 Controller options - C211

	a	b	c	d
<b>C211*</b>	<b>2</b>	<b>2</b>	<b>x</b>	<b>0</b>
<b>Function K1<sup>1</sup> (output 1)</b>				
off	0			
Limit controller	1			
Pulse width controller	2			
Pulse frequency controller	3			
Modulating controller <sup>2</sup>	4			
Proportional controller	5			
<b>Function K2<sup>1</sup> (output 2)</b>				
off		0		
Limit controller		1		
Pulse width controller		2		
Pulse frequency controller		3		
Modulating controller <sup>2</sup>		4		
Proportional controller		5		
<b>Calibration procedure<sup>5</sup></b>				
Zero point for 1-point calibration, process value output not frozen			0	
Zero point for 1-point calibration, process value output frozen			1	
End value for 1-point calibration, process value output not frozen			2	
End value for 1-point calibration, process value output frozen			3	
2-point calibration, process value output not frozen			4	
2-point calibration, process value output frozen			5	
<b>Manual operation<sup>3</sup></b>				
Manual operation off				0
Manual operation enabled, switched <sup>4</sup>				1
Manual operation enabled, only while the key is pressed				2
Simulated process value output 1				3
Simulated process value output 2				4

\*The factory-set parameters are shown in the position boxes.

- <sup>1</sup> Only effective if "1" is configured in C214c and / or "1" in C214d -> controller 2 or controller 1.
- <sup>2</sup> If the function "K1 (output 1) Modulating controller" is selected, then the function "K2 (output 2) Modulating controller" must also be selected (and the other way round).
- <sup>3</sup> Function description, ⇨ Chapter 28 "Manual operation", page 88.
- <sup>4</sup> Not possible if limit comparators have been configured.
- <sup>5</sup> The entry depends on the measurement variable that was configured (depends on rAnG).

## 26 Configuration level (not instrument-specific)

### 26.5 Controller outputs - C212

	a	b	c	d
<b>C212*</b>	<b>0</b>	<b>0</b>	<b>1</b>	<b>0</b>
<b>Signal K1 for overrange / hold</b>				
Output level 0%	0			
Output level 100%	1			
Output level 50% (not for limit controller)	2			
Output accepted	3			
<b>Signal K2 for overrange / hold</b>				
Output level 0%		0		
Output level 100%		1		
Output level 50% (not for limit controller)		2		
Output accepted		3		
<b>MIN / MAX contact for K1 / K2</b>				
K1	K2			
MIN	MIN		0	
MIN	MAX		1	
MAX	MIN		2	
MAX	MAX		3	
<b>Make / break contact</b>				
K1	K2			
make	make			0
make	break			1
break	make			2
break	break			3

---

\*The factory-set parameters are shown in the position boxes.

---

## 26 Configuration level (not instrument-specific)

### 26.6 Other outputs I - C213

	a	b	c	d
<b>C213*</b>	<b>8</b>	<b>0</b>	<b>3</b>	<b>0</b>
<b>Function of output 3 (relay 3 or analog output)</b>				
No function	0			
Hold (relay only)	1			
Alarm pulse contact (relay only)	2			
Alarm steady contact (relay only)	3			
MAX temperature limit comparator (relay only)	4			
MIN temperature limit comparator (relay only)	5			
MAX pH / redox limit comparator (relay only)	6			
MIN pH / redox limit comparator (relay only)	7			
Process value pH (analog output only)	8			
Process value temperature (analog output only)	9			
Proportional controller 1 (analog output only) <sup>1</sup>	A			
Proportional controller 2 (analog output only) <sup>1</sup>	b			
<b>Signal for output 3 (analog process value output only)<sup>2</sup></b>				
0 – 20 mA		0		
4 – 20 mA		1		
0 – 10 V		2		
2 – 10 V		3		
20 – 0 mA		4		
20 – 4 mA		5		
10 – 0 V		6		
10 – 2 V		7		
<b>Function of output 4 (logic output)</b>				
No function			0	
Hold			1	
Alarm pulse contact			2	
Alarm steady contact			3	
MAX temperature limit comparator			4	
MIN temperature limit comparator			5	
MAX pH / redox limit comparator			6	
MIN pH / redox limit comparator			7	
<b>Alarm monitoring of relays K1 and K2<sup>3</sup></b>				
K1 / K2				
monitored / monitored				0
monitored / not monitored				1
not monitored / monitored				2
not monitored / not monitored				3

\*The factory-set parameters are shown in the position boxes.

## 26 Configuration level (not instrument-specific)

- <sup>1</sup> 5xxx or x5xx must be selected in C211, SoL1 / SoL2 must be 0 and SoH1 / SoH2 must be 100.
- <sup>2</sup> Only effective if configuration in C213a is "8", "9", "A" or "b".
- <sup>3</sup> A monitored relay contact (K1 / K2) triggers an alarm if the alarm tolerance + alarm delay time is exceeded,  
⇒ Chapter 33 "Glossary", page 95ff.

### 26.7 Other outputs II - C214

	C214*	a	b	c	d
<b>Function of output 5</b> (relay 4 or analog output)	0	0	1	1	
No function	0				
Hold (relay only) <sup>2</sup>	1				
Alarm pulse contact (relay only) <sup>2</sup>	2				
Alarm steady contact (relay only) <sup>2</sup>	3				
MAX temperature limit comparator (relay only) <sup>2</sup>	4				
MIN temperature limit comparator (relay only) <sup>2</sup>	5				
MAX pH / redox limit comparator (relay only) <sup>2</sup>	6				
MIN pH / redox limit comparator (relay only) <sup>2</sup>	7				
Process value pH (analog output only)	8				
Process value temperature (analog output only)	9				
Proportional controller 1 (analog output only) <sup>3</sup>	A				
Proportional controller 2 (analog output only) <sup>3</sup>	B				
<b>Signal for output 5<sup>1</sup></b>					
0 – 20 mA	0				
4 – 20 mA	1				
0 – 10 V	2				
2 – 10 V	3				
20 – 0 mA	4				
20 – 4 mA	5				
10 – 0 V	6				
10 – 2 V	7				
<b>Function of output 2</b>					
No function	0				
Controller 2 <sup>4</sup>	1				
Alarm pulse contact <sup>5</sup>	2				
Alarm steady contact <sup>5</sup>	3				
MAX temperature limit comparator <sup>5</sup>	4				
MIN temperature limit comparator <sup>5</sup>	5				
MAX pH / redox limit comparator <sup>5</sup>	6				
MIN pH / redox limit comparator <sup>5</sup>	7				

## 26 Configuration level (not instrument-specific)

<b>Function of output 1</b>	I
No function	0
Controller 1 <sup>6</sup>	1
Alarm pulse contact <sup>7</sup>	2
Alarm steady contact <sup>7</sup>	3
MAX temperature limit comparator <sup>7</sup>	4
MIN temperature limit comparator <sup>7</sup>	5
MAX limit comparator <sup>7</sup>	6
MIN limit comparator <sup>7</sup>	7

\*The factory-set parameters are shown in the position boxes.

- 1 Only effective if configuration in C214a is "8", "9", "A" or "b".
- 2 No optical status indication.
- 3 5xxx or x5xx must be selected in C211, SoL1 / SoL2 must be 0 and SoH1 / SoH2 must be 100.
- 4 Enter the desired controller function in C211a.
- 5 The corresponding setting must be made in C211 (x0xx).
- 6 Enter the desired controller function in C211b.
- 7 The corresponding setting must be made in C211 (0xxx).

### 26.8 Response for HOLD / Overrange - C215

	a	b	c	d
<b>C215*</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>
<b>No function</b>	I	I	I	I
	0	I	I	I
		I	I	I
<b>K5</b>		I	I	I
Inactive		0	I	I
Active		1	I	I
			I	I
<b>K4</b>			I	I
Inactive			0	I
Active			1	I
				I
<b>K3</b>				I
Inactive				0
Active				1

## 26 Configuration level (not instrument-specific)

---

### 26.2 SoL - SoH - SPL - SPH - OFFS - SiL - SiH

#### SoL

Standard signal scaling of the analog process value output.

**Start value** of the range for standard signals of the process value output.

SoL1 -> Output 3

SoL2 -> Output 5

Value range:

depending on configuration -1.00 to 14.00 pH 50.0 to +250°C

Factory setting -1.00 pH

Example 1:

**4** – 20 mA should correspond to **2.00** – **9.00** pH

-> SoL = **2.00** / SoH = **9.00**

Example 2:


**0** – 20 mA should correspond to **-10** to **+40**°C

-> SoL = **-10.0** / SoH = **40.0**

Example 3:

**0** – 100% of the controller output should correspond to **0** – 8 V of the output signal (but the standard output signal of the controller is 0 – 10 V)

-> SoL = **0** / SoH = **120**



#### SoH

Standard signal scaling of the analog process value output.

**End value** of the range for standard signals of the process value output.

SoH1 -> Output K3

SoH2 -> Output K5

For value ranges and factory settings, see “SoL” above.

#### SPL

Setpoint limiting for controller setpoints.

This parameter is used to define the lower limit setting for the controller setpoints SPr1/2/3/4.

#### SPH

Setpoint limiting for controller setpoints.

This parameter is used to define the upper limit setting for the controller setpoints SPr1/2/3/4.

#### OFFS

Process value correction for temperature

The process value correction can be used to correct the measured value of the

## 26 Configuration level (not instrument-specific)

---

temperature input, either upwards or downwards.

Value range: -199.9 to 199.9°C or °F

Factory setting: 0°C

Example:

Measured value	Offset	Displayed value
34.7°C	+0.3°C	35.0°C
35.3°C	-0.3°C	35.0°C

---

### SiL

Start of transmission range

This value is taken from the operating instructions for the attached instrument.

Example for a JUMO 202630

(transmitter for free chlorine -> transmission range = 0 – 2.0 mg/l):

SiL = 0.00

---

### SiH

End of transmission range

This value is taken from the operating instructions for the attached instrument.

Example for a JUMO 202630

(transmitter for free chlorine -> transmission range = 0 – 2.0 mg/l):

SiL = 2.00

---

## 27.1 Configuration



For an explanation of the terminology used,  
 ⇒ Chapter 33 “Glossary”, page 95ff.

### Possible combinations

The control functions of outputs 1 and 2 can be freely combined<sup>1</sup>:

- Controller off
- Limit controller
- Pulse width controller
- Pulse frequency controller

<sup>1</sup> Exception: When using a modulating controller, outputs 1 and 2 must have the same configuration.

The controller functions are determined by the following parameters:

Configuration level <sup>1</sup>					Parameter level <sup>2</sup>	Operating level <sup>3</sup>
C211	C212	C212	C213	C214		
Controller off	--	--	--	--	--	--
Limit controller	MIN / MAX contact	make / break contact	--	--	Switching differential <b>HYS</b> Pull-in delay <b>Ond</b> Drop-out delay <b>Ofd</b>	Setpoint <b>SP(r)</b>
Pulse width controller	MIN / MAX contact	make / break contact	--	--	Proportional band <b>Pb</b> Derivative time <b>dt</b> Reset time <b>rt</b> Minimum ON time <b>tr</b> Pulse period <b>CY</b> Output level limit <b>Y1</b> or <b>Y2</b>	Setpoint <b>SP(r)</b>
Pulse frequency controller	MIN / MAX contact	make / break contact	--	--	Proportional band <b>Pb</b> Derivative time <b>dt</b> Reset time <b>rt</b> Minimum pulse width <b>tr</b> Maximum pulse frequency <b>Fr</b> Output level limit <b>Y1</b> or <b>Y2</b>	Setpoint <b>SP(r)</b>
Modulating controller	MIN / MAX contact	make / break contact	--	--	Proportional band <b>Pb</b> Derivative time <b>dt</b> Reset time <b>rt</b> Minimum ON time <b>tr</b> Pulse period <b>CY</b> Output level limit <b>Y1</b> or <b>Y2</b> Actuator time <b>tt</b>	Setpoint <b>SP(r)</b>
Proportional controller	MIN / MAX contact	make / break contact	Proportional controller 1	Proportional controller 2	Proportional band <b>Pb</b> Derivative time <b>dt</b> Reset time <b>rt</b> Output level limit <b>Y1</b> or <b>Y2</b>	Setpoint <b>SP(r)</b>


<sup>1</sup> ⇒ Chapter 26.4 “Controller options - C211”, page 78 or  
 ⇒ Chapter 26.5 “Controller outputs - C212”, page 79 or  
 ⇒ Chapter 26.6 “Other outputs I - C213”, page 80 or  
 ⇒ Chapter 26.7 “Other outputs II - C214”, page 81.

<sup>2</sup> ⇒ Chapter 20 “Parameter level of the conductivity indicator”, page 61ff.

<sup>3</sup> ⇒ Chapter 19 “Operator level of the conductivity indicator”, page 60ff.

# 27 Controller

**Example  
break / make  
contact**



		Range I		Range II		Range III	
		LED	contact	LED	contact	LED	contact
MIN	make contact	on	1	off	0	off	0
	break contact	on	0	off	1	off	1
MAX	make contact	off	0	off	0	on	1
	break contact	off	1	off	1	on	0

**Configuration  
notes**

Both outputs (K1 / K2) can be configured as pulse width or pulse frequency outputs (or as a combination).

Switching action K1 / K2	Setpoints w1 / w2
min / min	w1 < w2
min / max	w1 < w2
max / max	w1 > w2
max / min	w1 > w2

## 27.2 Controller optimization


### Optimum adjustment

The optimum adaptation of the controller to the control loop can be tested by recording the starting phase.


The following diagrams (referred to the PID action) indicate where the adjustments may be incorrect, and how they can be rectified.

It can be seen that a slower control action with higher stability can be achieved by increasing either the proportional band  $P_b$  or the reset time  $t_r$ .


A smaller proportional band  $P_b$  and / or a shorter reset time  $t_r$  will result in a control action with less damping.




optimum




$t_r, dt$  too small



$t_r, dt$  too large



$P_b$  too small



$P_b$  too large

# 28 Manual operation

**Description** In manual operation, outputs K1, K2 and K3 can be operated by hand, independently of the controller.




Manual operation is only possible if it has been configured first.  
 ⇒ Chapter 26.4 “Controller options - C211”, page 78.  
 The output level limiting is effective during manual operation (except for limit controllers).

**Initial condition** The instrument is in the measurement mode.

## 28.1 Manual operation for outputs K1, K2 or K3

**Activate** In manual operation, outputs K1, K2 and K3 can be operated by hand.



- \* Press keys + for less than 1 second – this starts “Manual operation 1”. The upper LED display switches between the momentary value and the text “HAnd”, the lower display shows the present temperature.
- \* Activate or deactivate a particular output, see table

Key	Output
	K1 <sup>1</sup>
	K2 <sup>1</sup>
	K3 <sup>2</sup>

- \* Return to measurement mode with

<sup>1</sup> Output level will be 0 / 100% for a proportional controller.  
<sup>2</sup> Only while the key is pressed. Only when the third relay is fitted (“Output 310”, ⇒ Chapter 4.1 “Type designation”, page 11).

### 28.2 Simulated process value output

#### Setting

---

When “Simulated process value output” has been configured,  
⇒ Chapter 26.4 “Controller options - C211”, page 78,  
the upper display shows “HAnd” alternately with 50.0 (%).

- \* Use ▼ to reduce the signal at the process value output in 10% steps,  
use ▲ to increase the signal at the process value output in 10% steps.

Example: Output signal 0 – 20 mA,  
intended simulated output signal 8 mA  
=> Setting 40%

---


# 29 Hold

## 29.1 Hold controller

**Description** When “Hold” is activated, the relay outputs take up the status defined in the configuration parameters “Controller outputs” – C212 and “Response to HOLD / Overrange” – C215,  
⇒ Chapter 26.5 “Controller outputs - C212”, page 79.  
⇒ Chapter 26.8 “Response for HOLD / Overrange - C215”, page 82.  
Any alarm delay time that may be running is set to “0”, but no alarm is produced.

**Initial condition** The operating level is unlocked,  
⇒ “Unlocking the levels”, page 29. (0110).  
The instrument is in the measurement mode.

**Activate “Hold” (manual)**



\* Press  $\uparrow$  + EXIT for longer than 2 seconds (but less than 4 seconds)

The upper LED display shows “HoLd” alternately with the momentary measurement

\* Return to measurement mode by pressing  $\uparrow$  + EXIT for longer than 2 seconds (but less than 4 seconds)






The controller outputs K1, K2 and K3 (depending on the instrument version and configuration) are set according to the configuration of C212.

The output level limiting is effective during “Hold” (except for limit controllers).

After configuration as limit comparator(s), outputs K1, K2, K3, K4 and K5 (depending on the instrument version and configuration) are set according to the configuration of C212 and C215.

### 30.1 Display software version and temperature unit



- \* Display the software version and unit for temperature with  + 

The software version is shown in the upper display.

The unit (lower display) can be either •C or •F (standard is •C; a conversion to •F can only be carried out at the factory).




---

# 31 Logic inputs

## 31.1 Functions




Setting the functions of the logic inputs,  
see **“Configuration level / logic inputs...- C112”, page 36.**

<b>Status of the logic input</b>		
<b>Key inhibit</b>	The indicator/controller can be operated from the keys on the front panel.	The indicator/controller can <b>not</b> be operated from the keys on the front panel.
<b>Alarm stop</b>	Alarm signals are generated at the configured output.	The alarm contact is deactivated – the LED for the configured alarm output blinks.
<b>Reset alarm time</b>	Alarm signals are generated at the configured output.	The alarm contact is deactivated. Any alarm delay that has started to run will be set to zero and held.
<b>Hold</b>	Controller active	Hold, ⇒ Chapter 29 “Hold”, page 90.
<b>Hold reversed</b>	Hold, ⇒ Chapter 29 “Hold”, page 90.	Controller active
<b>Measurement freeze</b>	The measured process value for the first measurement variable is displayed.	The measured process value for the first measurement variable is frozen.
<b>Setpoint changeover</b>	Setpoint pair 1 (SP1 and SP 2) is active.  <b>Display at operating level:</b> SPr1 SPr2 SP 3 SP 4	Setpoint pair 2 (SP3 and SP 4) is active.  <b>Display at operating level:</b> SP 1 SP 2 SPr3 SPr4
<b>Range expansion (x10)</b>	Process value output is linear between SoL and SoH	Process value 0 – 10% of full scale is scaled up to 0 – 100% of the process value output.  

### 32.1 MODbus /Jbus

This interface can be used to integrate the controller into a data network. The following applications, for instance, can be implemented:

- Process visualization
- Plant/system control
- Recording/data logging



The bus system is designed around the master-slave concept. A master computer can communicate with up to 31 controllers or other devices (slaves). The interface is a serial interface using the RS422 or RS485 standards.

The following data protocols may be used:

- MODbus /Jbus protocol



This interface can only be retrofitted at the factory.

---

# 32 Interface

---

## 32.2 Profibus-DP

**Fieldbus**

The Profibus-DP interface can be used to integrate the controller into a fieldbus system operating according to the Profibus-DP standard. This Profibus version is especially designed for communication between automation systems and decentralized peripheral devices at the field level, and optimized for speed.

---


**Data transmission**

The data transmission is made serially, using the RS485 standard.

---

**GSD generator**

GSD generator, the project-planning tool that is supplied with the package (GSD = Gerätestammdaten, i.e. basic device data), is used to make a selection of device characteristics for the controller to create a standardized GSD file that is used to integrate the controller into the fieldbus system.



For a detailed description, see the PROFIBUS-DP Interface Description B70.3560.2.1


---





Parameters which apply to both output K1 and K2 (e.g. tAb1 or tAb2) are only explained once.


Term	Parameter	Explanation
Actuator time	tt	The value for this parameter must be taken from the specific data for the actuator device (e.g. an motorized valve).
Alarm contact		<p>With limit control, the active time of the outputs K1 or K2 can be monitored (<b>dosing monitoring</b>). If the active time exceeds an adjustable value (<b>Alarm delay AL2</b>), then the alarm contact is activated.</p> <p>With pulse width or pulse frequency control, the size of the control deviation is monitored. If the control deviation exceeds the adjustable <b>Alarm tolerance AL1</b>, <u>and</u> remains outside this tolerance for longer than the <b>Alarm delay AL2</b>, then the alarm contact is activated.</p>
Alarm delay	AL2	If the control deviation exceeds the adjustable <b>Alarm tolerance AL1</b> , <u>and</u> remains outside this tolerance for longer than the adjustable Alarm delay AL2, then the alarm contact is activated.
Alarm tolerance	AL1	<p>If the process value goes above or below the value of setpoint <u>plus/minus</u> alarm tolerance (<math>x &gt; SP_{r..} + AL1</math> or <math>x &lt; SP_{r..} - AL1</math>) <u>and</u> remains outside these limits for longer than the <b>Alarm delay</b>, then the alarm contact is activated.</p> <p> The alarm tolerance is only active if pulse width or pulse frequency control has been configured,            ⇨ Chapter 26.4 “Controller options - C211”, page 78.            If limit control is configured, then the values for the alarm tolerance will be ignored.</p>



## 33 Glossary

Term	Parameter	Explanation
Bilinear output	C311	<p>This function has the effect that a small or large input signal produces a disproportionate analog process value output signal. The knee-point of the characteristic can be shifted along the dotted 50% line. The factory setting of 50% produces a straight-line characteristic.</p> 
Break contact / make contact	C212	<p><b>Break contact:</b> As long as the switching condition <b>is not</b> fulfilled, the corresponding output is active (closed).</p> <p><b>Make contact:</b> As long as the switching condition <b>is</b> fulfilled, the corresponding output is active (closed).</p>
Code word	CodE	<p>After the supply voltage has been applied, all levels are protected against accidental or unauthorized editing. If parameter settings have to be altered, the levels must be unlocked by entering a code word. A code word is also required to be able to calibrate the electrode.</p> <p>It is not necessary to remove the protection against editing if you just want to check the settings.</p>
Derivative time	dt	<p>This determines the differential component of the controller output signal. If the derivative time is set to "0", then the control response has no differential component.</p>
Dosing monitoring	C213	<p>Defines whether the output K1 and / or K2 is / are monitored by the alarm contact (see also under "Alarm contact").</p>
Drop-out delay	OFd	<p>The time required for the corresponding relay contact to return to the inactive status when the switching condition is <b>no longer</b> fulfilled. Brief excursions above or below the setpoint will be ignored by the controller.</p>
End of transmission range	SiH	<p>This value is taken from the operating instructions for the attached instrument.</p> <p>Example for a JUMO 202630 (transmitter for free chlorine -&gt; transmission range = 0 — 2.0 mg/l): SiH = 2.00</p>


Term	Parameter	Explanation
Filter constant	df	<p>The setting of this parameter is used to filter out interference or input signals which would provoke undesirable reaction in the controller. The filter is a 2nd order digital filter.</p> 
Hysteresis	HYS	see <b>Switching differential</b>
Limit controller	C211	<p>A single-setpoint controller with <b>pull-in</b> and / or <b>drop-out delay</b>.</p> 
Logic input 1 / 2	C112	see "Logic inputs", page 45.
Make contact / break contact	C212	<p><b>Make contact:</b> As long as the switching condition <b>is</b> fulfilled, the corresponding output is active (closed).</p> <p><b>Break contact:</b> As long as the switching condition <b>is not</b> fulfilled, the corresponding output is active (closed).</p>

## 33 Glossary


Term	Parameter	Explanation
MAX limit comparator	C211 SP A SP b SP C SP d SP E	<p>SP A ... E defines the switching point. Function: The output has the “active” status when the process value is <b>above</b> the limit value.</p>  <p>SP A ... E are only visible at the operating level, when at least one limit comparator has been configured.</p> <p>Assignment:            SP A is affected by: HYS1, Ond1 and OfD1            SP b is affected by: HYS2, Ond2 and OfD2            SP C is affected by: HYS3, Ond3 and OfD3            SP d is affected by: HYS4, Ond4 and OfD4            SP E is affected by: HYS5, Ond5 and OfD5</p>
MIN / MAX contact	C212	<p><u>MIN contact</u>: The controller output is active if the process value is below the setpoint.  <u>MAX contact</u>: The controller output is active if the process value is above the setpoint.</p> <p>For further explanation,            ⇒ Chapter 27 “Controller”, page 85ff.</p>
Minimum ON time	tr	<p>With a limit controller, pulse width controller, or modulating controller.            The value selected is determined by the technical requirements of the equipment operated by the controller (solenoid valves, dosing pumps etc.).</p>
MIN temperature limit comparator	C211 SP A ... E	<p>SP A ... E defines the switching point.            Function: The output has the “active” status when the process value is <b>below</b> the limit value.            For explanation, see “MAX limit comparator”.</p>
Modulating controller	C211	<p>A modulating controller can move a motor actuator in steps to any position from 0 — 100% of the actuator range.            A modulating controller can, for instance, be used to operate motorized valves.</p>
Output level limit	Y1 Y2	<p>Defines the maximum output level that can be produced by the corresponding relay, for a pulse width or pulse frequency controller.</p>
Process value x		<p>The signal that is fed to the controller from the conductivity cell.</p>
Process value input 2 (temperature)	C111	<p>With automatic temperature acquisition (using a Pt100 or Pt1000 temperature probe), the measured temperature is shown in the lower display.</p>

Term	Parameter	Explanation
Pull-in delay	Ond	The time required for the corresponding relay contact to be activated when the switching condition is fulfilled. Brief excursions above or below the setpoint will be ignored by the controller.
Pulse frequency	Fr	<p>Maximum pulse frequency (only for a pulse frequency controller)</p> <p>The value selected is determined by the technical requirements of the equipment operated by the controller (solenoid valves, dosing pumps etc.).</p> <p>The value is limited by the <b>minimum pulse width</b>:</p> <p>Pulse frequency [1/min] &lt; (60 / minimum ON time [sec])</p>
Pulse frequency controller	C211	<p>The repetition rate of the pulses depends on the output level and the controller parameters: <b>proportional band Pb, derivative time dt, reset time rt, pulse frequency Fr</b> and <b>output level limits Y1 or Y2</b>.</p> <p>The output signal from a pulse frequency controller can, for instance, be used to operate magnetic dosing pumps.</p> 
Pulse width	tr	For pulse frequency control, otherwise as <b>minimum ON time</b>
Pulse width controller	C211	<p>The width of the pulses depends on the output level and the controller parameters: <b>proportional band Pb, derivative time dt, reset time rt, pulse period CY</b> and <b>output level limits Y1 or Y2</b>.</p> <p>The output signal from a pulse width controller can, for instance, be used to operate solenoid valves.</p> 

## 33 Glossary

Term	Parameter	Explanation
Proportional band	Pb	The range over which the output signal from a pulse width or pulse frequency controller is proportional to the control deviation. Beyond the proportional band, the controller will output the signal defined by the <b>output level limit Y1 or Y2</b> .
Proportional controller	C211 C213 C214	In a proportional controller there is a continuous signal (i.e. a current or voltage) on the output. This signal can take on any intermediate value between a start value and an end value. Depending on the configuration of the instrument, this continuous signal can be in the range 0 – 10 V, 0 – 20 mA or 4 – 20 mA.  Proportional controllers are used, for example, to operate actuator valves.
Pulse contact / steady contact	C213	The behavior of an alarm contact.  <u>Pulse contact:</u> The alarm output remains active for approx. 1 second, even if the switching condition (cause) of the alarm remains present for a longer time.  The LED (for the output that was defined as the alarm output) blinks until the switching condition (the cause) of the alarm is no longer present.  <u>Steady contact:</u> The alarm output remains active until the switching condition (the cause) of the alarm is no longer present.  The LED blinks for the output that was defined as the alarm output.
Pulse period	CY	This value is the period within which the pulse width modulation occurs (only for a pulse width or modulating controller).  The value is limited by the <b>minimum ON time tr</b> , see above: Pulse period [sec]> minimum ON time [sec])
Reset time	rt	Integral time constant – controller parameter in a PI or PID controller. The value determines the speed at which the control deviation is integrated. If the reset time is set to “0”, then the control action has no integral component.
Setpoint 1	SP(r)1	The given value that should be achieved by the control loop (referring to output K1).  The setpoint pair that is fed to the controller is identified in the parameter display by (r). See also <b>Setpoint changeover</b>  <u>Example</u> for the active setpoint pair 1 => SPr1, SPr2 and SP 3, SP 4. for the active setpoint pair 2 => SP 1, SP 2 and SPr3, SPr4.
Setpoint 2	SP(r)2	As for <b>setpoint 1</b> , referring to output K2
Setpoint 3	SP(r)3	Refers to output K1. For explanation see <b>Setpoint 1</b> .   Only with activated <b>setpoint changeover</b>

## 33 Glossary

Term	Parameter	Explanation
Setpoint 4	SP(r)4	Refers to output K2. For explanation see <b>Setpoint 1</b> .  Only with activated <b>setpoint changeover</b>
Setpoint changeover	C112	If setpoint changeover is configured for one of the <b>logic inputs</b> , then setpoint pair 1 is active if the logic input is inactive, i.e. the controller uses the setpoints 1 and 2 (SPr1 and SPr2) for operation. If the logic input is active, then setpoint pair 2 is active, i.e. the controller uses the setpoints 3 and 4 (SPr3 and SPr4) for operation. Active setpoints are identified by an “r” in the parameter name (SPr1 and SPr2 as well as SP3 and SP4 if setpoint pair 1 is active).
Setpoint limiting	SPH	Setpoint limiting for controller setpoints. This parameter is used to define the upper limit setting for the controller setpoints SP1/2/3/4.
Setpoint limiting	SPL	Setpoint limiting for controller setpoints. This parameter is used to define the lower limit setting for the controller setpoints SP1/2/3/4.
Start of transmission range	SiL	This value is taken from the operating instructions for the attached instrument. Example for a JUMO 202630 (transmitter for free chlorine -> transmission range = 0 – 2.0 mg/l): SiL = 0.00
Steady contact / pulse contact	C213	The behavior of an alarm contact. <u>Steady contact:</u> The alarm output remains active until the switching condition (the cause) of the alarm is no longer present. The LED blinks for the output that was defined as the alarm output. <u>Pulse contact:</u> The alarm output remains active for approx. 1 second, even if the switching condition (cause) of the alarm remains present for a longer time. The LED (for the output that was defined as the alarm output) blinks until the switching condition (the cause) of the alarm is no longer present.
Switching condition		The process value goes above or below the setpoint. The switching condition is also dependent on the settings “Break contact/make contact” and “MIN/MAX contact”.


### 33 Glossary

Term	Parameter	Explanation
Switching differential	HYS	<p>(Also <b><i>hysteresis</i></b>) In a limit controller, this is the deviation of the process value from the setpoint that is required to trigger the switching of the control contact in response to a falling or rising process value.</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Limit controller MAX contact make contact</p> </div> <div style="text-align: center;"> <p>Limit controller MIN contact make contact</p> </div> </div>

### 34.1 Messages

Warning / Error	Cause / behavior / action
<b>F010</b>	<p>Alarm tolerance overrun/underrun and alarm delay time for the controller has elapsed.</p> <p>Relays K1/K2 behave as defined by the configuration C212,            ⇒ Chapter 26.5 “Controller outputs - C212”, page 79.</p> <p>Check process value. Check controller parameters.</p>
<b>F022</b>	<p>Underrange.</p> <p>Controller goes to “Hold”,            ⇒ Chapter 29 “Hold”, page 90.</p> <p>Check configured setpoints,            ⇒ Chapter 19.1 “Settings”, page 60.</p> <p>Check electrode / cable / connector.</p>
<b>F023</b>	<p>Overrange.</p> <p>Controller goes to “Hold”,            ⇒ Chapter 29 “Hold”, page 90.</p> <p>Check configured setpoints,            ⇒ Chapter 19.1 “Settings”, page 60.</p>
<b>F024</b>	<p>With automatic temperature acquisition, a temperature was measured below -50•C or above +250•C.</p> <p>Controller goes to “Hold”,            ⇒ Chapter 29 “Hold”, page 90.</p> <p>Check the connection to the resistance thermometer,            ⇒ Chapter 7.1 “Electrical connection”, page 20ff.</p>
<b>F030</b>	<p>Process value output went below the minimum value (SoL) (only if output 3 and / or 5 were configured as the process value output (C213 or C214)).</p> <p>Check the setting,            ⇒ Chapter 21.4 “rAnG - CELL - ALPH”, page 64.</p>
<b>F031</b>	<p>Process value output went above the maximum value (SoH) (only if output 3 and / or 5 were configured as the process value output (C213 or C214)).</p> <p>Check the setting,            ⇒ Chapter 21.4 “rAnG - CELL - ALPH”, page 64.</p>
<b>F050</b>	<p>Parameter limits swapped for process value output: SoL is higher than SoH (only if output 3 and / or 5 were configured as the process value output (C213 or C214)).</p> <p>Check the setting,            ⇒ Chapter 21.4 “rAnG - CELL - ALPH”, page 64.</p>

## 34 Warnings – Errors

Warning / Error	Cause / behavior / action
<b>F053</b>	<p>Incorrect setpoint combination.</p> <p>Precondition: Both controllers must be configured as pulse width or pulse frequency controllers. The controller contacts must be configured as MIN/MIN or MAX/MAX,            ⇒ Chapter 26.5 “Controller outputs - C212”, page 79.</p> <p>Cause: With MIN/MIN there will be an error message if <math>w1 &gt; w2</math>. There is <b>no</b> error message if <math>w1 &lt; w2</math>.</p> <p>With MAX/MAX there will be an error message if <math>w1 &lt; w2</math>. There is <b>no</b> error message if <math>w1 &gt; w2</math>.</p> <p>This also applies to the second pair of setpoints, if setpoint changeover is configured.</p>
<b>F060</b>	<p>Minimum ON time (<math>tr1</math>) is longer than the pulse period 1 (CY1) (only if controller 1 is configured as a pulse width controller), or</p> <p>Minimum ON time (<math>tr1</math>) is longer than 1/60 of the pulse frequency 1 (Fr1) (only if controller 1 is configured as a pulse frequency controller), or            ⇒ Chapter 20.1 “Settings”, page 61ff.</p>
<b>F061</b>	<p>Minimum ON time 2 (<math>tr2</math>) is longer than the pulse period 2 (CY2) (only if controller 2 is configured as a pulse width controller), or</p> <p>Minimum ON time (<math>tr2</math>) is longer than 1/60 of the pulse frequency 2 (Fr2) (only if controller 2 is configured as a pulse frequency controller), or            ⇒ Chapter 20.1 “Settings”, page 61ff.</p>
<b>Err</b>	<p>Calibration finished with an error. The old data are retained.</p> <p><u>Cause:</u>            The value determined during calibration lies outside the permissible range</p> <p><u>Corrective action:</u>            A fresh, correct calibration, (see the chapter for the measurement variable that was configured, e.g. pH indicator / calibration),            or            use the keys to enter the calibration value (altering one digit up or down at a time, and then confirming with the  key).</p>



Errors F010 to F031 and “Err” trigger an alarm; the configured alarm output will switch and the corresponding LED will blink.

With errors F022 to F024 and “Err”, the controller additionally goes to the “HoLd” condition, ⇒ Chapter 29 “Hold”, page 90.

The alarm relay does not switch as a result of one of the warnings F050 to F061, but the corresponding LED will blink.

## 35.1 Programming the controller

### Configuration

If a number of instrument parameters have to be modified in the instrument, then it is advisable to note them in the table below, and then modify these parameters in the sequence given.



The following list shows the maximum number of parameters that can be altered.

Depending on the type and configuration, your instrument may not show some of the listed parameters.

Code words to unlock the individual levels,  
 ⇒ "Unlocking the levels", page 29.

Parameter	Explanation	Factory setting	New setting	
<b>Configuration level</b>				
C111	Analog inputs	1000		36/46/61/ 72
C112	Logic inputs / probe / supply	0000		37/74
C113	Serial interface	0100		37/74
C114	Electrode monitoring	0000		37
C211	Controller options	1120		76
C212	Controller outputs	0010		77
C213	Other outputs I	8030		78
C214	Other outputs II	0011		79
C215	Response for HOLD / Overrange	0000		80
C311	Process value output conductivity	5000		62
SoL1	Scaling of the standard signal – start value K3	0.00		81
SoL2	Scaling of the standard signal – start value K5	0.00		
SoH1	Scaling of the standard signal – end value K3	1.00		
SoH2	Scaling of the standard signal – end value K5	1.00		
SiL	Start of transmission range	0.00		38/47/63/ 73/82
SiH	End of transmission range	1.00		
SPL	Lower setpoint limit for controller setpoints – SP(r)1	0.00		81
SPH	Upper setpoint limit for controller setpoints – SP(r)1	1.00		
rAnG	Display range			28/39/48/ 62/64
CELL	Relative cell constant	100.0		62
ALPH	Temperature coefficient	2.30		63
OFFS	Process value correction for temperature	0.0		81
<b>Parameter level</b>				
Pb1	Proportional band 1	0.50		34/44/59/ 70
Pb2	Proportional band 2	0.50		
dt1	Derivative time 1	0		
dt2	Derivative time 2	0		
rt1	Reset time 1	0		

## 35 Appendix

Parameter	Explanation	Factory setting	New setting	
rt2	Reset time 2	0		34/44/59/ 70
tr1	Minimum ON time 1	0.2		
tr2	Minimum ON time 2	0.2		
HYS1	Switching differential 1	0.30		35/45/60/ 71
HYS2	Switching differential 2	0.30		
HYS3	Switching differential 3	0.30		
HYS4	Switching differential 4	0.30		
HYS5	Switching differential 5	0.30		
Ond1	Pull-in delay 1	1.0		
Ond2	Pull-in delay 2	1.0		
Ond3	Pull-in delay 3	1.0		
Ond4	Pull-in delay 4	1.0		
Ond5	Pull-in delay 5	1.0		
OFd1	Drop-out delay 1	0.2		
OFd2	Drop-out delay 2	0.2		
OFd3	Drop-out delay 3	0.2		
OFd4	Drop-out delay 4	0.2		
OFd5	Drop-out delay 5	0.2		
Fr1	Maximum pulse frequency 1	100		
Fr2	Maximum pulse frequency 2	100		
CY1	Pulse period 1	20		
CY2	Pulse period 2	20		
Y1	Output level limit for K1	100		
Y2	Output level limit for K2	100		
dF	Filter constant	0.6		
tt	Actuator time	60		
<b>Operating level</b>				
SP(r)1	Setpoint 1 for contact K1	0.00		33/43/58/ 69
SP(r)2	Setpoint 1 for contact K2	1.00		
SP(r)3	Setpoint 2 for contact K1	0.00		
SP(r)4	Setpoint 2 for contact K2	1.00		
CodE	Code word to unlock the levels	0000		
SP A	Limit SP A (K1)	-50		
SP b	Limit SP b (K2)	-50		
SP C	Limit SP C (K3)	-50		
SP d	Limit SP d (K4)	-50		
SP E	Limit SP E (K5)	-50		
InP2	Temperature display for compensation (°C)	25.0		
AL1	Alarm tolerance	0.00		
AL2	Alarm delay (sec)	300		



